


## Smart Seeder MODEL 9840 / 9940

**Compact Logix** 



Copyright © 2018 by Burford® Corp.
Version 3.1 - Date: December 2017
Manual Part No.
Serial #

## SAFETY PRECAUTIONS

As Burford® Corp. strives to promote safety in the maintenance and operation of Burford® equipment; we request that the following safety procedures be followed, along with any additional safety procedures set by the customer's in-plant safety officers or local codes.

Read the manual completely before attempting installation or operation of this unit.

This machine may contain programs that are password protected. Contact your supervisor or Burford® Corp. for password.

Incoming electrical power must be properly shielded, routed, and grounded. All safety codes should be followed. Study wiring diagrams before attempting installation.

Disconnect power to equipment before removing any guards or covers. Replace guards or covers before resuming operation of the unit.

Loose clothing, jewelry, and long hair should be considered a safety hazard around mechanical equipment. Ensure that they will not be entangled in the equipment.

Keep clear of moving machine parts. Bodily harm and/or serious injury may result from contact with moving gears, sprockets, chains or pneumatically controlled machine components.

Do not bypass safety switches.

Do not attempt repairs while equipment is running.

Use only original equipment parts designed for safe operation of the equipment.

Only authorized personnel should be allowed to operate or perform maintenance on the unit.

This unit is not wash-down ready. Do not wash the unit or any of its electrical or mechanical components, with any form of high pressure or running liquids.

Orange indicates bodily harm may incur if instructions are not followed.

Red indicates important instructions to prevent unit damage or adverse effects.

Blue indicates useful information to assist in installation and operation of the unit.

### DISCLAIMER

The descriptions and specifications contained in this Service Manual were in effect when this manual was approved for printing. Our policy is one of continuous improvements, and we do hereby reserve the right to discontinue models at any time, or to change specifications, prices, or design without notice and without incurring obligations.

Burford<sup>®</sup> Corp. expressly disclaims any liability for damages and/or injuries caused because of negligence or misuse of its product. Such negligence or misuse includes, but is not limited to, software/program alteration, removal of guards, faulty wiring due to improper installation, subjecting the unit to wash-down environments or any physical or mechanical changes made to a Burford<sup>®</sup> unit, by anyone other than a qualified Burford<sup>®</sup> Technician.

Burford® equipment should only be used for the purpose for which it was sold, and should not be modified in any way without notifying the General Manager of Burford® Corp. in writing of the modification.

The original language for this document is English. Translations to other languages may not be accurate.

## **Contact Us**

Questions, comments, concerns? Let us know.

Mail: 11284 OK-74, Maysville, OK 73057

Phone: (877) 287-3673 or (405) 867-4467

Email: info@burford.com

Web: burford.com

## **TABLE OF CONTENTS**

SAF	FETY PRECAUTIONS	III
DIS	SCLAIMER	IV
TAE	BLE OF CONTENTS	V
CHA	APTER 1: INTRODUCTION	16
-	Specifications	17
•	Models	17
•	Models	18
•	Basic Topper Identification	19
	Topper Identification	20
	Topper Identification	21
	MPA Identification	22
	Conveyor Identification	23
•	Conveyor Identification	24
	Spray Rail Identification	25
CHA	APTER 2: KEY COMPONENTS	28
•	Topper	28
	Water Spray	28
	Hopper	29
•	Clutch	29
•	Mandrel Drive Motor	30
•	Mandrel	31
•	Air Controls	32
	Air Flow Controls	33

	F.R.L. Description	34
•	Agitator	35
•	Agitator Solenoid	35
•	Agitator Flow Controls	36
•	Agitator Cylinder	36
•	Upper Channel	37
•	Water Filter	38
•	Spray Rail	39
•	Spray Tip	39
•	Electronic Valve	40
•	Product Sensor	40
•	Operator Control Panel	41
•	нмі	41
•	PLC	42
•	Optional Key Components	42
•	Split / Spray Rail	43
•	Booster Pump (optional)	44
•	Diaphragm Pump (Part of Optional Booster)	45
•	Pump Air Regulator (Optional Booster Pump)	46
•	Pump Output Water Pressure Regulator (Optional Booster Pump)	47
•	Conveyor	48
•	Conveyor Drip Pans	49
•	Vibrator	50
•	Multi-Purpose Tank	50
•	Auto-Fill Systems	51
•	Flour Duster	52

CHA	PTER 3: INSTALLATION	54
•	Installation on an Existing Conveyor	55
•	Installation on Existing Conveyor System, continued	56
•	Installation on Existing Conveyor System, continued	57
•	Installation on a Burford® Conveyor	58
•	Remove Topper from Mount	58
•	Castors	59
•	Level Conveyor	60
•	Level Conveyor, continued	61
•	Permanent Installation	62
•	Product Sensor Setup	63
•	Reflector Product Sensor Setup	64
•	Product Sensor Setup, continued	65
•	Diffuse Reflective Sensor Setup	66
	Diffuse Reflective Sensor Setup, continued	67
•	Install the Water Spray	68
	Conveyor Requirements:	68
•	Unpacking Procedure for Installation On Existing Conveyor	69
	Power Connections	70
•	MPA Installation	71
	MPA Installation, continued	72
	MPA Installation, continued	73
	MPA Installation, continued	74
•	MPA Installation, continued	75
•	Utility Installation	76
•	Installation Arrangements	76

CHA	APTER 4: OPERATION	78
•	Control Panel	79
•	Start Screen	80
•	MainScreen	81
•	Main Screen - Message Display Field	82
•	Main Screen – Current Recipe	83
•	Main Screen – Mandrel Indicator	84
•	Main Screen – Cleanout Hopper	85
•	Main Screen – Topper Mode	86
•	Main Screen – Auto Hopper Fill (Optional)	87
•	Main Screen – Access Mode	88
•	Main Screen - Conveyor (Optional)	89
•	Main Screen - Jog Mandrel	90
•	Main Screen - Water Spray Purge	91
•	Main Screen - Water Split Purge	92
•	Main Screen – Calibrating Motor Positons	93
•	Main Screen – Clean Screen	94
•	Main Screen – Jog Flour Duster	95
•	Main Screen – Language Selection	96
•	Main Screen - Alarm Messages	97
•	Main Screen - Select Recipe / Edit Setup	98
•	Login Screen	99
•	Cleanout Hopper Screen	100
•	Calibrate Motor Positions Screen	101
•	Seeder Configuration Screen	102
•	Seeder Configuration Screen - Mandrel Override	103
	Mandrel	104

	Mandrel Recognition System, continued	105
•	Seeder Configuration Screen - Hopper Overrides	106
•	Seeder Configuration Screen - Conveyor Encoder	107
•	Seeder Configuration Screen - Automation Overrides	108
•	Seeder Configuration Screen - Automation Overrides	109
•	Seeder Configuration Screen - Shutdown Display	110
•	Seeder Configuration Screen - Diagnostics	111
•	Seeder Configuration Screen - Advance Buttons	112
•	Select Recipe Screen	113
•	Recipe Edit Screen Overview	114
•	Recipe Edit Screen Setup	115
•	Recipe Edit Screen Setup	116
•	Recipe Edit Screen Setup	117
•	Recipe Setup Screen Overview	118
•	Recipe Setup Screen	119
•	Recipe Setup Screen, continued	120
•	Recipe Setup Screen, continued	121
•	Recipe Setup Screen, continued	122
•	Recipe Setup Screen, continued	123
•	Recipe Setup Screen Application and Appearance Controls	124
•	Recipe Setup Screen - Agitator Speed	125
•	Pan Types	126
•	Pan Setup Screen (Bread)	127
•	Leading Edge	128
•	Pan Dimension Setup	129
•	Pan Dimension – Bun Pan Setup 1 of 5	130
•	Pan Dimension – Bun Pan Setup 2 of 5	131

	Pan Dimension – Bun Pan Setup 3 of 5	132
•	Pan Dimension – Bun Pan Setup 4 of 5	133
•	Pan Dimension – Bun Pan Setup 5 of 5	134
•	Pan Setup Screen (Bread)	135
•	Bread Pan Easy Way Setup	136
•	Pan Dimension – Bread Pan Easy Way Setup 1 of 5	137
•	Pan Dimension – Bread Pan Easy Way Setup 2 of 5	138
•	Pan Dimension – Bread Pan Easy Way Setup 3 of 5	139
•	Pan Dimension – Bread Pan Easy Way Setup 4 of 5	140
•	Pan Dimension – Bread Pan Easy Way Setup 5 of 5	141
•	Bread Pan Hard Way Setup	142
•	Pan Dimension – Bread Pan Hard Way Setup 1 of 4	143
•	Pan Dimension – Bread Pan Hard Way Setup 2 of 4	144
•	Pan Dimension – Bread Pan Hard Way Setup 3 of 4	145
•	Pan Dimension – Bread Pan Hard Way Setup 4 of 4	146
•	Water Spray	147
•	Water Spray Setup Screen Overview	148
•	Water Spray Setup - Valve Control	149
•	Water Spray Setup - Purge	150
•	Water Spray Setup Trigger Times	151
•	Water Spray Setup – Optional PWM	152
•	Water Split	153
•	Water Split Setup Screen Overview	154
•	Water Split Setup - Valve Control	155
•	Water Split Setup - Purge	156
•	Water Split Setup - Trigger Times	157
•	Automation Setup Screen	158

	Automation Setup Screen - Hopper	159
•	Automation Setup Screen – Pan Guide	160
•	Automation Setup Screen – Spray	161
•	Automation Setup Screen – Splitter	162
•	Hopper - Fill (Optional)	163
•	Hopper - Fill Time	164
•	Hopper Fill Setup	165
•	Seed Verification Alarm (Optional)	166
•	Flour Duster (Optional)	167
•	Flour Duster Setup Screen	168
•	Flour Duster – Speed Control	169
•	Flour Duster – Delay Times	170
CHAF	PTER 5: CREATING A NEW VARIETY	172
CHAF	PTER 5: CREATING A NEW VARIETY  New Recipe - Introduction	172 172
•	New Recipe - Introduction	172
•	New Recipe - Introduction  New Recipe - User Interface (HMI)	172 173
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen	172 173 174
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen  New Recipe - Name the Recipe	172 173 174 175
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen  New Recipe - Name the Recipe  New Recipe - Mandrel Select	172 173 174 175 176
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen  New Recipe - Name the Recipe  New Recipe - Mandrel Select  New Recipe - Hopper Controls	172 173 174 175 176
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen  New Recipe - Name the Recipe  New Recipe - Mandrel Select  New Recipe - Hopper Controls  New Recipe - Agitator Setup	172 173 174 175 176 177
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen  New Recipe - Name the Recipe  New Recipe - Mandrel Select  New Recipe - Hopper Controls  New Recipe - Agitator Setup  New Recipe - Hopper Position	172 173 174 175 176 177 178
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen  New Recipe - Name the Recipe  New Recipe - Mandrel Select  New Recipe - Hopper Controls  New Recipe - Agitator Setup  New Recipe - Hopper Position  New Recipe - Pan Guide	172 173 174 175 176 177 178 179
•	New Recipe - Introduction  New Recipe - User Interface (HMI)  Recipe Setup Screen  New Recipe - Name the Recipe  New Recipe - Mandrel Select  New Recipe - Hopper Controls  New Recipe - Agitator Setup  New Recipe - Hopper Position  New Recipe - Pan Guide  New Recipe - Spray Lift	172 173 174 175 176 177 178 179 180

	New Recipe – Pan Setup, continued	185
•	New Recipe – Water Spray	186
•	New Recipe – Water Split	187
•	New Recipe – Flour Duster (optional)	188
•	New Recipe – Seeder Configuration	189
CHAI	PTER 6: OPERATION PROCEDURES	192
	Theory of Operation	192
•	Main Disconnect	193
•	E-Stop	194
•	Press Start	195
•	Select Recipe	196
•	Select Recipe, continued	197
•	Select Recipe, continued	198
•	Insert Mandrel	199
•	Run Mode	200
•	Recipe Change Same Mandrel	201
•	Recipe Change - Jog Mandrel	202
•	Options	203
•	Models Without Automation	203
•	Pan Guide Adjustment - Manual	204
•	Pan Guide Adjustment - Manual, continued	205
•	Topper Height Adjustment – Manual	206
•	Topper Spray Nozzle Position	207
•	Topper Nozzle Dampness Output	208
•	Topper Product Sensors Topper	209
	Catch Trav	210

CH	APTER 7: TROUBLESHOOTING	212
•	Topper	212
•	Water Splitter Troubleshooting	214
CH	APTER 8: MAINTENANCE	216
•	Drive Settings	216
•	Drive Parameters	217
	Recommended Weekly Maintenance	217
•	Recommended Monthly Maintenance	217
	Recommended Bi-Annual Maintenance	217
•	Cleaning Recommendations	217
•	Maintenance Procedures	218
•	Purging Spray Valves	218
•	Alarm Banner	219
•	Alarm Banner, continued	220
CH	APTER 9: PARTS & DRAWINGS	222
•	Recommended Spare Parts	222

# Chapter 1

## Introduction

16 Chapter 1 Burford

## **CHAPTER 1: INTRODUCTION**

Congratulations on the purchase of your new Burford® Smart Seeder. We are confident that you will enjoy many years of dependable service from your new Topper.

The Burford® Smart Seeder is a proven Burford® design, backed by over 50 years of manufacturing experience. It is the most widely used topper for high volume topping applications on the market today.



The name Burford® is synonymous with innovation. Since the beginning with the first Twist Tyer machine, Burford® is focused on bringing innovation to the Baking Industry. Our passion is developing equipment that increases productivity and uniformity while decreasing production costs.

The Burford® Smart Seeder delivers labor savings and consistency to your product.

With the one touch setup, the Smart Seeder automatically adjusts its settings to provide an accurate coverage and seed savings every time.

The Burford® Smart Seeder has been designed to apply poppy, sesame, cracked wheat, bran, almonds, and other similar ingredients that have been factory approved.

Burford® offers a large lineup of bakery solutions from oilers to shakers. We invite you to visit our website at <a href="www.burford.com">www.burford.com</a> to see the other innovative equipment that we can offer to benefit your bakery today.

## Specifications

#### **ELECTRICAL**

110 V<sub>AC</sub>, 50/60 H<sub>Z</sub>, 1 Ф, 15 А

220 V<sub>AC</sub>, 50/60 H<sub>Z</sub>, 1 Φ, 15 A

220 V<sub>AC</sub>, 50/60 H<sub>Z</sub>, 3 Ф, 15 А

☐ 380/460 V<sub>AC</sub>, 50/60 H<sub>Z</sub>, 1 Ф, 15 А

380/460 V<sub>AC</sub>, 50/60 H<sub>Z</sub>, 3 Ф, 15 А

#### **AIR REQUIREMENTS**

.370 CFM@80 psi maximum


#### **WATER REQUIREMENTS**

40 psi @ 30 GPH

### Models

#### **MODELS**

9840 Product flow moves left to right when viewing from operator's side.9940 Product flow moves right to left when viewing from operator's side.




**Model 9940 Shown** 


## ■ Models

The Burford® Smart Seeder is available in a right hand model and a left hand model. The hand determines product flow in relation to the operator controls. The first two numbers in the model indicate the hand, e.g., 98xx is a right hand unit, and 99xx is a left hand unit.

The Smart Seeder is also available in a range of hopper widths to accommodate different pan widths. The last two numbers in the model indicate the width of the hopper, e.g., xx40 is a 40-inch hopper, and xx50 is a 50-inch hopper. 40-inch is the most common and is what comes standard on the Smart Seeder.




9940 - Left Hand Unit




9840 - Right Hand Unit

## Basic Topper Identification






## ■ Topper Identification




## **Operator Side View**




## Topper Identification

## Rear View



## **Mandrel Drive Side View**






## ■ MPA Identification

## MPA






**Hose Connection** 

## Conveyor Identification


## **Operator Side View**






## ■ Conveyor Identification

## **Motor Drive Side View**




## Spray Rail Identification

## **Upstream View**



Downstream View



# Chapter 2

## **Key Components**




## **CHAPTER 2: KEY COMPONENTS**

Below is a list of key components that you must familiarize yourself with to gain a better understanding of how the Topper functions.


#### Topper

The Topper applies the topping onto the product. The topping is stored in the hopper and dispensed via the mandrel. The height is adjustable for a wide variety of products.



## ■ Water Spray


The Water Spray valves deposits water onto the product. When the water meets the dough, the dough becomes 'sticky' and adheres the topping to the product. The spray rail height is adjustable to achieve varying results.






## Hopper

The Hopper stores the topping to be dispensed unto the product. The mandrel rotates when activated and dispenses the topping. The Hopper houses the optional agitator and vibrators.



## Clutch


The Clutch engages the mandrel drive to the motor drive system. When triggered by the product sensor, the Clutch will engage the mandrel resulting in the mandrel rotating and dispensing product. When the product sensor is no longer triggered, the clutch will disengage.





## Mandrel Drive Motor


The Mandrel Drive Motor rotates when the unit is enabled. When the Product Sensor is triggered, a clutch is engaged that connects the mandrel to the drive motor. The speed of the drive is in direct relation the amount of topping dispensed.





## Mandrel

The mandrel rotates and applies the topping unto your product. It is specifically designed for your pan width and type of topping used. When product is sensed by the product sensor the mandrel will rotate, dispensing toppings on your product.






### Air Controls

The Topper is equipped with a hopper dump cylinder, an optional agitator, and an optional vibrator. All of these components are controlled by compressed air. Some of the pneumatic lines going to these items contain flow control valves that regulate the amount of air pressure. The flow control valves are adjusted to obtain the desired effect. The flow controls valve is located either in the upper channel, the pneumatic box mounted on the hopper, or the solenoid mount above the mandrel motor.

The Pneumatic Box is located on the backside of the hopper. Remove cover to gain access to the panel.

Inside the Pneumatic Box are the solenoids that control the Deflector Cylinder and Agitator. The output pressure can be controlled by the flow controls located on the solenoid.



The Agitator has two flow control valves located on the solenoid. One is for the extend cycle and the other for the retract cycle. Adjust the flow valves to control the amount of airflow to the Agitator cylinder. The Vibrator has only one flow control valve.




### Air Flow Controls

The Hopper Dump is regulated by the two Air Flow Control valves located on the pneumatic panel. The speed should be set for the desired rate, but to avoid premature wear or damage, they should be adjusted so that the hopper assembly will travel smoothly through a dump cycle, not hitting too hard or too fast in any direction.




Did you know that Flow Control Valves must be installed in a particular direction of air flow travel to function properly? An arrow on the valve will indicate the correct installation.

#### **Flow Control Valve**



### Adjustment

Release the locking dial by turning it anticlockwise. This will allow the adjustment knob to turn freely.




Rotate the adjustment knob until desired flow is achieved.

Clockwise to decrease flow.

Anti-clockwise to

Lock the valve by turning the Locking Dial clockwise until firmly seated.




increase flow.


34 Chapter 2 Burlou

## ■ F.R.L. Description

### F.R.L. Burford® Part # C00404



A pressure gauge indicates the output pressure of the F.R.L. The normal operating pressure is 60 psi.






Pneumatic oil must be kept in the Oil Reservoir at all times. Burford® recommends Parker Pneumatic Oil F442. Check Reservoir weekly.




## Agitator

The agitator is a rake device that reciprocates in the hopper to keep the topping loose during operations. When the mandrel is rotating, the agitator will reciprocate back and forth. This is to prevent any bridging from occurring. Bridging occurs when the toppings in the hopper forms a cavity around the mandrel, preventing product being dispensed.




## Agitator Solenoid

The agitator is controlled by the air cylinder. When product is detected, the agitator will be enabled. The solenoid has two outputs: extend and retract. A timer in the PLC will toggle the solenoid between supplying air to extend or retract when the agitator is enabled.




## **Agitator Flow Controls**

There are two flow valves on the solenoids to control the agitator rake located in the pneumatic box attached to the hopper. One is for extend and the other to retract. The flow valves should be set for smooth operation. Hopper damage may result if agitator action is excessive.



## **Agitator Cylinder**


An air cylinder provides the movement for the agitator. By regulating the flow valves, you control the amount of air pressure going to the cylinder.




#### Upper Channel

Above the hopper is the Upper channel. The Upper Channel's lid can be removed by unlatching the four latches.

The Upper Channel houses the height automation controls and the air solenoids for the Dump and Optional AutoFill / MPA.








#### Water Filter

The Water Filter removes any contaminations from the water source. The filter supplied is rated at 10 microns. Replacement is recommended every 4 weeks but may differ depending upon the quality of the source water supply.




Order your replacement filters from Burford<sup>®</sup>. Call 1-877-Burford (1-877-287-3673) Today. Part Number: C00578



#### Spray Rail


The Spray Rail contains components to ensure a desirable coverage of water on the

product.




#### Spray Tip

The Spray Tip contains the components to ensure a desirable spray. A check valve may be present that is used to close the valve once the pressure reaches a minimum pressure. This prevents dripping and air getting into the hydraulic system. An O Ring gasket seals the spray nozzle and prevents any leaking. A tip is then used to direct the water into a fan with an orifice size and angle specific for your needs. Different orifice sizes and fan angles are available to meet a wide range of applications.




#### ■ Electronic Valve

The Electronic Valve is controlled by the pan sensor and actuates for the set of time that the sensor is triggered. The unit contains two types of electronic valves: spray and split.



#### ■ Product Sensor

The 80mm proximity sensor is to detect product for the water spray / split.



The CMOS Laser sensor is used to trigger the seeder. The sensor transmits a laser that reads when a pan passes through the beam. The sensor notifies the PLC that the laser has been broken. The laser sensitivity can be adjusted. Refer to the instructions at the back of this manual for more information.






#### Operator Control Panel

The control panel contains the Operator Interface, the E-Stop, and the power ON indicator light.



#### HMI

The HMI, (Human Machine Interface), is where the interactions between the unit and software occur. It allows the operator to input parameters that controls the unit. The unit is available with two types of display, the Allen Bradley 600 Plus and the Allen Bradley 700 plus.



Allen Bradley 700 Plus Shown

#### ■ PLC

The PLC (Programmable Logic Controller) is a digital computer used for the automation of the unit. The PLC contains proprietary Burford® software that executes the operations of the unit. This Smart Seeder comes with the upgraded Allen Bradley CompactLogix PLC.



#### Optional Key Components


The following Key Components are items that may be purchased as an upgrade with the Burford<sup>®</sup> Smart Seeder. Your unit may or may not have these items on it. Contact Burford<sup>®</sup> for further information.

Order your Optional Components from Burford®. Call 1-877-Burford (1-877-287-3673) or email <u>Sales@Burford.com</u> today.



#### ■ Split / Spray Rail

The Smart Seeder is available with an optional water splitter. With the optional splitter, the spray and split valves are installed on one automated rail. The splitter is controlled through the Seeder's HMI.




44 Chapter 2



#### ■ Booster Pump (optional)

The Booster Pump contains the necessary components to ensure uniform water pressure during the split sequence. It includes an air regulator, the water filter, pump, and accumulator. All of these components work in unison to deliver consistent water pressure during the split sequence.



It is vital that there are not any water pressure fluctuations during the split sequence. Any variations in water pressure may cause undesirable splits in the final product.



#### ■ Diaphragm Pump (Part of Optional Booster)

The Diaphragm Pump is a positive displacement pump that uses a reciprocating rubber diaphragm and valves on either sides to pump the water into the hydraulic system. The pump is powered by a supply of air and pressure can be controlled by the air regulator feeding the pump. The Output pressure of the pump is a 1:1 ratio of the input air pressure.



The Accumulator is a pressure storage reservoir in which the fluid is held under pressure by an internal bladder filled with compressed gas kept at a constant pressure, also known as a hydro-pneumatic accumulator. The use of an accumulator allows the hydraulic system to respond more quickly to a temporary demand and to smooth out any pulsations that may be present in the system. The internal bladder must be kept at 80% psi of the running pressure. A standard Schrader valve is used to fill the bladder. Compressed air may be used to fill bladder.




Dampener must be charged before use. Verify proper pressure before operations.

Example: If running pressure is 100 psi then the accumulator should be filled to 80 psi.

46 Chapter 2 Burford

#### ■ Pump Air Regulator (Optional Booster Pump)


The Booster Pump Air Regulator controls the pressure of the air operating the diaphragm pump. The air pressure is at a 1:1 ratio of the output water pressure of the pump. The air pressure should be set at 20% above the max operating pressure of the water pressure.





#### Pump Output Water Pressure Regulator (Optional Booster Pump)

The Pump Output Water Pressure Regulator controls the amount of water pressure supplied to the split nozzles. The amount of water pressure from the split tips determine the depth of the split into the product. Variations in dough will require adjustments to be made to the water pressure to receive the desire splits.




48 Chapter 2




#### Conveyor

An optional conveyor is available for your Smart Seeder. The conveyer transfers product through the unit so toppings can be applied. Burford® conveyors feature a drip pan collection system that increases the sanitation of the unit. A split, wet / dry conveyor is also available to keep the topping waste separate from the water drainage.



Standard Conveyor




Split Wet / Dry Conveyor




#### Conveyor Drip Pans

The conveyor system features two drip pans and a catch pan to collect any seed droppings. They are easily removable for cleaning at a different location. The catch pan contains a removable plug that can plumbed into a drainage system if needed.



#### Vibrator

An optional Vibrator is available. The vibrators are located on the rear of the hopper. Activated by the Topper Pan Sensor, the Vibrator will enable with the agitator rake to assure uniform topping application and to prevent bridging.



#### ■ Multi-Purpose Tank

If a MPA was ordered with your unit, then you received a portable tank. Connect the hose from the tank to the Auto Fill System located above the Topper.



#### Auto-Fill Systems


The Auto-Fill Systems are designed to operate with the Burford® Topper and Conveyor System. The operator is able to connect the transfer hose to one of multiple product hoppers. This allows the operator to change to a different topping with minimum effort.

Burford® offers two types of Auto-Fill systems: the MPA (Multi-Purpose Auto-fill), and the HS series. The MPA allows for the transfer of a wide range of toppings. The HS series is compatible with only seeds.

The MPA incorporates a vacuum assembly housed in the unit for product transfer from the tank to the hopper.

The HS series relies on compressed air to create a vacuum utilizing the Venturi effect. The model number after HS indicates the storage capacity of the tank in U.S. pounds. The HS series is available in 300lbs and 500lbs capacity. An optional Dryer is available on the HS series to keep the seed free from moisture.








HS-300 System with Optional Dryer

52 Chapter 2 Burlora

#### ■ Flour Duster

The Flour Duster applies flour to the top of your product. An optional, integrated Flour Duster may be purchased with your Smart Seeder. A stand-alone unit is also available that can be easily installed unto your existing conveyor system. Contact Burford® for more information.





TYPICAL FLOUR DUSTER PLACEMENT INTEGRATED INTO SMART SEEDER

# Chapter 3

## Installation

#### **CHAPTER 3: INSTALLATION**

Your Smart Seeder is fully assembled when it arrives at your facility.

The area chosen should not allow product to stop under the topper.

The area around the Topper installation site should be clear of any obstructions and the topper shall not be installed in such a way as to create a safety hazard, or block a normal passageway. Clearance must conform to all local safety codes.

Installation site should have ample clearance on the operator control side to allow:


- Easy access
- Removal of Mandrel
- Normal maintenance

Consideration must be made for the possibility of product storage near installation site.

#### Installation Outline

- Choose an appropriate location
- Level conveyor with existing conveyor system
- Lock castors
- Connect to utilities


#### Installation on an Existing Conveyor






#### Installation on Existing Conveyor System, continued


Mark air hoses (shown in bottom picture) and disconnect from filter-regulator-lubricator. Separate upper and lower assemblies. This will allow the upper and lower assemblies to be mounted as separate units.



Bolt the four mounting brackets on the sides of the lower cross frame into the corresponding mounting holes. If the exact distance cannot be obtained, then spacers, between the brackets and the conveyor frame should be used.



Carefully route air hoses through lower assembly and reconnect to filter-regulator-lubricator. Align upper assembly and mount to lower assembly.



#### ■ Installation on Existing Conveyor System, continued

- Install conveyor encoder.
- Loosen all of the setscrews securing the desired conveyor shaft to bearings and conveyor belt sprockets.
- Carefully slide shaft until enough clearance is gained to mount encoder.
- Slide encoder onto conveyor shaft and orientate cable connector as desired, then mark and drill a 1/4" hole to secure the anti-rotation flex mount to the conveyor wall.
- Attach communication cable to encoder and conveniently route cable back to seeder enclosure. Consult supplied wiring diagram for wire termination information.



Burford® recommends that a new conveyor shaft be made that is 1-1/2" longer than the existing conveyor shaft. This will allow the encoder to be mounted on the outside of the conveyor frame, greatly simplifying future encoder maintenance.

58 Chapter 3 Burlona

#### ■ Installation on a Burford® Conveyor

#### ■ Remove Topper from Mount

- 1. The unit may be mounted on castors for portability.
- 2. Locate an area that is clear of obstructions. The area chosen should not allow the product to stop, turn, or back-up. A supply of compressed air and power needs to be available at installation site.
- 3. Roll the unit into place.
- 4. Level both the upstream and downstream conveyor with your existing conveyor system. The transfers to and from the Burford® conveyor must be smooth so it will not damage the product during transfer.



Verify top clearance for hopper

#### Castors

The Unit may remain on the Castors for portability if permanent castors are installed, or the unit can be permanently fixed to the floor. When the unit is in operation, the Castors must be locked to prevent movement.



#### **Level Conveyor**

The unit will need to be level during operations to function properly. The support legs are adjustable. Match the height of your existing conveyor system to that of the Burford® conveyor. There are four leg supports with castors. The castors are mounted to a threaded shaft rod. The threaded shaft rod is able to extend and retract approximately 6" of travel within the leg support.

Locate the Castor strut that needs adjustment.



Loosen the bottom jam nut and bring the nut down on the shaft.



Loosen the top jam nut.



#### Level Conveyor, continued

With the nuts loosened, turn the shaft.



You may use your hand on the castor mount to aid in turning the shaft. Loosen the shaft from the frame to raise the unit. Tighten the shaft from the frame to lower the unit.



After the desired height is achieved, secure the shaft by first tightening the top jam nut to the frame then tighten the bottom jam nut to the top jam nut. This will lock the shaft.





#### Permanent Installation

The unit may be permanently fixed to the floor.



Remove all of the temporary castors.



Rotate Thread Shaft to adjust height.



Loosen the jam nuts.




When level with existing conveyor system tighten the jam nuts.

Drill holes matching the bolt pattern of the castor mount and secure with concrete anchors.

#### Product Sensor Setup

The Product sensor for the seeder may need to be properly adjusted before operations of the Smart Seeder.




The bracket that the sensor is mounted on is slotted. This allows the sensor to be rotated for alignment purposes. The sensor transmits a light beam to a reflector. The reflector "reflects" the beam back to the sensor. When a pan passes through the beam, the sensor no longer receives the light beam reflected from the reflector and signals the PLC that a pan is present. It is critical that when a pan is not present the beam is able to reflect back to the sensor.




#### Reflector Product Sensor Setup

A reflector is located on the inside of the conveyor track. The sensor transmits a light beam to a reflector that returns the beam back to the sensor when not blocked.




A passing pan disrupts the beam to the reflector, preventing the sensor from receiving the reflected beam. When the sensor fails to receive the reflected beam, a signal is sent to the PLC indicating that a pan is present.




#### Product Sensor Setup, continued

The image below illustrates the wrong way for sensor setup. The example below would constantly signal the PLC that a pan is present. The sensor must be able to receive back the transmitted beam when a pan is not present. This is accomplished by the reflector.



The height of the hopper will affect the path of the beam. When setting the height of the hopper for a variety be mindful of the product sensor path to the reflector. During setup of the hopper height on a variety, verify that the product sensor is making contact the sensor.

In some situations, a photo-reflective may not be suitable. An optional 80mm proximity sensor is available.



In situations where deflection is difficult, a diffuse reflective sensor may be more user friendly. Detection occurs when the light beam, emitted to the target, is reflected by a target and received.




66 Chapter 3 Burford

#### Diffuse Reflective Sensor Setup

Place the product pan under the sensor and adjust the sensitivity until sensor is reading the pan.






A passing pan disrupts the beam to the reflector, preventing the sensor from receiving the reflected beam. When the sensor fails to receive the reflected beam, a signal is sent to the PLC indicating that a pan is present.

### ■ Diffuse Reflective Sensor Setup, continued

Test the Sensor setting by running the pan used for the recipe, through the seeder. The sensor light will let the operator know the sensor is triggered by the pan. If the sensor light blinks, the sensor needs to be adjusted to read a lower depth. More than likely, the sensor is reading the lip of the pan and not the cavity.





Recommended depth setting for the sensor is 4" below the tracks of the conveyor.

Chapter 3

#### ■ Install the Water Spray

The Burford® Water Spray was shipped to you completely assembled. Partial disassembly is required before the actual mounting. The disassembly of the unit should be done carefully to prevent damage to the unit.

#### ■ Conveyor Requirements:

- 1. The conveyor chosen must utilize pan guides to keep the pans straight when traveling through the unit.
- 2. The conveyor chosen should not allow the product to stop, turn, or back-up.
- 3. Area around the unit installation site should be clear of any obstructions or block a normal passageway. Clearance must conform to all local safety codes.
- 4. Installation site should have ample clearance on operator control side for easy access and normal maintenance.
  - A. Easy access
  - B. Normal maintenance

#### Unpacking Procedure for Installation On Existing Conveyor

Uncrate the unit and set up right onto the packing crate cushions.


Loosen and remove the bolts that hold the lower cross frame to the uprights and remove pan proximity sensor carefully lay aside. You should now have two separate assemblies of the spray and split.




Measure the conveyor width and then bolt the four mounting brackets on the sides of the lower cross frame into the corresponding mounting holes. If the exact distance cannot be obtained, then spacers, between the brackets and the conveyor frame should be used.



With the mounting brackets in place, slide the lower cross frame under the conveyor and raise upward until the top of the cross frame is 3/4" from the bottom of the conveyor frame. Mark and drill the mounting holes into the conveyor frame and mount the unit.




After the lower cross frame is bolted in place, the uprights can now be lowered over the top of the conveyor onto the lower cross frame and bolted on.



70 Chapter 3 Burlow

#### Power Connections

Connect power to the unit. A qualified electrician must make all electrical hook-ups using a suitable service with all safety requirements and compliance to local codes being followed. Refer to electrical diagram at the end of the manual for connection details.




Connect air to the F.R.L. A minimum operating pressure of 60 psi is required.

#### MPA Installation

The MPA is removed during shipment to your facility. It will be necessary to install the MPA when the unit arrives.

Locate the eight MPA mounting bolts supplied with the unit.








### MPA Installation, continued

Remove the upper channel lid by releasing the four latches.






#### ■ MPA Installation, continued

The MPA is heavy. With at least two people, position the MPA on the hopper. Be careful as not to allow the full weight of the MPA rest upon the hopper or damage may occur.



#### MPA Installation, continued

Secure four of the supplied bolts to the front of the unit.





Secure the remaining four bolts the bottom of the mount.



#### MPA Installation, continued

Connect the transfer duct with the bands provided.





Route electrical, air lines along frame, and connect to vacuum receiver.

Stage the auto-fill hopper(s) to allow the supply hose to reach the vacuum receiver, and then connect supply hose and air lines as shown.

76 Chapter 3 Burlon

#### Utility Installation

A qualified electrician must make all electrical hook-ups and the unit must be incorporated into a suitable service with all safety requirements and compliance to local codes.

#### ■ Installation Arrangements

A Burford® factory trained Installation Engineer may be hired for any installation. The arrangement can be made with the Service Manager:

Burford® Corp. Maysville, Oklahoma

Phone: 1-877-BURFORD or 405-867-4467

Fax: 405-867-4219

# Chapter 4

## Operation


78 Chapter 4 Burlow

#### **CHAPTER 4: OPERATION**



The User Interface is the space where interactions between humans and the machine occur. The interaction by the operator allows control of the machine, while the machine simultaneously sends back information that aids the operator's decision-making process. The HMI (Human-Machine Interface) is the primary method of controlling the machine. The HMI on your unit is touch screen. This provides a more versatile user experience with an intuitive design. The HMI on your unit may differ from the one shown on the following pages.


#### **Control Panel**




This is the primary operator interface of the unit. It displays menus error messages and allows access to screens required for setup and operation of the unit.



#### Start Screen




The Start Screen is displayed after initial power up. When safe Pull the E-Stop out.



Press Start to initiate the unit. If the unit is not homed, the unit will home all axis.

#### **Main Screen**




The main screen is the screen that will be available to the operator during production. It contains all of the system controls necessary to operate the unit. In the following section, we will discuss the User Interface.

Some Screen Functions will not be available on the Main Screen. Screen Functions are available depending on model, equipment, and options selected.




#### Main Screen - Message Display Field



DisplayField	Description		
MUST INSERT MANDREL	No mandrel is present or the mandrel inserted is not used for the current recipe.		
MANDREL ## INSERTED	Displays what mandrel # that is inserted into the hopper tube.		

The Message Display Field will alert the operator of conditions that may prevent the unit from going into RUN mode.


#### Main Screen – Current Recipe



The Current Recipe Selected Indicator will display the variety that is currently loaded for the Topper. All adjustments for the Topper have been performed accordingly to the setup parameters entered for that variety and the unit is ready to operate.

84 Chapter 4 Burford

#### Main Screen - Mandrel Indicator




The Smart Seeder features a Mandrel Recognition System (MRS). The system automatically detects the mandrel that is inserted into the unit. This provides the correct setup parameters for the variety chosen and prevents an incorrect mandrel from being inserted inadvertently.

The Mandrel Number Indicator displays the number of the mandrel currently inserted into the unit. If there is not a Mandrel inserted NONE, will be displayed.

If the mandrel number is blinking with a red number, this indicates that the mandrel override option has been activated and the variety selection display may not be using the proper mandrel.

Hopper Indicator	Description		
Mandrel # is inserted	Shows what Mandrel is in the hopper tube.		
Insert Mandrel #	Allows the operator to know which mandrel needs to be inserted for the selected recipe.		


#### Main Screen – Cleanout Hopper



At the end of a production run, or if there is a changeover, the operator may need to empty out the hopper of any toppings. Place the Topper Mode into Standby Mode and press the Cleanout Hopper button to advance to the Hopper Cleanout Screen.

86 Chapter 4 Burford

#### Main Screen – Topper Mode



There are two modes for the unit, Standby and Run.

Touch the button to toggle the status.


Standby Mode: When the unit is in this status, topping and water will NOT be applied.

Run Mode: When the unit is in this status, the unit will detect pans and dispense product.

The Topper must be in RUN mode for the Water Spray or Water Split to be operational.

All settings may be accessed and modified in both "Run" and "Running" modes.

#### Main Screen - Auto Hopper Fill (Optional



Press the "Automatic Hopper Fill" button on the Main Run screen to enable or disable the Auto Hopper-Fill.

The operator can turn the Auto Hopper Fill ON or OFF.

When a changeover of toppings is about to occur, it is usually a good practice to empty as much of the hopper as possible. This will make the changeover process easier as there will not be as much topping to remove from the hopper in preparation of the new toppings.


The operator can minimize the amount of topping in the hopper by turning the Auto Hopper Fill off and running the remaining topping out.

Many variables will determine the amount of product that a hopper will be able to top once the Auto Hopper Fill is deactivated. Over time, a good operator will become very familiar with the time needed to finish out a particular production run and precisely know when to disable the Auto Hopper Fill function.

Refer to page 51 to learn more about the different types of auto-fill systems Burford® has to offer.

Chapter 4

#### Main Screen – Access Mode



The unit contain two user groups with different security privileges. Local is used primarily for operators and provides limited access to the setup features. Supervisory mode allows access to the setup features of the unit.


Pressing the LOCAL MODE button displays a dialog box to enter the supervisor credentials. If the correct credentials are entered, then the unit will switch into SUPERVISOR MODE.

While mode in LOCAL MODE, some options will not be available and the unit setup settings will not be able to be modified.

When in SUPERVISOR MODE, protected screens are still protected and must only be modified by authorized personnel.

Contact Burford for the password. Call 1-877-Burford (1-877-287-3673) or email <a href="mailto:service@Burford.com">Service@Burford.com</a> today.

#### Main Screen - Conveyor (Optional)



A conveyor is used to transfer product through the unit. The Burford<sup>®</sup> conveyor can be controlled either by the Topper or by an external signal. Press the to toggle between selections.


The status indicator is beneath the button and will alternate through the different options as the button is pressed. If "CONVEYOR AUTO" mode is chosen, after a few seconds the display will change to indicate the status of the external signal. "AUTO ON" indicates the external signal is on and the conveyor is running. "AUTO OFF" indicates that the external signal is off.

Conveyor Modes	Description				
OFF	The Conveyor is disabled.				
ON	The Conveyor is enabled.				
AUTO	The conveyor is in remote mode and the conveyor w be dependent on an external signal to operate.				
Auto Status	Description				
AUTO ON	The external signal to operate the conveyor is present. The Conveyor is enabled.				
AUTO OFF	The external signal to operate the conveyor is not present. The Conveyor is disabled.				

90 Chapter 4




#### Main Screen - Jog Mandrel



The Jog Mandrel feature is used to load the Mandrel with toppings prior to the first pan and to verify operation.

Pressing the Mandrel button will rotate the mandrel.

#### Main Screen - Water Spray Purge



The Topper uses a spray of water applied to the dough product to aid in adhering the topping to the dough.


If the Water Spray is enabled for the current variety, then the operator can purge the valves.

Press the Purge Spray button to toggle the Water Spray to purge. The border around the button will turn from red to green during the purge.

Water Spray Purge	Description			
PURGING SPRAY	The Water Spray valves will purge air from the water lines.			
PURGE SPRAY	The Water Spray is in normal operation.			

The Water Spray must be enabled for the current variety in the setup parameters for the water spray modes to be available. If the Water Spray is turned off for the current variety, the operator will not be able to purge.

#### Main Screen - Water Split Purge



The Splitter uses a jet of pressurized water applied to the dough to split the product.


If the Water Split is enabled for the current variety then the operator can enable, disable, or choose Water Split only (this will Split the product but not apply any toppings).

Press the H20 SPLIT button to toggle the Water Split modes.

Water Spray Purge	Description			
PURGING SPLITTER	The Water Split valves will purge air from the water lines.			
PURGE SPLITTER	The Water Split is in normal operation.			

The Water Split must be enabled for the current variety in the setup parameters for the water split modes to be available. If the Water Split is turned off for the current variety, the operator will not be able to purge.


#### ■ Main Screen – Calibrating Motor Positons




#### Calibrating Motors

Press Motor Calibration Screen.


From this screen the operator can choose to calibrate all motors or each motor individually.








#### Main Screen – Clean Screen




Press to advance to the cleaning screen. This will allow the operator to clean the screen without the HMI buttons being active.

Clean Screen



#### Main Screen – Jog Flour Duster



If a Flour Duster is installed and is being controlled by the Smart Seeder control system, then a button labeled will be present on the Main Run screen.


If the Flour Duster is configured for ON mode for the variety that is loaded, then the operator will be able to control the Jog Flour Duster. Pressing the toggle the mode between Jog Flour and Jogging and Jogging .

Pressing the Flour will rotate the duster brush.

Jogging loads the brush with flour prior to the first pan.





#### Main Screen – Language Selection



Pressing the Figure Will translate the HMI text to the selected language.

#### Main Screen - Alarm Messages





The system keeps a log of all fault conditions. The fault message will include the date and time the fault occurred with a brief description of the fault.


The most recent fault will be at the top. Press 🛕 and 🔻 to scroll through the list.

Press to acknowledge the highlighted alarm or to acknowledge all alarms.

Once you acknowledge the alarm, the previous screen will appear.

Chapter 4 98

#### Main Screen - Select Recipe / Edit Setup




To enter EDIT SETUP, you must be logged in with supervisor credentials. Press A dialog box will appear to enter the supervisor credentials. +



The SETUP screens are password protected and must only be modified by authorized personnel.

button advances the display to the Recipe selection screen shown on Page 113, providing a simple method to select a desired recipe.

#### Login Screen







Pressing the button will open a dialog box. Enter the Password. Press enter to advance to Seeder Configuration page.




#### **Cleanout Hopper Screen**





The Cleanout Hopper screen assists the operator in removing any topping remaining in the hopper. The hopper can tilt approximately 90°.

The hopper must be at a safe height before it can tilt. Press raise the hopper to the proper height.



Once the hopper is at the correct height to dump, press and hold the right. The button will change to hopper while its dumping.


Hopper Dump on the


If an optional vibrator is installed on the hopper, then they will automatically vibrate. The vibrator assists in emptying the hopper of its contents.

Press the Hopper Load to raise the hopper back to a safe height.

Press to go back to the Main Run screen.

#### Calibrate Motor Positions Screen





#### IF POWER INTERRUPTION OCCURS, IT IS RECOMMENDED TO CALIBRATE ALL MOTORS!

Press to calibrate the selected motor. Press to return to the Main Screen.

### **Navigation to the Water Calibrate Motor Positions Screen**










#### Seeder Configuration Screen



Seeder Configuration screen allows you to change critical unit functions and override certain features. Use extreme caution when changing any settings.

**MANDREL OVERRIDE** – Bypasses the Mandrel Recognition System.

**DUMP POSITION** – Bypasses the Dump Position location encoder.

**LID INTERLOCK** – Bypasses the Hopper Lid Interlock.

**CONVEYOR ENCODER** – Conveyor setup.

**HOPPER TILT-** Bypasses hopper safeguards.

**AUTOMATION DISABLED** – Disables all automation motors.

**CONVEYOR SPEED** – Display the Conveyor speed in hz.

SHUTDOWN DISPLAY - Turns off the display and pops up the file application screen.

**DIAGNOSTICS** – Advances Operator to the Diagnostics Screen.

**ALARMS** – Advances the Operator the the Alarms Screen.


**HOME** – Takes the Operator back to the Main Screen.







#### Seeder Configuration Screen - Mandrel Override



#### **MANDREL OVERRIDE** – Bypasses the Mandrel Recognition System.

The topper uses sensors to detect which Mandrel is inserted into the unit. In rare circumstances, the sensors may fail. It may then be necessary to override the Mandrel Recognition System to run a variety. If the Mandrel Override function is turned ON, the Mandrel Recognition System will be ignored and whatever Mandrel number is in the box will be used.

Press the Mandrel Override function.

When this option is active, the mandrel number shown on the Main Run screen will be "blinking red" to indicate that the override option is active.

See next Pages for more information of the Mandrel Recognition System.

#### Mandrel

The Burford® Smart Seeder features a Mandrel Recognition System (MRS). The MRS automatically detects the inserted mandrel and only load varieties associated to that mandrel. This feature eliminates the operator from inadvertently loading the incorrect mandrel for a particular variety.

The system utilizes metal rings appropriately spaced at the end of each mandrel. Each mandrel has a unique sequence of rings. Proximity sensors located at the end of the mandrel tube detects if metal rings are present. Using a binary system, the PLC is able to detect which mandrel is inserted.

#### **Binary System**

Most of us are familiar with the decimal numbering system. That is "0" through "9". In the decimal system, the rightest number is the One's column. The next column to the left is the Ten's then the Hundred's and so forth.


Binary is a base 2 numbering system. The only digits, or bits, are "1" and "0". The rightest column is the 1's column. The next column to the left is the 2's then the 4's, 8's and so forth, doubling each time.

To convert a Binary number to decimal you add all of 1's in their respective column together. For example, Binary 0100 shows that there is a "1" in the 4's column. 0100 is the decimal equivalent of 4. Binary 0101 shows that there is "1" in the 4's column and a "1" in the 1's column. We add 4 + 1 to get the decimal equivalent of 5. Binary 0111 shows that there is "1" in the 4's column, a "1" in the 2's column, and a "1" in the 1's column. We add 4+2+1 to get the decimal equivalent of 7. The table below lists the Binary numbers for 0 through 15.

Binary Number							
8	4	2	1	Decimal			
0	0	0	0	0			
0	0	0	1	1			
0	0	1	0	2			
0	0	1	1				
0	1	0	0	4			
0	1	0	1	5			
0	1	1	0	6			
0	1	1	1	7			
1	0	0	0	8			
1	0	0	1	9			
1	0	1	0	10			
1	0	1	1	11			
1	1	0	0	12			
1	1	0	1	13			
1	1	1	0	14			
1	1	1	1	15			


#### ■ Mandrel Recognition System, continued

When the mandrel is inserted, certain proximity sensors will be energized dependent if a metal ring is present at the sensor's location. In the illustration below, the proximity sensors would send the binary number 1101 to the PLC. The PLC detecting that mandrel 13 has been inserted will make available to the operator the varieties that are configured for that mandrel only.





#### Seeder Configuration Screen - Hopper Overrides



The hopper has many sensors. These sensors detect the angle, height, and lid position of the hopper. In rare circumstances, the sensors may fail. It may then be necessary to override the hopper position sensors to run a variety.



Press the toggle switch ON or OFF to enable / disable the Hopper Lid Interlock override. With this enabled, you may run the unit regardless of the hopper lid position.



Press the toggle switch ON or OFF to enable / disable the Dump Position override. With this enabled, you may dump the hopper regardless of the hopper height.




Press the toggle switch ON or OFF to enable / disable the Hopper Tilt override. With this enabled, you may run the hopper regardless of the hopper angle.

If the hopper is dumped too low, damage may occur to the unit. If the Hopper is angled too low, the application of toppings may be undesirable.

The unit will continue to run even if the hopper lid is open. Mechanical movement in the hopper can cause serious bodily injury.

#### Seeder Configuration Screen - Conveyor Encoder



The CONVEYOR ENCODER is used to calculate the speed of the conveyor. For the Smart Seeder to function properly, we must know the distance that the conveyor is traveling at any time. This is accomplished with an encoder linked to the conveyor shaft. We need to know distance of travel per encoder count.

Using the topper's pan sensor and the known length of a target, a pan, we can calculate a scaling factor that can be used to ensure that 100 encoder counts equal one inch of conveyor travel.


SCALING

- 1. Turn ON the conveyor (page 89).
- 2. Verify that the speed is set to the speed that the varieties will be running in production. Locate a pan and measure the length.
- 3. Enter the length in a decimal format, for example, 22 1/2" would be 22.5.
- 4. Press calculate.
- 5. Release the pan upstream of the topper and allow it to travel through the unit, downstream of the topper.
- 6. The CURRENT SCALING FACTOR value will update.

If a Burford® conveyor shipped with the unit, then the scaling was set from the factory. Scaling will need to be performed at installation if the topper is mounted on customer's conveyor. WHEN SCALING IS PERFORMED, EACH VARIETY WILL NEED TO BE RE-CONFIGURED.




#### Seeder Configuration Screen - Automation Overrides



The will disable or enable all automation motors. You are can enable or disable each of the automated controls: Hopper Lift, Pan Guides, and the Spray / Split Lift.


# Seeder Configuration Screen - Automation Overrides



The allows the operator to adjust and set the speed of the conveyor. The speed is measured in Hz. Use the keypad to set to the speed that the varieties will be running in production.




Seeder Configuration Screen - Shutdown Display



The allows the operator to shut down the display.

## Seeder Configuration Screen - Diagnostics





The Diagnostic Screen allows the operator to check that all sensors are communication with the PLC.

Green – indicated that the sensor is active.

Dark Green indicates that the particular sensor is energized.

Red indicates that the particular sensor is not energized.

Spare will have no color in the color box.


Advances to the previous or next screen.

Takes the operator back to the Seeder Configuration Screen.





# Seeder Configuration Screen - Advance Buttons




The allows the operator to advance to the Alarm Screen.


The allows the operator to advance to the Edit Recipe Screen.

The allows the operator to advance to the Main Screen.

### Select Recipe Screen




Select the recipe that you want to run. The border will turn GREEN.



Verify what mandrel is used for the highlighted recipe in the message box and press .


If the selected recipe requires a different mandrel than what is currently being used, then the hopper will automatically move to the dump position.

# **Navigation to the Recipe Select Screen**





### Recipe Edit Screen Overview



The Recipe Edit screen allows the user to make changes to, create, copy and delete recipes. The boxes at the top of the screen displays the saved recipes. An indicator at the lower center of the screen displays the current recipe. Using the PREVIOUS PAGE and NEXT PAGE allows the user to advance to other saved recipes. The RECIPE COPY button will make a copy of the highlighted recipe. To delete a recipe, highlight the recipe and press the RECIPE DELETE button and then press accept.

The ADD RECIPE button allows the operator to name a new recipe. After the recipe is named, the operator will push the RECIPE SETUP button to advance to the recipe configuration page.


Each recipe will be displayed in the boxes at the top of the screen. If the operator selects a recipe that is not available with the current Mandrel inserted, a dialog box will appear informing the operator of the correct Mandrel to be inserted for the recipe selected.

Once the recipe is highlighted, the operator will push the ACCEPT button. The unit will now move all of the automated adjustments to the position that was configured for that particular recipe.

Press DECLINE to return to the Main Run screen.



### Recipe Edit Screen Setup



Select the recipe that you want to edit. The border will turn GREEN.


Use the editing buttons on the bottom of the screen to make changes.

The button will appear only after the operator has highlighted a recipe and pressed an editing button. Pressing the Accept button will allow the edit to take place.



116

### Recipe Edit Screen Setup



Select the recipe that you want to edit. The border will turn GREEN.



This button will copy the highlighted recipe as a new recipe. (example: will become will become



This button will delete the highlighted recipe.



This button will add a new recipe named *new variety* to the recipe list. The name can be changed on the Setup Recipe Screen.

(example: \_\_\_\_\_\_\_).


Edits will not go into effect until



is pressed.



### Recipe Edit Screen Setup



Select the recipe that you want to edit. The border will turn GREEN.



This button allows the operator to setup the highlighted recipe by advancing to the Recipe Setup screen.



This button will accept the edit button selected and will advance to the next action.



This button takes the operator to the Main Screen when pushed when no recipes are selected. If a recipe is selected and the edit button is pushed it will allow the operator to decline the edit.


Edits will not go into effect until



is pressed.



# Recipe Setup Screen Overview



Select a recipe. Press screen.

and then




to advance to the Configure Recipe

The Setup screen provides access to all of the configuration options for the recipe.

Press to go back to the Recipe Edit Screen.



#### Recipe Setup Screen



The Recipe Setup screen is the first screen that you will encounter in the setup menus. It identifies the variety that will be modified. Verify it is the variety to modify. Changes made will only modify the variety loaded.



Pressing the box with the variety name will display a keyboard to modify the name.




Indicates which mandrel will be used for the recipe.



Allows operator to turn mandrel OFF, rotate Forward or Reverse.





The Recipe Setup screen is the first screen that you will encounter in the setup menus. It identifies the variety that will be modified. Verify it is the variety to modify. Changes made will only modify the variety loaded.


Allows the operator to control the amount of topping by adjusting the speed of the mandrel, (Range 0 - 100).

Toggle the Deflector bar position between OFF and ON.

Allows operator to adjust the speed of the agitator, (Range 0 - 100).

Advances to the pan dimension screen for bun pans.

Toggles between Bread Pan and Bun Pan. Select this prior to Pan Setup.



The Recipe Setup screen is the first screen that you will encounter in the setup menus. It identifies the variety that will be modified. Verify it is the variety to modify. Changes made will only modify the variety loaded.


Advances to the Water Spray setup screen.

Advances to the Automation Positioning setup screen.


Toggles the Hopper Fill OFF and ON.


Allows the operator to set the Hopper Fill time, (Range 5 - 60).





The Recipe Setup screen is the first screen that you will encounter in the setup menus. It identifies the variety that will be modified. Verify it is the variety to modify. Changes made will only modify the variety loaded.





The Recipe Setup screen is the first screen that you will encounter in the setup menus. It identifies the variety that will be modified. Verify it is the variety to modify. Changes made will only modify the variety loaded.



Advances to the Seeder Configuration screen.




Advances to the Recipe Select screen.



Advances to the Main screen.

124 Chapter 4 Burlet

### **Recipe Setup Screen Application and Appearance Controls**



The Application and Appearance Controls are used to modify the Mandrel speed, direction, and deflector bar position.

Deflector - The deflector bar is available to provide optimal product coverage. With the deflector bar in the active position, topping is dispensed by the mandrel onto the deflector bar, which allows large toppings or toppings that clump together to be more evenly applied. On smaller toppings like sesame, the deflector bar should be retracted.

Topping Speed - Is used to control the amount of toppings applied to the product. The number value is a percentage of the maximum Mandrel Speed from 0 to 99. Press the "UP" or "DN" button to increase or decrease the rotation speed of the Mandrel.

Mandrel – The button indicates the current mode selected. Press the Button to toggle between FORWARD, REVERSE, and OFF. "Forward" and "Reverse" refer to the direction that the Mandrel is turning. Changing the direction of rotation on the Mandrel may improve the topping's application and appearance. This may be particularly beneficial on thin and large diameter toppings. Press the button until the indicator is displaying OFF, this will disable the toppings for this variety.

# *P*--*V*

#### Allen-Bradley PanelVeiw Plus 700 Mandrel Number Variety Name Mandrel Hoagie OFF Deflector Bar OFF Pan Bread Setup Pan 45 Hopper Fill Time Water Hopper Fill OFF Automation Positioning Spray MIPS Code Water Flour Split Duster 679846 Verification Alarm ON

### Recipe Setup Screen - Agitator Speed


The Agitator Speed enables or disables and sets the speed of the Agitator for this variety.

The agitator is a rake device that reciprocates in the hopper to keep the topping loose during operations. When the mandrel is rotating the agitator will reciprocate back and forth. This is to prevent any bridging from occurring. Bridging is when the toppings in the hopper form a cavity around the mandrel preventing product from being dispensed.

You are able to control the rate at which the Agitator oscillates by adjusting speed of the agitator by pressing and inserting a numeric value in the keypad ranging from 1 – 100%.


## Pan Types

Your Smart Seeder has the ability to accommodate different types of pans: Bun and bread the hard way, or bun and bread the easy way. Hard way and easy way refers to the orientation of the pan through the conveyor system. We will discuss how to setup each variation of pan.




**Bread Pan Easy Way** 

**Bun Pan Easy Way** 



**Bread Pan Hard Way** 




**Bun Pan Hard Way** 

## Pan Setup Screen (Bread)



YOU MUST BE LOGGED IN WITH SUPERVISOR PERMISSIONS
TO ENTER SETUP. REFER TO PAGE 99

YOU MUST HAVE THE BREAD PAN BUTTON PRESSED IN ORDER TO ADVANCE TO THE BREAD PAN SETUP SCREEN.



**Bun Pan Setup Screen** 

The Burford® Smart Seeder applies topping precisely on the dough with the ability to skip the area between rows. This significantly reduces topping consumption.

Entering your pan information for the variety allows the software to accurately calculate when to engage the topping output.


The Pan Dimension screen allows the user enter dimensions of the pan for the software to perform the computation necessary to provide topping savings.

The next few pages will discuss how to setup each pan.



# Leading Edge


Be mindful of the leading edge of the pan. The Pan Setup is completely reliant on the proper leading edge when entering pan dimensions.




# Pan Dimension Setup

If setting up a bun pan the easy or hard way turn to page 130.






If setting up a bread pan the easy way turn to page 136.



If setting up a bread pan the hard way turn to page 142.






### ■ Pan Dimension – Bun Pan Setup 1 of 5

We will fine tune the pan dimensions for the bun pan to maximize coverage and minimize the use of toppings.


The first objective is to place a small line of toppings at the center of the first row.



#### MAKE THE FOLLOWING ADJUSTMENTS

Set the NUMBER OF CUPS to 1


Set DIM A to 3.75 Set DIM B to 2.00 Set DIM C to 5.25




### ■ Pan Dimension – Bun Pan Setup 2 of 5


Begin by running pans of product through the system. It may take several pans to setup up a variety. There should be dough in the pan to achieve the best results.

Adjust Dim A until the row of toppings are exactly at the center of the first row. Adjust in increments of .25. To move the row away from the leading edge increase DIM A. To move the row closer to the leading edge decrease DIM A. When close to the center, adjusting with smaller increments may be necessary.


















# Pan Dimension – Bun Pan Setup 3 of 5

The second objective is to place a small line of toppings at the center of row 1 and row 2.


Change the NUMBER OF ROWS to 2.

Adjust Dim C until row "2" toppings are exactly at the center of the second row. Adjust in increments of .25. To move the row away from the leading edge increase DIM C. To move the row closer to the leading edge decrease DIM C. When close to the center of the second row, adjusting with smaller increments may be necessary.










**Increase DIM C** 






Move to next step




### Pan Dimension – Bun Pan Setup 4 of 5


Now we will increase the width of the cup size with DIM B until the topping is covering the entire cup.

Adjust Dim B until the toppings just barely cover the entire product. Adjust in increments of .10. To widen the width of the topping in the cup increase DIM B. To narrow the width of the topping in the cup, decrease DIM B.


















### ■ Pan Dimension – Bun Pan Setup 5 of 5

This setup method should provide you with close to ideal settings; however, you may need to fine-tune some of the pan dimension values. When fine-tuning, do so when the product is running. Make small incremental changes. If set properly it should be evident by the starting and stopping of the mandrel between the rows of the cups.

Press when satisfied with the results.




From the Setup screen press to go to the Main Run screen. Press to go to the Recipe Edit screen. You may find it necessary to re-adjust some of the Variety Topper Options.

### Pan Setup Screen (Bread)



YOU MUST BE LOGGED IN WITH SUPERVISOR PERMISSIONS TO ENTER SETUP. REFER TO PAGE 99

YOU MUST HAVE THE BREAD PAN BUTTON PRESSED IN ORDER TO ADVANCE TO THE BREAD PAN SETUP SCREEN.



Bread Pan Setup Screen

The Burford® Smart Seeder applies topping precisely on the dough with the ability to skip the area between rows. This significantly reduces topping consumption.

Entering your pan information for the variety allows the software to accurately calculate when to engage the topping output.

The Pan Dimension screen allows the user to enter dimensions of the pan for the software to perform the computations necessary to provide topping savings.


The Topper can be used with Bun Pans or Bread Pans.

In next few pages we will go over the proper setup procedures of setting up your pan dimensions.

This step is critical to maximize the cost saving benefits of your Burford® Smart Seeder.

# ■ Bread Pan Easy Way Setup


The following setup instructions will be for a bread pan going the EASY WAY.



### ■ Pan Dimension – Bread Pan Easy Way Setup 1 of 5


We will fine tune the pan dimensions for the bread pan, easy way, to maximize coverage and minimize use of toppings.

The first objective is to place a small line of toppings at the center of the first row.



#### MAKE THE FOLLOWING ADJUSTMENTS


Set the NUMBER OF CUPS to 1 Set DIM A to 2.25 Set DIM B to 4.50 Set DIM C to 6.50




### Pan Dimension – Bread Pan Easy Way Setup 2 of 5

Begin by running pans of product through the system. It may take several pans to setup up a variety. There should be dough in the pan to achieve the best results.

Adjust Dim A until the row of toppings are exactly at the center of the first row. Adjust in increments of .25. To move the row away from the leading edge increase DIM A. To move the row closer to the leading edge decrease DIM A. When close to the center, adjusting with smaller increments may be necessary.







### ■ Pan Dimension – Bread Pan Easy Way Setup 3 of 5

The second objective is to place a small line of toppings at the center of row 1 and row 2.

Change the NUMBER OF ROWS to 2.

Adjust Dim C until row the toppings are exactly at the center of the second row. Adjust in increments of .25. To move the row away from the leading edge increase DIM C. To move the row closer to the leading edge decrease DIM C. When close to the center of the second row, adjusting with smaller increments may be necessary.









# ■ Pan Dimension – Bread Pan Easy Way Setup 4 of 5

Change the NUMBER OF ROWS to the number of rows in your pan.

Now we will increase the width of the cup size with DIM B until the topping is covering the entire cup.






### ■ Pan Dimension – Bread Pan Easy Way Setup 5 of 5

This setup method should provide you with close to ideal settings; however, you may need to fine-tune some of the pan dimension values. When fine-tuning, do so when the product is running. Make small incremental changes. If set properly it should be evident by the stopping of the mandrel between the rows of the cups.

Press the RECIPE icon when satisfied with the results.






From the Setup screen press HOME to go to the Main Run screen. Press Continue to go to the Main Setup screen. You may find it necessary to re-adjust some of the Variety Topper Options.

# ■ Bread Pan Hard Way Setup


The following setup instructions will be for a bread pan going the Hard Way.



# ■ Pan Dimension – Bread Pan Hard Way Setup 1 of 4


We will fine tune the pan dimensions for the bread pan, hard way, to maximize coverage and minimize use of toppings.

The first objective is to place a small line of toppings at the center of the first row.



#### MAKE THE FOLLOWING ADJUSTMENTS

Set DIM A to 5.25 Set DIM B to 2.00







# ■ Pan Dimension – Bread Pan Hard Way Setup 2 of 4


Begin by running pans of product through the system. It may take several pans to setup up a variety. There should be dough in the pan to achieve the best results.

Adjust Dim A until the row of toppings are exactly at the center of the row. Adjust in increments of .25. To move the row away from the leading edge increase DIM A. To move the row closer to the leading edge decrease DIM A. When close to the center, adjusting with smaller increments may be necessary.























#### Pan Dimension – Bread Pan Hard Way Setup 3 of 4


The second objective is to cover the entire product.

Adjust Dim B until the toppings are covering the entire product. Adjust in increments of .25. To increase the coverage, increase DIM B. To decrease the coverage, decrease DIM B.


















#### Pan Dimension – Bread Pan Hard Way Setup 4 of 4


This setup method should provide you with close to ideal settings; however, you may need to fine-tune some of the pan dimension values. When fine-tuning, do so when the product is running. Make small incremental changes. If set properly it should be evident by the starting and stopping of the mandrel between the rows of the cups.

Press when satisfied with the results.



From the Setup screen press to go to the Main Run screen. Press to go to the Recipe Edit screen. You may find it necessary to re-adjust some of the Variety Topper Options, go to page 119 for more instructions.

#### Water Spray



The Topper uses a spray of water applied to the dough product to aid in adhering the topping to the dough.


The spray rail consists of water spray valves that can be turned ON and OFF dependent on variety needs. The standard unit is equipped with six valves but additional valves may have been purchased when your unit was ordered.

# **Navigation to the Water Spray Setup Screen**





#### Water Spray Setup Screen Overview



Valve Control – Allows individual control of spray valves.

Spray Modes – Press to toggle between Enabled and Disabled modes.

Delay On and Delay OFF – Allows precise control of water spray actuation.


Purge – Activates all enabled water spray valves.

PWM Duty and Speed – If equipped with the optional PWM spray valves, enter setup parameters.

Return – Takes you back to the Recipe Setup screen.

Any changes made on any setup screen will take effect to the current variety selected and will be automatically saved to the current mandrel in the Topper. Verify that you are on the correct variety prior to making any changes.

#### Water Spray Setup - Valve Control



**Spray Valve Control** – The standard unit is equipped with six valves. Additional valves may have been purchased when your unit was ordered. Eight valves are the most common configuration.

If the unit is equipped with six Spray Valves, then spray valve 1-3 and 10-12 will not be operational. Spray valves 4 through 9 will control the six valves.

The width of the pan, the number of cups, and the amount of water spray desired, will determine the number of water spray valves that will need to be enabled. Press the button below each respective valve number to toggle the state of the valve. Green indicates that the valve is enabled. Red indicates that the valve is disabled.

The button will change from




O Valve 2

when the valve is active.

Any changes made on any setup screen will take effect to the current variety selected and will be automatically saved to the current mandrel in the Topper. Verify that you are on the correct variety prior to making any changes.

150 Chapter 4 Burlon

#### Water Spray Setup - Purge



**Purge** – When is pressed, all enabled valves will turn on.

Purge is primarily used to remove any air from the Water Spray valves. Any air in the system will cause adverse effects.

In proper operation the valves should turn on and off immediately without any dripping. The spray should be fanned evenly. If you experience undesirable results, then the valves may need to be purged. Press and hold the purge button for 10 seconds. Release the button shortly and repeat. Repeat until desirable results.

You may also use Purge to verify your valve configuration and placement with the current variety.

Press and release the Purge button to momentarily turn on the enabled valves.


Press Press



to go back to the Main Setup screen.

If after several minutes of purging, you are unable to obtain desirable results check for any air leaks in the water lines. Verify that the nozzle tips are seated and properly tightened.

#### Water Spray Setup Trigger Times



Water Spray Trigger Times – The pan sensor for the water spray rail is located upstream from the water spray valves. It may be necessary to delay the start and stop of the water spray valves to ensure complete coverage of the product.

Delay On – The Delay On is the time from when the pan first makes the pan sensor and the spray valves turn on. When the pan sensor is made, the PLC will wait the value of DELAY ON before turning the water spray valves on. The value of DELAY ON should have the water spray valves turn on when product is directly beneath the valves. The goal is to prevent overspray and wasted water.

#### **Delay On**

Press the box to modify the value.

Delay OFF – The Delay Off is the time from when the pan is no longer making the pan sensor and the spray valves turn off. When the pan sensor is no longer made, the PLC will wait the value of DELAY OFF before turning the water spray valves off. The value of DELAY OFF should have the water spray valves turn off when product is no longer directly beneath the valves. The goal is to prevent overspray and wasted water.

#### **Delay Off**


Press the box to modify the value.

Press to return to the Recipe select screen.

Any changes made on any setup screen will take effect to the current variety selected and will be automatically saved to the current mandrel in the Topper. Verify that you are on the correct variety prior to making any changes.

152 Chapter 4 Burlow

#### Water Spray Setup – Optional PWM



**PWM Setup** – An optional PWM spray system is available for your water spray unit.

PWM (Pulse Width Modulation) Flow Control involves switching spray nozzles on and off very quickly in order to control the flow rate. This cycling takes place so quickly that the flow often appears to be constant. PWM Flow Control requires the use of electrically actuated nozzles and a spray controller.

#### **PWM Speed**


Touch the box to select between the available frequencies of the spray valves. The frequency determines the number of cycles per second.

#### **PWM Duty**

Touch the box to select between the available durations of the spray valves. The duty determines the time that the spray valve is on during each cycle.


Any changes made on any setup screen will take effect to the current variety selected and will be automatically saved to the current mandrel in the Topper. Verify that you are on the correct variety prior to making any changes.

#### Water Split




The Topper features an optional Splitter that is available to enhance your product.

The Split rail consists of water split valves that can be turned ON and OFF dependent on the variety needs. The standard Splitter is equipped with six valves but additional valves may have been purchased when your unit was ordered.





#### Water Split Setup Screen Overview



Valve Control – Allows individual control of spray valves.

Spray Modes – Press to toggle between Enabled and Disabled modes.

Delay On and Delay OFF – Allows precise control of water spray actuation.


Purge – Activates all enabled water spray valves.

Return – Takes you back to the Recipe Setup screen.

Any changes made on any setup screen will take effect to the current variety selected and will be automatically saved to the current mandrel in the Topper. Verify that you are on the correct variety prior to making any changes.



#### Water Split Setup - Valve Control



**Split Valve Control** – The standard unit is equipped with six valves. Additional valves may have been purchased when your unit was ordered. Eight valves are the most common configuration.

If the unit is equipped with six Split Valves, then spray valve 1-3 and 10-12 will not be operational. Spray valves 4 through 9 will control the six valves.

The number of cups will determine the number of water split valves that are needed. Press the oval button below each respective valve number to toggle the state of the valve. Green indicates that the valve is enabled. Red indicates that the valve is disabled.

The button will change from Valve 2 to




when the valve is active.

Any changes made on any setup screen will take effect to the current variety selected and will be automatically saved to the current mandrel in the Topper. Verify that you are on the correct variety prior to making any changes.



#### Water Split Setup - Purge



is pressed, all enabled valves will turn on for 45 seconds. Purge – When

Purge is primarily used to remove any air from the Water Split valves. Any air in the system will cause adverse effects.

In proper operation the valves should turn on and off immediately without any dripping. The split should be very fine with a tight jet of water. If you experience undesirable results, then the valves may need to be purged. Press and hold the purge button for 10 seconds. Release the button shortly and repeat. Repeat until desirable results.

You may also use Purge to verify your valve configuration and placement.


Press and release the Purge button shortly to turn on the enabled valves.



Press to go back to the Main Setup screen.

If after several minutes of purging, you are unable to obtain desirable results check for any air leaks in the water lines. Verify that the nozzle tips are seated and tighten properly.

#### Water Split Setup - Trigger Times



Water Spray Trigger Times – The pan sensor for the water spray rail is located upstream from the water spray valves. It may be necessary to delay the start and stop of the water spray valves to ensure complete coverage of the product.

Delay On – The Delay On is the time from when the pan first makes the pan sensor and the spray valves turn on. When the pan sensor is made, the PLC will wait the value of DELAY ON before turning the water spray valves on. The value of DELAY ON should have the water spray valves turn on when product is directly beneath the valves. The goal is to prevent overspray and wasted water.

Press the DELAY ON box to modify the value.

Delay OFF – The Delay Off is the time from when the pan is no longer making the pan sensor and the spray valves turn off. When the pan sensor is no longer made, the PLC will wait the value of DELAY OFF before turning the water spray valves off. The value of DELAY OFF should have the water spray valves turn off when product is no longer directly beneath the valves. The goal is to prevent overspray and wasted water.

Press the DELAY OFF box to modify the value.


Press to return to the Recipe select screen.

For best results, the Trigger Times should be adjusted with the pan and conveyor speed that will be used for the variety in production.


158 Chapter 4 Burlow

#### **Automation Setup Screen**






The Automation Setup Screen allows the operator to move and set the Hopper, Pan Guides, Spray Rail and Split Rail to a location specific to the recipe that is currently running.



The Automation Setup Screen will only allow the operator to set the location if you are setting up a recipe that is not currently running.

#### Automation Setup Screen - Hopper



The height of the hopper may affect the application of your topping. The adjustable height hopper will return to the exact height every time the variey is selected. Normally 2 to 3 inches above the product is acceptable for most toppings.

Press the MOVE HOPPER button and it will change to HOPPER MOVING.

When setting the height of the hopper, it is preferably to do so with the product in production. This way you can immediately see the results while adjusting.

The numeric value in the center displays the number of encoder counts from the home position. This is for reference only.

Press the MOVE UP or MOVE DOWN buttons to move the hopper in the respective direction until the hopper is in the desired position for the variety selected.

Once the hopper height is set, press the SAVE button to save the changes.


Move to the next automation or press



to go back to the Recipe Setup Screen.

160 Chapter 4 Burlow

#### **Automation Setup Screen – Pan Guide**



Determine the width of the Pan Guides for this variety. Place the pan for this variety on the conveyor. Close the guides until there is ½" gap from the sides of the pan to the guides.

Press the Pan Guide and it will turn to Pan Guide .


When setting the width of the pan guide it is preferably to do so with the product in production. This way you can immediately see the results while adjusting.

The numeric value in the center displays the number of encoder counts from the home position. This is for reference only.


Press the or button to move the pan guide in the respective direction until the hopper is in the desired position for the variety selected.

Once the pan guide is set, press the button to save the changes.

Move to the next automation or press Screen.



#### Automation Setup Screen – Spray



Determine the height of the Spray Rail for this variety. Place the pan for this variety on the conveyor. Lower the rail to a positon that allows complete coverage of water to the product.


Press the Nove and it will change to Spray.

When setting the height of the spray rail it is preferably to do so with the product in production. This way you can immediately see the results while adjusting.

The numeric value in the center displays the number of encoder counts from the home position. This is for reference only.

Press the box or button to move the rail in the respective direction until the hopper is in the desired position for the variety selected.

Once the spray rail height is set, press the




Move to the next automation or press Screen.



to go back to the Recipe Setup

#### **Automation Setup Screen – Splitter**



Determine the height of the Splitter Lift for this variety. The height of the Splitter Rail and the water pressure will affect the split of the product.

Press the Splitter and it will change to

When setting the height of the split rail it is preferably to do so with the product in production. This way you can immediately see the results while adjusting.

The numeric value in the center displays the number of encoder counts from the home position. This value is for reference only.

Press the Down or button to move the rail in the respective direction until the hopper is in the desired position for the variety selected.


Once the split rail height is set, press the button to save the changes.

Move to the next automation or press Screen.



to go back to the Recipe Setup

Hopper - Fill (Optional)



The Hopper-Fill allows the Seeder to be connected to a larger external hopper that will automaticlay refill the Seeder when it becomes low of toppings.

The Hopper is designed to keep product in the hopper during production runs. An external large capacity tank is used to transfer product from the tank to the hopper located on the seeder.


## **Navigation to the Water Spray Setup Screen**



164 Chapter 4




#### **Hopper - Fill Time**



The Hopper-Fill allows the Seeder to be connected to a larger external hopper that will automaticlay refill the Seeder when it becomes low of toppings.

The Hopper is designed to keep product in the hopper during production runs. An external large capacity tank is used to transfer product from the tank to the hopper located on the seeder.

The Hopper Fill Time is the amount of time that the Auto-Fill will transfer product from the tank to the hopper once a low-level trigger is received from the Seeder. The system will transfer product for this time regardless of product level in the hopper. This value is in seconds.




**Fill Time Setting** 

Range: 5 – 60 seconds

**Recommended Setting: 20 seconds** 

#### Hopper Fill Setup



Press the (Hopper Fill OFF) to select if the Hopper-fill function is available for this variety. The button will change to when available.


If the Hopper Fill is ON for this variety, then the operator will be able to control it from on the Main Run screen.

The function allows the operator to set the time that the Auto fill will remain on ranging from 5-60 seconds. This is the time that he MPA or Topper Hopper will vacuum product from the product source. In most cases, the source will be mobile.

If is selected, then the next time the variety is loaded the Auto-Fill function will be automatically enabled.



#### Seed Verification Alarm (Optional)



The Low Level Alarms can alert the operator if either the Seeder's hopper or the AutoFil's Hopper become low. The alarm should provide the operator with enough time to refill the respected hopper.

Press the




toggle switch to enable or disable the Low Level Alarms.

# **Navigation to the Water Spray Setup Screen**



#### Flour Duster (Optional)



The Smart Seeder is available with an optional Flour Duster. The Flour Duster applies a flour dusting to your product. The Flour Duster can be used in unison with the Topper.

The Flour Duster may be incorporated into the Smart Seeder controls system or can be a standalone unit. If you purchased a standalone unit, please refer to the manual that came with your unit.


The following information is for the Flour Duster that is incorporated into the Smart Seeder control systems.

# **Navigation to the Water Spray Setup Screen**





#### Flour Duster Setup Screen



The Burford® Flour Duster is designed to provide a uniform application of flour dusting automatically to your product without interruption. A variable speed controlled motor allows easy adjustment of the amount of applied to your product.

**Percent Duster Speed** – Controls the amount of flour applied to product.


Flour Duster Trigger Time – Allows precise control of the dispensed flour.

**Mode Select** – Flour Duster operating mode.

**Return** – Takes you back to the Recipe Setup screen.

#### Flour Duster – Speed Control

Speed




The Speed Input is used to control the amount of flour applied to the product. The number value is a percentage of the maximum applicator speed from 0 to 99. Use the keypad to set a numeric value speed percentage that controls the rotation of the flour applicator.

An increase in the speed will result in more flour being dispensed in relation to the speed of the conveyor. A decrease in the speed will result in less flour being dispensed in relation to the speed of the conveyor.

170 Chapter 4 Burford

#### Flour Duster – Delay Times



Flour Duster Trigger Times – The pan sensor for the Flour Duster is located upstream from the applicator dispense. It may be necessary to delay the start and stop of the flour applicator to ensure complete coverage of the product without any waste.

DELAY ON - The time from when the pan first makes the product sensor and the flour applicator turns on. When the product sensor is made, the PLC will wait the value of DELAY ON before turning the flour applicator on. The value of DELAY ON should turn the flour applicator on when the product is directly beneath the applicator dispense. The goal is to prevent wasted and ensure complete product coverage.

Press the DELAY ON box to modify the value.

DELAY OFF - The time from when the pan is no longer making the product sensor and the flour applicator turns off. When the product sensor is no longer being made, the PLC will wait the value of DELAY OFF before turning the flour applicator off. The value of DELAY OFF should turn off the flour applicator when product is no longer directly beneath the applicator dispense. The goal is to prevent waste and ensure complete product coverage.

Press the DELAY OFF box to modify the value.

# Chapter 5

# Creating a New Variety

#### CHAPTER 5: CREATING A NEW VARIETY

#### ■ New Recipe - Introduction

The Burford® Smart Seeder uses varieties to store the setup information from the user. The system is capable of storing up to 60 individual varieties.

Each recipe will have a mandrel number associated with it. Varieties can only be linked to one mandrel number at a time. The mandrel number that is associated with the recipe must be inserted into the unit to be able to run that recipe.

The Recipe stores all of the data needed to be able to return to the user set position each time.

As we create a recipe, we go through all of the features available on the Burford® Smart Seeder. Some of these optional features may not be on your particular unit. Advance to the next section if we are discussing an option that is not on your unit.


Setting up a new recipe will require several pans of the product that you would like to create the recipe for to pass through the system.

The user should familiarize themselves with Chapter 4, *User Interface*, before attempting to create a new recipe.



#### New Recipe - User Interface (HMI)


We will begin from the Main Run screen. To add a recipe, we must advance to the Recipe Setup screen. To have access to the setup screens you must be logged in with supervisor privileges. For more information, please contact your supervisor or Burford<sup>®</sup> Corp. The operator will press the SETTINGS button to log in and advance to the Seeder Configuration Screen. Press the RECIPE button to advance to the Edit Recipe button. From the Edit Recipe, the operator will select the ADD NEW button and then press ACCEPT for that edit to advance to the Recipe Setup Screen.





#### Recipe Setup Screen

This Recipe Setup Screen is where the operator will be able to modify the New Recipe. For more information, as to what all the buttons on this screen does refer to page 119.



SOME OPTIONS WILL NOT BE AVAILABLE DEPENDING ON WHAT WAS PURCHASED.


Authorized personnel should only modify these settings. Damage to the unit and / or bodily injury may occur. Exercise extreme caution when making changes.



#### ■ New Recipe – Name the Recipe

Type in the name of the new variety with the on-screen keyboard. Press the Return key when finished. In our example, the name Hoagie.

Press the New Recipe to name the New Recipe. In this example we will use as the recipe name.




Authorized personnel should only modify these settings. Damage to the unit and or bodily injury may occur. Exercise extreme caution when making changes.




### New Recipe – Mandrel Select

Determine which mandrel will have the new variety and insert it into the topper. The Hopper will automatically move to the Dump position and perform Dump Procedures.

Twist the mandrel to lock it into the hopper. In this example, we will use Mandrel 1.





The Mandrel Label Button will show what mandrel is inserted. The operator is also able to input the mandrel that will be used in the recipe by pressing the Mandrel Label Button and inputting number on the keypad and pressing ENTER.

Enable the Mandrel drive by pressing






#### New Recipe – Hopper Controls

We will now setup the mandrel controls.

Set the Mandrel Speed by pressing the button and input a numeric percentage. The higher the number the more toppings applied to the product.

Set the Mandrel Direction by pressing the button until the direction of your choosing appears. Usually will be chosen.

Extend Deflector Bar ON), or Retract Deflector bar.





#### New Recipe – Agitator Setup

Determine if the Agitator is needed for this variety.


If the Agitator is enabled, set the speed in which the Agitator reciprocates by pressing the **AGITATOR SPEED** button and inputting a numeric value.

The greater the number the faster the Agitator will reciprocate.

If the Agitator is not needed for the recipe, then set the speed to 0 (zero).

For this example, we will use 45 April as the speed.

For more information on the Agitator, refer to page 125.





#### New Recipe – Hopper Position

On the Recipe Setup Screen, select



(Automation Positioning).


Determine the height of the hopper for this variety by placing a pan with the product that will be used during this recipe on the conveyor under the hopper.


Press to lower the Hopper.

Press to raise the Hopper.

Normally 2 to 3 inches above the product is acceptable for most toppings.

For Complete information on Hopper Position setup, see page 159.





**Press** 



to save this setting.

180 Chapter 5 Burford

#### New Recipe – Pan Guide

On the Recipe Setup Screen, select Automation Positioning).


Determine the width of the pan guides for this variety by placing a pan with the product that will be used during this recipe at the infeed and outfeed positions of the conveyor.


Press to close the Pan Guide distance.

Press to increase the Pan Guide distance.

Normally 1/4 inch on both sides of the pan is acceptable.

For Complete information on Pan Guide setup, see page 160.





Press to save this setting.



#### New Recipe – Spray Lift

On the Recipe Setup Screen, select Automation Positioning).


Determine the height of the Spray Rail for this variety by placing a pan with the product that will be used during this recipe under the spray rail.


Press to lower the Spray Rail.

Press to raise the Spray Rail.

Normally 5 to 6 inches above the product is acceptable for most toppings.

For Complete information on Hopper Lift setup, see page 161.





**Press** 



to save this setting.

182 Chapter 5 Burford

#### New Recipe – Split Lift


On the Recipe Setup Screen, select Automation Positioning).

Determine the height of the Split Rail for this variety by placing a pan with the product that will be used during this recipe on the conveyor. Run the pan under the rail until you achieve the split desired.

Press to lower the split rail.

Press to raise the split rail.

For Complete information on Hopper Lift setup, see page 162.



Press to save this setting.




#### New Recipe – Hopper Fill (Optional)

Determine if the Hopper Fill is needed for this variety. Select whether the Hopper Fill will be available for this variety when loaded by the toggling the top half of the screen.

If the Auto-Fill will be available on this variety, then select the time of the Hopper Fill by placing a numeric value in sends in the

For this example, we will use 45 seconds as the fill time.

For Complete information on the Hopper Fill setup, see page 163.





#### **New Recipe - Seed Level Alarms (Optional)**


Determine if the Seed Verification Alarms are needed for this variety.

Turn the Seed Verification Alarm ON or OFF by pressing Verification Alarm ON





For Complete information on Level Alarms setup, see page 166.







#### New Recipe - Pan Setup, continued

Begin by running pans of product through the system. It may take several pans to setup up a variety. There should be dough in the pan to achieve the best results.

Set the Pan Dimensions by pressing the corresponding input selections on the screen that are associated with the dimension of the pan. The software utilizes the dimensions entered to calculate the necessary amount of topping to dispense into each cup, minimizing the topping consumption.

To learn how to set the dimensions refer to page 130.







Press to return to the Recipe Setup Screen.

Chapter 5 186


#### **New Recipe – Water Spray**

Determine if the variety will be sprayed when variety is loaded. Select the button to advance to the Water Spray Setup Screen.

With a pan for the variety present, turn on the valves that will be enabled when the recipe is loaded. Position the valves on the spray rail in alignment with the pan. Refer to page 207 for information on Topper Spray Nozzle position.

With the conveyor running, place the pan on it and allow it to pass under the spray rail. Observe the ON and OFF actuation of the valves in reference to the beginning and end of the pan. Adjust the ON and OFF delays until you are satisfied with spray coverage.

For Complete information on Water Spray setup, see page 161.



**Press** 



to return to the Recipe Setup Screen.



#### New Recipe - Water Split


Determine if the variety will be Split when loaded. Select the button the Water Splitter Setup Screen.

With a pan for the variety present, turn on the valves that will be enabled when the variety is loaded. Position the valves on the splitter rail in alignment with the pan.

With the conveyor on, place the pan on it and pass the pan under the split rail. Observe the ON and OFF actuation of the valves in reference to the beginning and end of the pan. Adjust the ON and OFF delays until you are satisfied with spray coverage.

For Complete information on Splitter setup, see page 162.





**Press** 




to return to the Recipe Setup Screen.



#### New Recipe – Flour Duster (optional)

On the Main Setup Screen press Positioning (Flour Duster).



If equipped with a Flour Duster, enter the parameters for setup.

Select the mode for this variety by pressing and enable or disable the Flour Duster for this recipe.

Enter the PERCENT DUSTER SPEED by pressing and putting in a numeric value.

Enter the DELAY ON and DELAY OFF time values.




For Complete information on the Flour Duster setup, see page 168.

Press to return to the Recipe Setup Screen.



#### New Recipe – Seeder Configuration







Set the critical unit functions to the recipe by returnin to the Main Screen and pressing the Setup utton to advance to the Seeder Configuration Sceen.

Use extreme caution when changing any settings.

Refer to page 102 for more information regarding the Seeder Configuration Screen.

Congratulations! You have now set a new recipe.

## Chapter 6

# Operation Procedures

192 Chapter 6 Burford

#### **CHAPTER 6: OPERATION PROCEDURES**

#### ■ Theory of Operation

Product begins to flow onto the unit's conveyor. As the product moves down the conveyor chain it encounters a product sensor. Once the product has actuated the product sensor for the amount of time entered in the "SPRAY DELAY" the spray sequence begins (determined by the setup information provided via the control panel). Product then travels beneath the spray head assemblies. The application of water is a crucial step in the application of topping since it helps bond the topping to the dough. An insufficient application of water will lead to the topping bouncing or slipping off the product; too much water can lead to spotting during bake out. The product then exits the spray / split area and continues downstream.


After water has been applied, the pans travel to the topping application area located directly under the unit's hopper. A pan sensor is used to sense the leading edge of the pan. When a pan is sensed, an electrically controlled clutch/brake is actuated, causing the mandrel assembly to rotate and dispense topping. The pan dimension data entered for the particular recipe and encoder signals control the timing and duration of the dispensing process.



#### Main Disconnect

The main disconnect controls the power to the unit. This is where the machine is turned "ON" or "OFF". Turn the Unit "ON" by turning the disconnect Switch to the "ON" position.

Turn the Unit "ON" by turning the disconnect Switch to the "ON" position. The HMI will perform a self-diagnostic test.



Shown above is the disconnect switch in the "ON" position. Turn the handle 90° clockwise to turn the unit OFF.



#### ■ E-Stop


When safe to do so, pull the E-Stop out to initialize the unit. The HMI will perform self-diagnostic tests.






#### Press Start

The unit will begin moving to in the following sequence: Hopper Lift, Pan Guides, Spray Lift, and Split Lift. The homing process can take several minutes. Do not interrupt the homing of the unit.









#### Select Recipe


After the homing process, you will be at the Main Run screen. To select a recipe, press the button. You will advance to the select recipe screen.







#### Select Recipe, continued



The Select Variety screen allows the user to change the current variety selected. An indicator at the lower middle of the screen displays the Mandrel needed for the highlighted recipe. Once the variety is highlighted, the operator will push the ACCEPT button. The unit will now move all of the automated adjustments to the position that was configured for that particular variety.


If the operator then selects a variety that is not available with the current Mandrel inserted, a dialog box will appear informing the operator of the correct Mandrel to be inserted for the variety selected. Once the correct Mandrel is inserted, the unit will begin moving to dump and wait for the correct mandrel. Once the correct mandrel is inserted, the unit will move to the configured positions for that Recipe.

Press DECLINE to return to the Main Run screen.



#### Select Recipe, continued

This will display all of the varieties that are installed on the unit. Highlight the desired variety that you want to load. The message box will display what mandrel is used with the recipe.




Select a recipe by touching the recipe box and then press,



ACCEPT.


If the recipe calls for a different mandrel than what is inserted, then the hopper will move to the dump position and perform the dump procedure.






#### Insert Mandrel

Insert the Mandrel number indicated as follows.



Retrieve the mandrel from the mandrel storage.






#### Run Mode

Verify Water Spray and Water Split are working by pressing Purge. Verify Topper, Conveyor, Auto-fill and Flour Duster are on in accordance with the selected recipe.


To set up a recipe refer to Chapter 5.





#### Recipe Change Same Mandrel


The SELECT Recipe button advances the display to the variety selection screen shown on following page, providing a simple method to select a desired recipe.



Highlight the recipe that you would like to run and press the set parameters for that recipe.




. The unit will move to



Chapter 6



#### Recipe Change - Jog Mandrel



Pressing the JOG MANDREL button will rotate the mandrel. The Mandrel will remain rotating for 15 seconds.

The Jog Mandrel feature is used to load the Mandrel with toppings prior to the first pan and to verify operation.




#### Options

Depending on options purchased, your unit may or may not be fully automated. The next few pages reviews the procedures for manual setup of the pan guides, Hopper height. Spray and Split lift. If your unit is fully automated, refer to Chapter 4 and 5 on how to set the automation of your Unit.

#### ■ Models Without Automation

Before running a recipe, the Topper must be setup properly. If the unit is fully automated, the Topper will automatically position itself for the recipe selected. Depending on the automation options purchased, the operator may have to adjust:


- Pan Guides
- Hopper Height
- Water Spray / Water Split Height






#### Pan Guide Adjustment - Manual

Place your pan on the conveyor and adjust the pan guide so that there is not more than a 1/4" gap on either side. The pan must be squared beneath the topper hopper.



The Pan Guide system has two hand cranks for adjustment.




When making adjustments, both hand cranks  $\underline{\text{MUST}}$  be turned simultaneously to prevent binding of pan guide mechanism.



#### ■ Pan Guide Adjustment - Manual, continued

The pan guides need to be adjusted to prevent the pan from turning during transfer through the Topper. It is important that the pan travels straight under the Topper dispense for proper topping coverage. A slight gap must be present on the sides of the pan to prevent pans from stopping on the conveyor.




There should be a 1/4" gap on either side of pan in relation to the pan guide.



#### ■ Topper Height Adjustment – Manual

Locate the hand crank shown below. Adjust the height of the hopper so that it is approximately 2" - 3" above the product.







#### ■ Topper Spray Nozzle Position

The position of the nozzles should be set so the spray is directly over the cups of the pan. All of the nozzles should be set in a direct line with one another. The nozzles can easily be moved by the use of the T-handle lock on each nozzle.


The Nozzles are adjustable laterally for alignment with product.




Locate nozzle to be positioned.



Position nozzle to desired location.



Rotate lever to free nozzle.



Rotate lever to lock nozzle.

When positioning nozzles be mindful of the water hoses and electrical connections. Plumbing and connectors to the nozzles should not be taut.



#### ■ Topper Nozzle Dampness Output


The degree of dampness obtained on the product will be determined by the number of nozzles used, water pressure, and orifice size used in each nozzle.

Each nozzle may be individually turned off or on and should be used accordingly to the number of cups in the pan.


The recommended pressure setting is 40 psi for water.

The orifice size of each nozzle as it came from factory is .012. This size should be sufficient for your product, but larger or smaller sizes may be obtained if needed.

Below is an example of using one spray nozzle for each cup. This will supply more volume of water.




Below is an example of using one nozzle for two cups. This will supply less volume of water.



#### ■ Topper Product Sensors Topper

The 9840S Topper has two product sensors assemblies. One for the Spray  $\!\!\!/$  Split and the other for the Topper.




**Topper Sensor** 



#### Catch Tray

Install the Catch Tray as shown below when running varieties that do not require toppings. This will reduce or eliminate the contamination of other doughs.



## Chapter 7

### Troubleshooting



#### **CHAPTER 7: TROUBLESHOOTING**

#### Topper

#### Problem

Product not damp enough for topping to stick.

Possible Causes Solutions

Nozzles set too high from product.

Water pressure too low.

Decrease hopper height.
Increase water pressure.

Nozzles not centered over cups of pan.

Nozzle tips too small.

Conveyor moving too fast.

Re-adjust nozzles.

Order larger tips.

Slow conveyor speed.

#### Problem

#### Spot spray system not activating.

Possible Causes Solutions

Water spray control switch is turned off. Check switch control.

Limit switch not sensing cups. Check switch.

Pan guides allowing pans to turn and not

activating limit switch. Re-adjust pan guides.

#### Problem

#### Nozzles not dispensing water.

Possible Causes Solutions

Water pressure too low. Increase air pressure. Valve(s) turned off. Check operator panel.

Obstruction in nozzle tip. Clean tip.

#### Problem

#### Not enough topping on product.

Possible Causes Solutions

Mandrel speed too slow. Increase Mandrel speed. Hopper set too high over product. Lower hopper height.

#### Problem

#### Too much topping on product

Possible Causes Solutions

Mandrel speed set too fast. Slow Mandrel speed down.

Pans slow down when going over sensor. Re-adjust pan guides.



#### Problem

#### Topper not activating.

Possible Causes	Solutions
Control switch turned off.	Turn control on.
Product sensors not sensing cups.	Set sensor properly.
Pan guides allowing pans to turn and	
miss product sensor.	Re-adjust pan guide.
Unit set to Remote Conveyor and not	
Receiving signal.	Check Signal and setting.
Conveyor Encoder not sending data	Check Encoder signal.

#### Problem

#### Topping not dispensing.

Possible Causes	Solutions
Air pressure too low.	Increase air pressure.
Mandrel not engaging	Replace Clutch.
Foreign material in hopper.	Clean hopper.
Clutch not receiving signal	Check Clutch Circuit.

#### Problem

#### Streaks showing on product.

Possible Causes	Solutions
Foreign material in hopper, restricting	
flow of topping.	Clean out hopper.
Pan guides off-center.	Re-adjust pan guides to center cups
	of pan to pattern mandrel.

#### Problem

#### Product not topped from one end to the other.

#### Solutions

Adjust Pan Dimensions. Check Product Sensor.

Check pans for warped bottom.



#### ■ Water Splitter Troubleshooting

#### Problem:

#### UNIT WILL NOT POWER UP

A. Check incoming power supply.

#### Problem:

#### **INADEQUATE SPLITTING DEPTH**

- A. Check nozzle height setting.
- B. Check manifold output setting.
- C. Check product sensor to nozzle timing.

#### Problem:

#### **EXCESSIVE SPLITTING DEPTH**

- A. Check manifold output setting.
- B. Check nozzle height setting.

#### Problem:

#### LOSS OF NOZZLE PRESSURE

- A. Check fluid output setting.
- B. Check fluid filter.
- C. Check for dirty tips.

#### Problem:

#### **UNEVEN DISTRIBUTION OF SPLITS**

- A. Check nozzle height setting.
- B. Check sensor to nozzle timing.
- C. Check for dirty tips.

#### Problem:

#### SENSOR NOT DETECTING PRODUCT

- A. Check sensor height.
- B. Check sensor alignment.
- C. Check for product.

## Chapter 8

### Maintenance



#### **CHAPTER 8: MAINTENANCE**

#### ■ Drive Settings

The Burford® Unit is equipped with up to (4) AC motor drives to control the operation of the unit. The above programmable motor controller is an example of the drives used. The table below provides a brief description of the function keys. See supplied motor drive manual for additional information.





REF	FUNCTION	DESCRIPTION
1	Display	Displays parameter groups and values. Also contains status LEDs. See accompanying owner manual for more information.
2	Escape	Back one step in programming menu. Cancels a change and exit programming mode.
3	Select	Advance one step in programming menu. Selects a digit when viewing parameter values.
4	Enter	Advance one step in programming menu. Save a change to a parameter value.
5	Speed Dial	Used to control speed of drive.
6	Scroll	Used to scroll through parameters or to increase/decrease parameter values.
7	Start	Used to start the drive.
8	Stop	Used to stop the drive or clear a fault.
9	Reverse	Used to reverse direction of drive.

#### Drive Parameters

The motor controllers have been preset at Burford® Corp. for your particular application. The digital input function is used to configure the controllers for remote operation via the programmable logic controller and touch screen interface. See Drive Settings in Drawings and Parts for the settings of your unit.

#### ■ Recommended Weekly Maintenance

Drain air filter.

Check and fill lubricator.

Inspect water/air lines and replace if defective.

Check and clean water filter.

Inspect electrical enclosure air filter. Clean if necessary.

Use compressed air to clean dust and debris from the smart seeder.

#### ■ Recommended Monthly Maintenance

Check all mounting screws and insure they are secure.

Check sprocket setscrews and keys for tightness.

Check the chain alignment and lightly lubricate chains.

Remove product from hopper and clean thoroughly.

Replace water filter.

#### Recommended Bi-Annual Maintenance

Lubricate all-threads and worm gears with food-grade grease.

Check all sensors for proper operation.

Check all spray and split valves for proper operation.

Check all pneumatic restrictors for proper operation.

#### Cleaning Recommendations

Remove all catch pans and catch trays from unit and thoroughly clean at a site away from the topper.

Separate the conveyor chain and clean at a site away from the topper.



#### Maintenance Procedures

#### Purging Spray Valves

When the unit is initially installed, all water lines must be purged, which can take 15-20 minutes to accomplish. However, once the main lines have been purged, they will stay full of water so that subsequent purging, due to changing of tips or check screens, can be done more quickly.

The proper procedure is as follows:

Remove all check-screens, O-rings, and tips from valve assemblies.

Connect a  $\frac{1}{4}$ " line to the "PURGE" valve and route to a suitable container (purging may require approximately 10 - 20 gallons of water through the system).

With the "PURGE" valve open, depress the "purge" button.

Allow the water to flow until a smooth, continuous stream appears.

Close the "PURGE" valve and repeat while monitoring the water flow from the spray valves.

Install the check-screens, O-rings, and tips into the valve assemblies. Purge the unit: every time the water is turned off, the stream spraying from the tips should have a clean and instant cut off. There should be no dribbling or slow stopping of water. If this occurs, you will need to repeat the steps for purging until a clean stop of water is apparent.

Keep clear of hopper when moving the hopper to "DUMP".

The Smart Seeder has multiple sensors and electronic components that may be damaged by water. Keep the Smart Seeder dry.

It is very important to purge all the air from the manifold and nozzles for proper operation of the water spray valves.

Keep the Smart Seeder dry.



#### Alarm Banner

The Alarm Banner is configured to pop up over any screen to display that an error has occurred with the unit. A sample alarm banner below indicates a failure has occurred with the Hopper movement. The banner will remain until the "Acknowledge" box is touched or the condition has been resolved. There are 77 different alarm banners to assist with

troubleshooting the unit.



Item	Text ID	Code	Message Displayed
1	1075	INFO 1.16	Recipe Change
2	1076	INFO 1.17	Mandrel Change
3	1082	ERROR 1.01	Mandrel Drive COM Error-Read. PLC was unable to read data from the device.
4	1086	ERROR 1.03	Conveyor Drive COM Error-Read. PLC was unable to read data from the device.
5	1087	ERROR 1.02	Mandrel Drive COM Error-Write. PLC was unable to write data to the device.
6	1090	ERROR 1.04	Conveyor Drive COM Error-Write. PLC was unable to write data to the device.
7	1345	INFO 1.18	System Restart
8	2884	ERROR 2.1	Mandrel Drive Power Loss.
9	2885	ERROR 2.2	Mandrel Drive Under voltage.
10	2886	ERROR 2.3	Mandrel Drive Overvoltage.
11	2887	ERROR 2.4	Mandrel Drive Motor Stalled.
12	2888	ERROR 2.5	Mandrel Drive Motor Overload.
13	2889	ERROR 2.6	Mandrel Drive Heat Sink Over temperature.
14	2890	ERROR 2.7	Mandrel Drive HW Overcurrent (300%).
15	2891	ERROR 2.8	Mandrel Drive Ground Fault.
16	2893	ERROR 2.9	Mandrel Drive Auto Reset Tries.
17	2894	ERROR 2.10	Mandrel Drive Phase U to Ground Short.
18	2895	ERROR 2.11	Mandrel Drive Phase V to Ground Short.
19	2896	ERROR 2.12	Mandrel Drive Phase W to Ground Short.
20	2897	ERROR 2.13	Mandrel Drive Phase UV Short.
21	2898	ERROR 2.14	Mandrel Drive Phase UW Short.
22	2899	ERROR 2.15	Mandrel Drive Phase VW Short.
23	2900	ERROR 2.16	Mandrel Drive Software Overcurrent.
24	2901	ERROR 2.17	Mandrel Drive Overload.
25	2902	ERROR 2.18	Mandrel Drive Power Unit Fail.
26	2904	ERROR 2.19	Mandrel Drive Communication Loss.
27	2905	ERROR 2.20	Mandrel Drive Parameter Checksum Error.
28	2906	ERROR 2.21	Mandrel Drive I/O Board Fail.
29	2910	ERROR 3.1	Conveyor Drive Power Loss.
30	2911	ERROR 3.2	Conveyor Drive Under voltage.
31	2912	ERROR 3.3	Conveyor Drive Overvoltage.
32	2913	ERROR 3.4	Conveyor Drive Motor Stalled.
33	2914	ERROR 3.5	Conveyor Drive Motor Overload.



#### Alarm Banner, continued

Item	Text ID	Code	Message Displayed
34	2915	ERROR 3.6	Conveyor Drive Heat Sink Over temperature.
35	2916	ERROR 3.7	Conveyor Drive HW Overcurrent (300%)
36	2917	ERROR 3.8	Conveyor Drive Ground Fault.
37	2919	ERROR 3.9	Conveyor Drive Auto Reset Tries.
38	2920	ERROR 3.10	Conveyor Drive Phase U to Ground Short.
39	2921	ERROR 3.11	Conveyor Drive Phase V to Ground Short.
40	2922	ERROR 3.12	Conveyor Drive Phase W to Ground Short.
41	2923	ERROR 3.13	Conveyor Drive Phase UV Short.
42	2924	ERROR 3.14	Conveyor Drive Phase UW Short.
43	2925	ERROR 3.15	Conveyor Drive Phase VW Short.
44	2926	ERROR 3.16	Conveyor Drive Software Overcurrent.
45	2927	ERROR 3.17	Conveyor Drive Overload.
46	2928	ERROR 3.18	Conveyor Drive Power Unit Fail.
47	2930	ERROR 3.19	Conveyor Drive Communications Loss.
48	2931	ERROR 3.20	Conveyor Drive Parameter Checksum Error.
49	2932	ERROR 3.21	Conveyor Drive I/O Board Fail.
50	2935		Axis Option Drive Power Loss.
51	2936		Axis Option Drive Under voltage.
52	2937		Axis Option Drive Overvoltage.
53	2938		Axis Option Drive Motor Stalled.
54	2939		Axis Option Drive Motor Overload.
55	2940		Axis Option Drive Heat Sink Over temperature.
56	2941		Axis Option Drive HW Overcurrent (300%)
57	2942		Axis Option Drive Ground Fault.
58	2944		Axis Option Drive Auto Reset Tries.
59	2945		Axis Option Drive Phase U to Ground Short.
60	2946		Axis Option Drive Phase V to Ground Short.
61	2947		Axis Option Drive Phase W to Ground Short.
62	2948		Axis Option Drive Phase UV Short.
63	2949		Axis Option Drive Phase UW Short.
64	2950		Axis Option Drive Phase VW Short.
65	2951		Axis Option Drive Software Overcurrent.
66	2952		Axis Option Drive Overload.
67	2953		Axis Option Drive Power Unit Fail.
68	2955		Axis Option Drive Communications Loss.
69	2956		Axis Option Drive Parameter Checksum Error.
70	2957		Axis Option Drive I/O Board Fail.
71	2984	ERROR 1.05	Topping Hopper Product Level Low.
			Hopper Movement Failed. Unable to move to programmed position. Unit will
72	3116	ERROR 1.06	continue to setup. You must move this axis to position manually!
70	0447	EDDOD 4 00	Spray Rail Movement Failed. Unable to move to programmed position. Unit will
73	3117	ERROR 1.08	continue to setup. You must move this axis to position manually!
74	0110	EDDOD 4 67	Pan Guide Movement Failed. Unable to move to programmed position. Unit will
74	3118	ERROR 1.07	continue to setup. You must move this axis to position manually!
75	2100	EDDOD 1 00	Splitter Movement Failed. Unable to move to programmed position. Unit will
/5	3122	ERROR 1.09	continue to setup. You must move this axis to position manually!
76	3136	ERROR 1.10	Pan Sensor Blocked. Check for pan spacing or reflector dirty or damaged. Check for sensor problem.
77	3174	ERROR 1.11	Autofill Hopper Product Level Low.
11	31/4	LUUUN 1.11	Automi Hopper Floudet Level Low.

# Chapter 9

# Parts & Drawings



#### **CHAPTER 9: PARTS & DRAWINGS**

#### ■ Recommended Spare Parts

In order to prevent unnecessary down time, Burford $^{\rm @}$  Corp. recommends the list of parts in the Drawings and Parts section be kept in stock.

# Contents

Recommended Spare Parts	1
Seeder Assembly (MOD)	2
Seeder Hopper Main Assembly	4
Hopper Agitator Assembly	6
Hopper Deflector Assembly	8
Dump Vibrator Assembly	10
Hopper Enclosure Assembly	12
Hopper Height Adjust Assembly	14
Seeder Pneumatic System	16
Water Spray/Split Frame Assembly (MOD)	18
Pan Sensor Assembly / Splitter Nozzle Assembly / Pulsating Spray Gun Assembly	20
Spray/Split Frame Height Adjust	22
Conduit Assembly	24
FD1150 Assembly	26
Duster Conveyor Mount	28
MPA Frame Mount Assembly	30
HS-300 Assembly / MPHS-300/500 Kit / MPA Connecting Hose	32
Pump Cart Assembly	34
MPAS Vibrator Kit	36
Conveyor Components	38

Catch Pan Assembly	40
Pan Guide Assembly	42
Catch Pans	44
Drive Settings	46
Electrical BOM	46-1
Electrical Ladder	48
Electrical Layout	50

Call 1-877-BURFORD or fax 405-867-4219 to order your parts.

#### Proprietary

The following information is the exclusive property of Burford Corp., Maysville, Oklahoma and is confidential, provided only for reference. Do not copy or reproduce.

# Drawings & Parts

# Recommended Spare Parts

Please have the following machine information on hand before calling Burford®.

- Machine Voltage 480 Vac
- •Model Number 9950BBU-UL, STS-862, MPAS-100, FD1150BLE, 948LI-160S 21040 21059
- Sarial Number 21058


Fold Out to View Table of Contents

	•Ser	ial Number	21058,	21060,	210	59, 2	1061,	21062
		9950BBU-UL or	SO118568				948LI-160S on	SO118568
QTY	PART #		DESCRIPTION		QTY.	PART #		DESCRIPTION
1	304123-001	Motor,Gear,1/8HP	200/230-50/6,3.6	:1	1	612045-004	Controller,Pwr	FLX525, 480-3
1	610913	Power Supply, 480	VAC-24 VDC,10A	,3PH	1	611388	Bearing, 1" Bo	re, 2 Bolt Flange, SST
1	304239	Clutch/Brake, Shat	it Mount, 24 VDC		2	611635	Bearing, 1" Bo	re, 3 Bolt Flange
2	304350-001	Sensor, Prox, 8mm,	10-30 VDC, PNP	N.C.	2	611723	Sprocket, 16T,	3.11" OD, EZ Clean
1	304430	Cable,Sensor,M12	5Wire,F,QC,Str		2	611724	Sprocket, 24T,	4.65" OD, EZ Clean
1	610151	Sensor, Prox, 6.5mr	m, 10-30 VDC, PN	P, N.C.	1	611906	Gearmotor, 1,	'2 HP, 460-60-3, 109 RPM RH
1	610172	Switch, Light Bulb,	24 VDC, LED		4	611725	Belt, 6' x 1/2"	Pitch, Series 1100 *sold per ft*
3	610404	Relay, Terminal Mo	ounting, 24 VDC,	6A, 1 PDT				
1	610421	Relay, Terminal Mo	ounting, 24 VDC,	2A, SSR			FD1150LE on S	SO118568
1	610426	Bearing, Rod End,	1/2" ID, 1/2-20 UN	IF.	QTY.	PART #		DESCRIPTION
1	612061	Sensor, Keyence L	aser Distance, 2M	1	1	612045-004	Controller, Pw	r Flx525, 480-3
1	611102	Encoder, 1.375 Thr	u Bore		1	612330-050	Brush, Flour Du	ster, 50"
1	611119	Valve, Solenoid, 24	VDC, 3-Way, Cl	osed Cen 1/4P	1	C07678	Sensor, Interlo	ck
2	611237	Bearing, Pillow Bloo	ck, 5/8" SST		1	612455	Motor, Clutch	Brake, 1/8 HP, 90:1
2	611238	Bearing, Flange, 5,	'8" SST		1	C07670-001	Sensor, Prox, C	Capacity, 30mm, 24V
1	611365	Valve, Solenoid, 24	VDC, 2-Way, Wi	th Flow Controls	1	611027	Sensor, Photo,	Diffuse, 10-30 VDC Wide
2	611387	Bearing, Flange, 3,	/4" SST					
1	611603	Gearmotor, 1/3HP,	230/460-60-3,LH				MPAS-100 on	SO118568
1	611937	Plc,Compactlogix,	L30ER,1M		QTY.	PART #		DESCRIPTION
1	611574	Valve, Pulsajet Gu	n		1	210453	Filter, Dust, Uni	filter
1	612008	Valve,SOL, SS 1/8N	PT 2 Way 24VDC		1	210454	Gasket, Rim, V	Vhite Silicone
2	612018	Tip,Split,Bete,.020"	1/8" NPT		1	610295	Sensor, Prox 18	3 mm, 24 VDC
1	612563	PLC.Display,PV+(7)	Touch, Ethernet		1	610739	PLC,ML1500,I/	O Module 6IN/4OUT
1	612045-004	Controller, Power F	Flex 525,480-3		1	611117	Valve, Solenoi	d, 24 VDC
2	C00565	Spray Tip, SS, Tee J	et		1	611951	Vacuum Moto	or 220V MPA
1	C00579	Filter, Water, Repla	icement #AP110		1	612338	Cable,25 Pin [	0-Sub,1.5 Meter
4	C05724	Varistor, Surge, 125	5A, 25 VAC / 31 V	DC	1	C06597-001	Relay, Overloo	ad, 3-Ph, Adj, 5.5-8.0A
1	C06753	Sensor, Cable, M1	2, 5-Wire, Straight	, Female, QC	1	C06702-001	Relay, Motor S	tarter, 24VDC, 10A
1	C07101	Switch, Contact C	artridge, 1, N.C.		1	C07670	Sensor, Prox, 3	0 mm, 24 VDC

#### Seeder Assembly (MOD) 211107 Rev A

TEM #	QTY.	PART#	DESCRIPTION	ITEM #	QTY.	PART#	DESCRIPTION
1	1	103478	SPROCKET IDLER, 35-A-15 3/8" BORE	64	1	712222	SPROCKET, 25-B-19 5/8" BORE
2	6'	108331	CABLE, 18AWG, 4 COND, BLACK CORD	65	1	712376	HANDLE, REWORK, 6" DIA, ALUM
3	2	111497	MUFFLER, 1/8" NPT	66	1	712853	ROD, CYL. MNT., HOPPER DUMP
4	2	122228	BUSHING 3/8 X 3/4 X .024 MACH	67	1	712958	SHAFT, ALL-THREAD PROX COUNT
5	REF.	210384	ASSY, HEIGHT ADJ., HOPPER, 9840S	68	1	712961	BRACKET, HEIGHT ADJ. PROX
6	1	210385	ASSY, PNEUMATICS, SEEDER, 9840S	69	1	712780	SENSOR, REFLCTR, TAPE 4-3/4 X 1-1/2
7	1		ASSY, ENCL, MAIN, 9840-BBU	70	1	714506	
8	1			70	1		PLATE, MOTOR MNT, MANDREL DRIVE
		210411	ASSY, BLOCK, HEIGHT ADJ TARGET			714507	A/W, CATCH PAN, MANDREL MOTOR
9	1		ASSY, ENCL, DISP, PV700+,9940, L/H, BBU	72	1	715528	A/W, MANDREL DRIVE GUARD, OUTER
10	1	210446	ASSY, CYLINDER, HOPPER DUMP	73	1	715531	ROD, ECCENTRIC IDLER, 9840
11	1	211109	ASSY, SEEDER HOPPER, 9950	74	2	715532	SPACER, MANDREL DRIVE GUARD
12	5	302361	DECAL, SMALL, KEEP GUARD IN PLACE	75	1	715533	A/W, MANDREL DRIVE, GUARD MNT.
13	2	303056	PLUG, HOLE, SST 7/8" DIA	76	1	716100	A/W, CHANNEL BASE, 9850
14	8	304015	ROLLER, LIFT	77	1	716103	A/W, TOP SEEDER CHANNEL, 9950
15	8	304016	SHAFT SPACER ROLLER LIFT 9840	78	1	716106	A/W, COVER, TOP CHANNEL,9850/9950
16	2	304109	BRACKET, MANDREL RACK	79	1	716108	Shaft, height adjustment, 9850
17	2	304350-001	SENSOR,PROX,8MM,10-30V,PNP,NC,TURCK	80	1	716129	A/W, SEEDER DUMP TRAY,9850
18	1	304430	CABLE,SENSOR,M12,5WIRE,F, QC,STR	81	1	716131	A/W, CATCH PAN, 9850 HOPPER
19	2	304830	A/W, ANGLE MOUNT, 9840	82	1	A06858	FITTING,TEE, 1/4 NPTF,SST
20	2	304831	A/W, ANGLE MOUNT, 9840S	83	2	A08049	NAMEPLATE, BURFORD LOGO, LARGE
21	3	401152	FITTING,CONN,1/4MPT X 1/4T,ENP,Q.R.	84	10	C00174	LOCKING NUT, 1/2 NPT, NYLON
22	2	401302	VALVE, REG, FLOW CONTROL, ENP, Q.R.	85	1	C00404	F.R.L. COMBO, 1/4 NPTF, 72 SERIES
23	6"	610360	TERMINAL, DIN RAIL, MINI	86	1	C00905	FITTING,NIPPLE,1/4 NPTM X 2,SST
24	25	610361	TERMINAL, BLOCK, MINI	87	6'	C01237	CABLE, 22AWG, 15 COND, SHIELDED
25	3	610362	TERMINAL, END COVER, MINI	88	1	C03335	PLATE, FRL MOUNTING
26	2	610363	TERMINAL, ANCHOR, END CLAMP, MINI	89	2	C04828	SPROCKET, REWORKED 35-B-21, .75B
27	1	610364	TERMINAL, JUMPER, 10-POLE, MINI	90	4	C07626	SENSOR,CABLE,M8,3WIRE,F,QC,90
28	3	610507	FITTING, CONN, 1/4NPT X 3/8T, ENP, Q.R.	91	9	988916	SCREW FIN HEX 3/8-16 X 1 SST
29	1	610534	TERMINAL, GROUNDING, MINI	92	8	955975	WASHER FLAT 3/8" SST
30	2	610602	FITTING, ELL, 1/4NPT X 1/4T,ENP,Q.R	93	6	955620	NUT HEX NYLOC 3/8-16 UNC SST
31	8	610839	COLLAR,1-1/2 SPLIT, SST	94	3	955470	KEY, SQ 3/16 X 1.00 .002 UNDERSIZE
32	3'		TUBING, 1/4" POLYURETHANE, BLUE	95	20	989912	SCREW FIN HEX 1/4-20 X 3/4 SST
33	3'						
			TUBING, 1/4" POLYUPETHANE, RED	96	22	955940	WASHER LOCK 1/4" SST
34	10'		TUBING, 1/4" POLYURETHANE, CLEAR	97	1	955400	NUT HEX JAM 1/2-20 SST
35	20'		TUBING, 3/8" POLYURETHANE, CLEAR	98	5	955977	WASHER FLAT 1/4" SST
36	8	610953	CONNECTOR, CORD, .2035, DOME, NYLON	99	31	955976	WASHER FLAT 5/16 SST
37	2	610954	CONNECTOR, CORD, .3956, DOME, NYLON	100	22	955619	NUT HEX NYLOC 5/16-18 UNC SST
38	10	610955	CONNECTOR, SEAL RING, 1/2NPT, POLYETH	101	42	989728	SCREW FIN HEX 5/16-18 X 1 3/4 SST
39	3	610956	FITTING,BLKHD ELL 1/4T,ENP,Q.R.	102	10	982310	SCREW FLT HD SOC #10-24 X 5/8 SST
40	1	611102	ENCODER, 1.375 THRU BORE	103	20	955939	WASHER, LOCK 5/16" SST
41	1	611119	VALVE,SOL,24V,3 WAY,CLOSED CEN,1/4P	104	4	972008	SCREW SET SOC 5/16-18 UNC X 1/2 SST
42	4	611165	LATCH, DRAW, COMPRESSION SPRING	105	2	955938	WASHER, LOCK 3/8" SST
43	2	611237	BEARING, 5/8 PILLOW BLOCK, SST	106	9	978906	SCREW SOC HD CAP #10-24 UNC X 3/8 SST
44	4	611238	BEARING, 5/8, 2 BOLT FLANGE, SST	107	16	978328	SCREW SOC HD CAP 1/4-20 X 1 3/4 SST
45	4	611387	BEARING, 3/4", 2 BOLT FLANGE, SST	108	1	981620	SCREW FLT HD SOC 5/16-18 UNC X 1 1/4 SST
46	1	611603	GEARMOTOR,1/3HP,230/460-60-3,LH	109	4	979520	SCREW SOC HD CAP #8-32 UNC X 1 1/4 SST
47	1	710161	COVER, TERMINAL STRIP, 9840S/9940S	110	6	955625	NUT HEX NYLOC #8-32 UNC SST
48	2	711938	RWK, WORM GEAR	111	9	955941	WASHER LOCK #10 SST
49	2	711939	RWK, WORM STEEL, 5/8" B, 10 D.P.	112	4	987506	SCREW BUTT HD SOC #6-32 X 3/8 SST
50	1	711995	A/W, UPRIGHT SUPT	113	4	955624	NUT HEX NYLOC #6-32 UNC SST
51	1		A/W, UPRIGHT SUPT ENCL MT,9840-BBU	114	2	955661	NUT HEX NYLOC 1/4-20 UNC SST
52	3	712000	BRACKET, COVER UPRIGHT ROLLER, 9840S	115	6	971208	SCREW SET SOC 1/4-20 UNC X 1/2 SST
53	2	712000	PLATE, BEARING MT, HEIGHT ADJ, 9840S	116	10	971804	SCREW SET SOC #10-24 UNC X 1/4 SST
54	4	712001	BLOCK, CLAMP, BEARING PLATE	117	2	955972	WASHER FLAT #6 SST
55	2	712002	NUT, HIEGHT ADJ, 9840S	117	2	955936	WASHER LOCK #6 SST
56	2	712004	ALL-THREAD, 1"-5 ACME, HEIGHT ADJ.	119	2	976906	SCREW SOC HD CAP #6-32 X 3/8 SST
57	2	712005	PLATE, SIDE, HEIGHT ADJ, 9840S	120	8	955937	WASHER LOCK 1/2 SST
58	2	712006	PLATE, SIDE, HOPPER MNT, 9840S	121	8	988320	SCREW FIN HEX 1/2-13 X 1 1/4 SST
59	2	712008	BAR, HOPPER LID STOP, 9840S	122	2	998908	SCREW RD HD SLOT #8-32 X 1/2 SST
60	1	712026	SPROCKET, REWORK,35B14, 5/8 BORE	123	4	955621	NUT HEX NYLOC #10-24 UNC SST
61	1	712029	BLOCK, SHAFT SUPT, HEIGHT ADJ.	124*	1	304497	ASSY HOPPER DUMP VIBRATOR
62	2	712219	BLOCK, HIEGHT ADJ SHAFT	125*	1	718188	A/W, FINGER GUARD 9850/9950
63	1	712221	SPROCKET, 25-B-19 3/8" BORE	126*	1	717373	BAR, BACKUP, SENSOR BRACKET

\*NOT SHOWN





#### Seeder Hopper Main Assembly 211109 Rev B

ITEM #	QTY.	PART#	DESCRIPTION	ITEM #	QTY.	PART#	DESCRIPTION
1	2	103478	SPROCKET IDLER, 35-A-15 3/8" BORE	39	1	716109	A/W, SEEDER HOPPER, 9950, LH
2	1	111498	FITTING,MUFFLER,1/4 NPTM,BRS	40	1	716115	A/W, HOPPER COVER LATCH, 9850
3	5	122223	BUSH,MACH 3/4ID 1-1/4 ODX.0747	41	1	716117	SHAFT, CLUTCH BRAKE, 98450/9950
4	2	152169	CHAIN,ROLL,#35,NICKEL PLATED	42	1	716118	SHAFT, HOPPER INNER, 9850/9950
5	2	152175	CHAIN LINK #35 CONNECTING N.P.	43	4	955380	NUT HEX JAM #10-24 UNC SST
6	2	152186	SPRING EXTENSION	44	1	955455	KEY, SQ 3/16 X 1 3/4 (CUT FROM C01260)
7	1	210386-003	ASSY, ENCL, SEEDER HOPPER, 9940-BBU	45	2	955457	KEY SQ 3/16 X 1/2 .002 UNDER SIZE
8	1	300684	BRACKET, SEEDER MAGLOCK MT, CE	46	9	955620	NUT HEX NYLOC 3/8-16 UNC SST
9	1	304060	ASSY, MANDREL DRIVE	47	12	955935	WASHER LOCK #4 SST
10	1	304239	CLUTCH/BRAKE, SHAFT MOUNT 24 V.	48	2	955939	WASHER, LOCK 5/16" SST
11	1	304264	SPROCKET RWK 35-A-36 1.43" B	49	6	955940	WASHER LOCK 1/4" SST
12	2	304265	SPROCKET, RWK 35-B-28 3/4" BORE	50	13	955941	WASHER LOCK #10 SST
13	1	304322	SPACER, CLUTCH SPROCKET	51	4	955942	WASHER LOCK #8 SST
14	1	304323	PLATE, RESTRAINT C/B, 9840	52	8	955971	WASHER FLAT #4 SST
15	1	304430	CABLE,SENSOR,M12,5WIRE,F,QC,STR	53	2	955976	WASHER FLAT 5/16 SST
16	1	401152	FITTING,CONN,1/4MPT X 1/4T,ENP,Q.R.	54	13	955978	WASHER FLAT #10 SST
17	4	610151	SENSOR,PROX,6.5MM,10-30VDC,PNP,N.O.	55	2	958416	PIN ROLL 3/16 X 1 SST
18	1	610797	SENSOR,PHOTO,RETRO-REF,10-30V,N.O/C	56	2	971204	SCREW SET SOC 1/4-20 UNC X 1/4 SST
19	1	610885-07	TUBING, 1/4" POLYURETHANE, CLEAR	57	8	971208	SCREW SET SOC 1/4-20 UNC X 1/2 SST
20	1	611027	SENSOR,PHOTO,DIFFUSE,500MM,10-30V,QC	58	2	971803	SCREW SET SOC #10-24 UNC X 3/16 SST
21	4	611387	BEARING, 3/4", 2 BOLT FLANGE, SST	59	5	972704	SCREW SET SOC #6-32 X 1/4 SST
22	1	710623	RWK,BEARING, ROD END,1/2-20NF	60	4	976006	SCREW SOC HD CAP #4-40 X 3/8 SST
23	1	711573	PLATE, AGITATOR COVER	61	4	976008	SCREW SOC HD CAP #4-40 X 1/2 SST
24	1	712022	BLOCK, MANDREL SENSOR MT, 9840S	62	4	976012	SCREW SOC HD CAP #4-40 X 3/4 SST
25	1	712023	CLAMP, MANDREL SENSOR BLOCK	63	13	978908	SCREW SOC HD CAP #10-24 UNC X 1/2 SST
26	1	712024	PLATE, COVER, MANDREL SENSOR, 9840S	64	2	978916	SCREW SOC HD CAP #10-24 UNC X 1 SST
27	1	712042	ROD, CYLINDER MT, HOPPER DUMP, 9840S	65	3	985712	SCREW BUTT HD SOC 1/4-20 X 3/4 SST
28	1	712107	PLATE, TAPPED, LASER BACKUP MT	66	4	986904	SCREW BUTT HD SOC #8-32 X 1/4 SST
29	1	712127	BAR, HOPPER AIR CYL. STIFFENER	67	3	988916	SCREW FIN HEX 3/8-16 X 1 SST
30	1	712377	ROD, SENSOR BLOCK PLUG	68	6	988920	SCREW FIN HEX 3/8-16 X 1 1/4 SST
31	1	715524	COVER, MANDREL DRIVE SPROCKET, LWR	69	2	989712	SCREW FIN HEX 5/16-18 X 3/4 SST
32	1	715525	COVER, MANDREL DRIVE SPRKT, MID	70	3	989912	SCREW FIN HEX 1/4-20 X 3/4 SST
33	1	715526	COVER, MANDREL DRIVE SPRKT,TOP	71	2	A04792	COLLAR, LATCH RETURN, HOPPER
34	1	715527	STANDOFF, C/B SHAFT LOCK	72	4	A05015	PLATE, BEARING SEAL
35	1	715537-001	GUARD, CHAIN, MANDREL/CLUTCH, LH	73	1	A05020	COLLAR,3/4" SPLIT,SST
36	1	715595	PLATE, TAPPED, LASER BACKUP MT	74	1	C07219	SENSOR,INTERLOCK,MAGNETIC,KEYED
37	1	715614	ROD, ECCENTRIC IDLER, LONG	75	1	C07220	ACTUATOR, MAGNET
38	1	715615	ECCENTRIC, IDLER SHAFT, SHORT				

\*NOT SHOWN 4

Seeder Hopper Main Assembly 211109 Rev B






#### Hopper Agitator Assembly 211109 Rev B


ITEM #	QTY.	PART#	DESCRIPTION
1	6	113646	WASHER BELLEVILLE SPRING
2	1	119534	FITTING,CONN,1/8MPT X 1/4T,ENP,Q.R.
3	1	174049	FITTING,ELL,1/8MPT X 1/4T,Q.R,SHORT
4	1	304280	A/W, MOUNT CYLINDER AGIT, 9840
5	1	304284	BRACKET, SLIDE MOUNT AGIT, 9940
6	1	304285	BRACKET, SLIDE MOUNT AGIT, 9940
7	1	304610	SHAFT, AGITATOR CONNECTOR
8	1	304611	SEAL, HOPPER AGITATOR
9	1	610504	SPRING,COMP .88 OD X .067 WD X 1.5 FL
10	1	610885-02	TUBING, 1/4" POLYURETHANE, BLUE
11	1	610885-04	TUBING, 1/4" POLYURETHANE, RED
12	1	611366	CYLINDER, AIR, 1" BORE, 1" STRK, MAG
13	1	716122	A/W, DUAL AGITATOR RAKE, 9850
14	2	955379	NUT HEX 1/4-20 UNC SST
15	1	955620	NUT HEX NYLOC 3/8-16 UNC SST
16	6	955661	NUT HEX NYLOC 1/4-20 UNC SST
17	1	955939	WASHER, LOCK 5/16" SST
18	3	955975	WASHER FLAT 3/8" SST
19	1	955976	WASHER FLAT 5/16 SST
20	4	955977	WASHER FLAT 1/4" SST
21	1	971804	SCREW SET SOC #10-24 UNC X 1/4 SST
22	2	975008	SCREW SHLDR 5/16 X 1/2, 1/4-20 SST
23	1	988916	SCREW FIN HEX 3/8-16 X 1 SST
24	2	988924	SCREW FIN HEX 3/8-16 X 1 1/2 SST
25	1	989720	SCREW FIN HEX 5/16-18 X 1 1/4 SST
26	4	989928	SCREW FIN HEX 1/4-20 X 1 3/4 SST
27	4	A04348	BLOCK, BEARING, SEEDER

Hopper Agitator Assembly 211109 Rev B



# Hopper Deflector Assembly 211109 Rev B


	ITEM #	QTY.	PART#	DESCRIPTION
	1	1	111937	PIVOT BRACKET CYLINDER (PKG)
	2	1	119534	FITTING,CONN,1/8MPT X 1/4T,ENP,Q.R.
	3	1	152074	ROD END, BEARING 1/4"
	4	1	174049	FITTING,ELL,1/8MPT X 1/4T,Q.R,SHORT
	5	1	301406	CYLINDER, AIR, 3/4" BORE, 2" STROKE
	6	1	304130	BLOCK CYL MOUNT DEFL. 9840
	7	2	304192	COLLAR PIVOT DEFLECTOR 9840
	8	2	304193	PLATE, SWIVEL DEFLECTOR
	9	1	610885-02	TUBING, 1/4" POLYURETHANE, BLUE
	10	1	610885-04	TUBING, 1/4" POLYURETHANE, RED
	11	1	716119	A/W, DEFLECTOR, 9850/9950
	12	1	955661	NUT HEX NYLOC 1/4-20 UNC SST
	13	5	955940	WASHER LOCK 1/4" SST
	14	4	955978	WASHER FLAT #10 SST
	15	2	971208	SCREW SET SOC 1/4-20 UNC X 1/2 SST
	16	4	971804	SCREW SET SOC #10-24 UNC X 1/4 SST
	17	4	978308	SCREW SOC HD CAP 1/4-20 X 1/2 SST
	18	4	978908	SCREW SOC HD CAP #10-24 UNC X 1/2 SST
	19	1	989920	SCREW FIN HEX 1/4-20 X 1 1/4 SST
	20	1	C02463	TRIP COLLAR
ĺ	21	4	955941	WASHER LOCK #10 SST



# Dump Vibrator Assembly 304497 Rev B


QTY.	ITEM	PART #	DESCRIPTION
1	1	03-MI9200-002	INST HOPPER MOD FOR DUAL AIR VIB
2	2	301455	VIBRATOR-AIR US13
3	2	111497	MUFFLER 1/8 NPT
4	1	610531	FITTING, 1/4"Y", Q.R.
5	1	A06905	FITTING, NIPPLE, HEX, 1/8 NPTM, SST
6	4'	610885-05	TUBING, 1/4" POLYURETHANE, YELLOW
7	2	119534	FITTING,CONN,1/8MPT X 1/4T,ENP,Q.R.
8	1	C00924	FITTING,TEE,1/8 NPTF,SST
9	1	401302	VALVE, REG, FLOW CONTROL, ENP, Q.R.
10	4	989716	SCREW 5/16-18 N.C. X 1 SS
11	4	955619	NUT HEX NYLOC 5/16-18 UNC SST
12	1	174049	FITTING,ELL,1/8MPT X 1/4T,Q.R,SHORT

# Dump Vibrator Assembly



#### Hopper Enclosure Assembly 210386-003 Rev A


ITEM #	QTY.	PART#	DESCRIPTION
1	1	113315	DECAL,24 VOLTS
2	2	174049	FITTING,ELL, 1/8MPT X 1/4T, Q.R, SHORT
3	1	303056	PLUG, HOLE, SST 7/8" DIA
4	7"	610360	TERMINAL, DIN RAIL, MINI
5	27	610361	TERMINAL, BLOCK, MINI
6	2	610362	TERMINAL,END COVER,MINI
7	2	610363	TERMINAL, ANCHOR, END CLAMP, MINI
8	1.5	610364	TERMINAL, JUMPER, 10-POLE, MINI
9	6	610459	FITTING, BULKHEAD UNION 1/4T, ENP
10	2'	610885-04	TUBING, 1/4" POLYURETHANE, RED
10	1	610534	TERMINAL, GROUNDING, MINI
11	2'	610885-02	TUBING, 1/4" POLYURETHANE, BLUE
13	2'	610885-07	TUBING, 1/4" POLYURETHANE, CLEAR
14	1	610952	CONNECTOR, SEAL INSERT, . 160 4 HOLES
15	1	610953	CONNECTOR, CORD, .2035, DOME, NYLON
16	1	610954	CONNECTOR, CORD, .3956, DOME, NYLON
17	3	610955	CONNECTOR, SEAL RING, 1/2NPT, POLYETH
18	4	610966	FITTING,CONN,1/8NPT x 1/4T, Q.R.,HEX
19	1	610969	CONNECTOR, CORD, 3/16-5/16 STR, NYLON
20	1	610974	CONNECTOR,LOCKING-NUT,3/8NPT,NYLON
21	1	610975	CONNECTOR 0-RING 3/8 NPT .51 OD .06 THK
22	1	611364	VALVE, MANIFOLD, 2 STATION, 1/8"NPT PORTS
23	2	611365	VALVE,SOL,2-WAY,w/ FLOW CNTRLS
24	1	611371	MEMBRANE VENT, .413"
25	1	611372	NUT, BACKING, MEMBRANE VENT
26	1	715536-001	RWK, ENCLOSURE, 9.84x7.87x 3.98 (611875)
27	3	C00174	LOCKING NUT, 1/2 NPT, NYLON
28	2	C00916	FITTING,PLUG,1/8 NPTM,SST
29	4	C05724	VARISTOR,SURGE,125A,25VAC,31VDC
30	6'	C07066	CABLE,22AWG,25 COND
31	2	978820	SCREW SOC HD CAP #10-32 UNF X 1 1/4" SST
32	3	955936	WASHER LOCK #6 SST
33	3	999504	SCREW RD HD SLOT #6-32 X 1/4 SST



13

#### Hopper Height Adjust Assembly 210384 Rev B


ITEM #	QTY.	PART#	DESCRIPTION
1	5'	142113	CABLE, 16AWG, 4 COND
2	1'	303631	CHAIN LINK #35 ROLL NICKEL PLATE
3	1	152175	CHAIN LINK #35 CONNECTING
4	1	304123-001	GEARMOTOR, 1/8HP, 100RPM, 3.6:1 RATIO
5	1	611469-010	ENCODER, 3/8 BORE, IP64,10CPR,SMJ
6	1	C06754-002	SENSOR, CABLE M12,5WIRE,F,QC,90,SH
7	1	610954	CONNECTOR, CORD,.3956, DOME, NYLON
8	1	610955	CONNECTOR,O RING,1/2NT,BUNA-N
9	1	712026	SPROCKET, REWORK, 35B14 5/8 BORE
10	1	712027	BRACKET, MOTOR MT, HEIGHT ADJ, 9840S
11	1	C00174	CONNECTOR, LOCKING NUT, 1/2NPT, NYLON
12	4	955661	NUT HEX NYLOC 1/4-20 UNC SST
13	2	955939	WASHER LOCK 5/16 SST
14	2	955976	WASHER FLAT 5/16 SST
15	4	955977	WASHER FLAT 1/4 SST
16	2	971808	SCREW SET SOC 10-24 X 1/2 SST
17	4	989610	SCREW FIN HEX 5/16-24 X 5/8 SST
18	4	989964	SCREW FIN HEX 1/4-20 X 4 SST



# Seeder Pneumatic System 210385 Rev D

1	36	110417	FITTING, STREET ELL, 1/4M X 1/4F, BRS
1	35	610673	FITTING "Y" 3/8 X 1/4 2X QR
4	34	610602	FITTING, ELL, 1/4NPT X 1/4T, ENP, Q.R.
2	33	C00916	FITTING, PLUG, 1/8 NPTM, SST
1	32	611364	VALVE, MANIFOLD, 2 STATION, 1/8" PORT
1	31	712305	A/W, AUTO FILL Q.C. MOUNT
1	30	611117	VALVE,SOL,24V,2 WAY,1/4P
4	29	610505	FITTING, ELL, 1/4NPT X 3/8T, Q.R
1	28	A06858	FITTING, TEE, 1/4 NPTF, SST
1	27	118872	FITTING,QC,BODY,AIR,1/4 NPTF,BRS
1	26	110423	FITTING,PLUG,1/4 NPTM,BRS
1	25	110414	FITTING, NIPPLE, HEX, 1/4 NPTM, BRS
1	24	C03335	PLATE, FRL MOUNTING
1	23	C00398-002	PORTING BLOCK INSERT KIT
1	22	C00905	FITTING, NIPPLE, 1/4 NPTM X 2, SST
1	21	C00404	F.R.L. COMBO, 1/4 NPTF, 72 SERIES
30'	20	610885-07	TUBING, 1/4" POLYURETHANE, CLEAR TUBING, 3/8" POLYURETHANE, CLEAR
20'	19	610886-07	TUBING, 3/8" POLYURETHANE, CLEAR
25'	18	610885-04	TUBING, 1/4" POLYURETHANE, RED
7'	17	610885-02	TUBING, 1/4" POLYURETHANE, BLUE
4	16	610966	FITTING, CONN, 1/8NPT X 1/4T, Q.R., HEX
1	15	611119	VALVE,SOL,24V,3 WAY,CLOSED CEN,1/4P
2	14	611365	VALVE,SOL,24VDC,2-WAY,W/FLOW CTRLS
1	13	210446	ASSY, CYLINDER, HOPPER DUMP
1	12	611363	VALVE, MANIFOLD, BLANK PLATE (611364)
3	11	610956	FITTING, BLKHD ELL 1/4T, ENP, Q.R.
2	10	610507	FITTING, CONN, 1/4NPT X 3/8T, ENP, Q.R.
6	9	610459	FITTING, BULKHEAD UNION 1/4T, ENP
2	8	401302	VALVE, REG, FLOW CONTROL, ENP, Q.R.
4	7	401152	FITTING, CONN, 1/4MPT X 1/4T ,ENP, Q.R.
1	6	611366	CYLINDER AIR 1 1/16 BORE 1" STR MAG
1	5	301406	CYLINDER, AIR, 3/4" BORE, 2" STROKE
2	4	174049	FITTING, ELL, 1/8MPT X 1/4T, Q.R, SHORT
-1	3	119534	FITTING, CONN, 1/8MPT X 1/4T, ENP, Q.R.
1	2	111498	FITTING, MUFFLER, 1/4 NPTM, BRS
4	1	111497	FITTING, MUFFLER, 1/8 NPTM
QTY	ITEM	PART #	DESCRIPTION

#### Seeder Pneumatic System 210385 Rev D




#### Water Spray/Split Frame Assembly (MOD) 210766-001 Rev F

ITEM #	QTY.	PART#	DESCRIPTION	ITEM #	QTY.	PART#	DESCRIPTION
1	1	210391-002	ASSY, CIRCUIT, WATER, DUAL SPRAY/SPLIT	29	2	715665	BLOCK, WATER SPRAY, BEARING MT.
2	2	210397-003	ASSY, SENSOR, PANCAKE PROX.	30	2	715666	BRACKET, ENCLOSURE MOUNT, WATER
3	1	118568-800	ASSY, ENCLOSURE WATER, SPRAY/SPLIT	31	1	715668	A/W, MANIFOLD, WATER 8 NOZ, R/H
4	REF.	210389-PWM	ASSY, PULSATING SPRAY GUN	32	2	716159	PLATE, SPLASH GUARD, WATER SPRAY
5	REF.	211099	ASSY, NOZZLE, WATER SPLITTER, 9840	33	4	716468	CHANNEL, WORM GEAR END PLATE
6	2	304830	A/W, ANGLE MOUNT, 9840	34	3	955619	NUT HEX NYLOC 5/16-18 UNC SST
7	2	304831	A/W, ANGLE MOUNT, 9840S	35	8	955621	NUT HEX NYLOC #10-24 UNC SST
8	16	610169	SENSOR,BULKHEAD,M12,5 WIRE,F,QC	36	20	955661	NUT HEX NYLOC 1/4-20 UNC SST
9	2	610967	TERMINAL,STRIP,BREAK-A-PART,MINI 12	37	6	955937	WASHER LOCK 1/2 SST
10	2	610969	CONNECTOR, CORD, 3/16-5/16 STR, NYLON	38	16	955938	WASHER, LOCK 3/8" SST
11	4	611237	BEARING, 5/8 PILLOW BLOCK, SST	39	24	955939	WASHER, LOCK 5/16" SST
12	8	611238	BEARING, 5/8, 2 BOLT FLANGE, SST	40	8	955942	WASHER LOCK #8 SST
13	4	611534	GASKET, TERMINAL MANIFOLD COVER	41	8	955975	WASHER FLAT 3/8" SST
14	8	612307	GUARD, WORM GEAR HOUSING	42	9	955976	WASHER FLAT 5/16 SST
15	4	711933	BLOCK, INNER CHASSIS, HEIGHT ADJ.	43	8	978916	SCREW SOC HD CAP #10-24 UNC X 1 SST
16	4	711934	SHAFT, INNER CHASSIS, HEIGHT ADJ.	44	8	979506	SCREW SOC HD CAP #8-32 UNC X 3/8 SST
17	4	711938	RWK, WORM GEAR	45	2	988316	SCREW FIN HEX 1/2-13 X 1 SST
18	4	711939	RWK, WORM STEEL, 5/8" B, 10 D.P.	46	4	988910	SCREW FIN HEX 3/8-16 X 5/8 SST
19	4	712058	PLATE, TERMINAL MANIFOLD COVER	47	8	988920	SCREW FIN HEX 3/8-16 X 1 1/4 SST
20	4	712078	PLATE, MANIFOLD MNT. MAIN	48	4	988956	SCREW FIN HEX 3/8-16 X 3 1/2 SST
21	2	712080	SHAFT, HEIGHT ADJUSTMENT, WATER	49	24	989712	SCREW FIN HEX 5/16-18 X 3/4 SST
22	1	118568-025	A/W, UPRIGHT, WATER SPRAY FRAME	50	8	989716	SCREW FIN HEX 5/16-18 X 1 SST
23	2	715639	ANGLE, SPRAY/SPLIT, MANIFOLD MT, TOP	51	2	989744	SCREW FIN HEX 5/16-18 X 2 3/4 SST
24	1	715641	A/W, UPRIGHT, WATER SPRAY FRAME	52	4	989910	SCREW FIN HEX 1/4-20 X 5/8 SST
25	1	715643	A/W, TOP CROSS SUPPORT, WATER FRAME	53	16	989916	SCREW FIN HEX 1/4-20 X 1 SST
26	2	715645	A/W, SPRAY MANIFOLD BEARING MT, LWR	54	2	A05584	PLATE-SERIAL NUMBER
27	2	715647	A/W,SPRAY MANIFOLD BEARING MT, LWR	55*	1	118568-021	AW,MANIFOLD,WATER 14 NOZ
28	1	715662	A/W, BASE WATER SPRAY 46"	56*	4	118568-024	BRACKET,ENCL MNT, WATER SPRAY

17 \*NOT SHOWN 18

# Water Spray/Split Frame Assembly (MOD) 210766-001 Rev F



19

#### Pan Sensor Assembly 210397-003 Rev B

ITEM #	QTY.	PART#	DESCRIPTION
1	1	304430	CABLE, SENSOR, M12, 5WIRE, F, QC, STR
2	1	715600	PLATE, PROX. MNT.
3	1	715601	BRACKET, PROX. MNT
4	4	955621	NUT HEX NYLOC #10-24 UNC SST
5	2	955661	NUT HEX NYLOC 1/4-20 UNC SST
6	2	955977	WASHER FLAT 1/4" SST
7	4	982324	SCREW FLT HD SOC #10-24 X 1 1/2 SST
8	2	989914	SCREW FIN HEX 1/4-20 X 7/8 SST
9	1	C06752	SENSOR,PROX,80MM,10-55VDC,NPN,EDDY


#### Splitter Nozzle Assembly 211099 Rev B

ITEM #	QTY.	PART#	DESCRIPTION
1	1	211100	ASSY, NOZZLE MOUNT (612008)
2	1	304208	ADJUSTABLE HANDLE 1/4-20 THREAD
3	1	401152	FITTING,CONN,1/4MPT X 1/4T,ENP,Q.R.
4	1	610187-002	CABLE,MICRO-CHANGE,M12,5WIRE,SPRAYM
5	1	610885-05	TUBING, 1/4" POLYURETHANE, YELLOW
6	1	610966	FITTING,CONN,1/8NPT x 1/4T, Q.R.,HEX
7	1	612008	VALVE,SOL SS 1/8NPT 2 WAY 24VDC
8	1	612018	TIP, SPLIT, BETE, .020", 1/8" NPT
9	1	955409	NUT JAM 1/4-20 UNC
10	1	955940	WASHER LOCK 1/4" SST
11	1	955977	WASHER FLAT 1/4" SST
12	2	MC0320	SCREW, FLAT HD, 3 X 20 MM


#### Pulsating Spray Gun Assembly 210389-PWM Rev B

ITEM #	QTY.	PART#	DESCRIPTION
1	1	119534	FITTING,CONN,1/8MPT X 1/4T,ENP,Q.R.
2	1	210379-PWM	ASSY, NOZZLE MOUNTING BLOCK
3	1	304208	ADJUSTABLE HANDLE 1/4-20 THREAD
4	1	401152	FITTING,CONN,1/4MPT X 1/4T,ENP,Q.R.
5	1'	610885-05	TUBING, 1/4" POLYURETHANE, YELLOW
6	1	611574	VALVE, PULSAJET GUN
7	1	955409	NUT HEX JAM 1/4-20 UNC SST
8	1	955940	WASHER LOCK 1/4" SST
9	1	955977	WASHER FLAT 1/4" SST
10	2	982912	SCREW FLT HD SOC #8-32 X 3/4 SST
11	1	C00506	RETAINER CAP CP1325-NP
12	1	C00565	TIP #650017 SS TEE JET
13	1	C07663	FIELD ATTACH, M12,5 WIRE,MALE


#### Pan Sensor Assembly 210397-003 Rev B



Splitter Nozzle Assembly 211099 Rev B




Pulsating Spray Gun Assembly 210389-PWM Rev B



21

#### Spray/Split Frame Height Adjust 210768-003 Rev B

ITEM #	QTY.	PART#	DESCRIPTION
1	1	304123-001	MOTOR,GEAR,1/8HP,200/230-50/6,3.6:1
2	2	304219	SPROCKET,RWK,25-B-24 1.104 BORE
3	2	304238-001	CLUTCH,24 VDC,9840
4	4	304350-001	SENSOR,PROX,8MM,10-30V,PNP,NC,TURCK
5	1	304350-003	SENSOR,PROX,8MM,10-30V,PNP,NC,TURCK
6	1	712075	BRACKET, ENCODER MOTOR H2O
7	1	712076	SPROCKET, MOTOR H2O
8	2	712082-001	PLATE, SENSOR MNT.
9	1	715650	A/W, HOME SENSOR/CLUTCH TAB
10	1	715651	PLATE, OVERTRAVEL SENSOR MT
11	2	715653	BLOCK, SPACER, WATER SPRAY SENSOR
12	1	715654	A/W, MOTOR MOUNT, WATER
13	1	715657	A/W, CHAIN COVER FRONT, WATER
14	1	715661	BRACKET, MOTOR MNT SUPT
15	2	C05448	COLLAR,1/2" SET,SST
16	5	C07626	SENSOR,CABLE,M8,3WIRE,F,QC,90




23

# Conduit Assembly

ITEM #	QTY.	PART#	DESCRIPTION
1	4	118568-007	BAR, CONDUIT CLAMP
2	1	118568-031	CONDUIT, 1" RIGID, THREADED X 4.25"
3	1	118568-032	CONDUIT, 1" RIGID, THREADED X 12.50"
4	1	118568-400	CONDUIT, TEE, 1" NPT, FEMALE, ZP
5	4	118568-401	CONDUIT CLAMP, 1" RIGID, SST
6	1	118568-403	FITTING, COUPLING, 1" NPS, ALUM
7	2	715629-0425	CONDUIT, 1" RIGID, THREADED X 4.25"
8	1	715629-0950	CONDUIT, 1" RIGID, THREADED X 9.50"
9	1	715629-1925	CONDUIT, 1" RIGID, THREADED X 19.25"
10	1	715629-4800	CONDUIT, 1" RIGID, THREADED X 48.00"
11	1	C00173	CONDUIT,1" NON-METALLIC
12	1	C00181	CONNECTOR, CONDUIT, 1/2 STR, NYLON
13	1	C00182	CONNECTOR, CONDUIT, 1"-90 NYLON
14	2	C00887	CONNECTOR, CONDUIT, 1"HUB
15	4	C00892	CONNECTOR, CONDUIT, 1"PULL-ELBOW

Conduit Assembly 118568-105




#### FD1150 Assembly 211400-050 Rev A

ITEM #	OTY	PART#	DESCRIPTION	ITEM #	OTY	PART #	DESCRIPTION
]	1	103478	SPROCKET IDLER, 35-A-15 3/8" BORE	43	1	717621	MOTOR PLATE LH
2	1	114055	SPROCKET, 41-B-30, 3/4" B	44	1	717623	A/W, GUARD LH
3	4	152074	ROD END, BEARING 1/4"	45	1	717625	A/W, CATCH PAN LH
4	2.50'	152169	DRIVE CHAIN	46	1	717626	ANGLE BRACKET LH
5	1	152175	CHAIN LINK #35 CONNECTING N.P.	47	1	955405	NUT HEX JAM 3/8-16 UNC SST
6	1	211372	HOUSING AND BEARING	48	1	955407	NUT HEX JAM 5/16-18 UNC SST
7	1	303000	LABEL.BURFORD LOGO.4.25 SCRIPT	49	1	955620	NUT HEX NYLOC 3/8-16 UNC SST
8	1	304430	CABLE,SENSOR,M12,5WIRE,F,QC,STR	50	2	955621	NUT HEX NYLOC #10-24 UNC SST
9	1	304431	CABLE,SENSOR,M12,5WIRE,F,QC,90	51	4	955625	NUT HEX NYLOC #8-32 UNC SST
10	1	610858	WELL, 30MM SENSOR MNT, DELRIN	52	8	955661	NUT HEX NYLOC 1/4-20 UNC SST
11	1	611027	SENSOR,PHOTO,DIFFUSE,500MM,10-30V,QC	53	25	955940	WASHER LOCK 1/4" SST
12	1		BRUSH, FLOUR DUSTER 50"	54	2	955941	WASHER LOCK #10 SST
13	1	612331	STRAIGHT LINE ACTION CLAMP	55	1	955975	WASHER FLAT 3/8" SST
14	1	711570	BRACKET PHOTOEYE DUSTER	56	1	955976	WASHER FLAT 5/16 SST
15	2	711726	BUSHING DELRIN SHAFT PIVOT FD200	57	6	955977	WASHER FLAT 1/4" SST
16	5	714312	AUGER, SPLIT COLLAR RIGHT	58	11	955978	WASHER FLAT #10 SST
17	5	714313	AUGER, SPLIT COLLAR LEFT	59	6	955979	WASHER FLAT #8 SST
18	1	715595	PLATE, TAPPED, LASER BACKUP MT	60	1	958712	PIN, ROLL, 5/16" DIA X 3/4", SST
19	2	716855	SPACER, COLLAR, FD300	61	2	971210	SCREW SET SOC 1/4-20 UNC X 5/8 SST
20	1	717321	TORQUE SHAFT END SUPPORT	62	2	974904	SCREW SHLDR 1/4 X 1/4, #10-24 SST
21	1	717323	MAIN LINK	63	2	975006	SCREW SHLDR 5/16 X 3/8, 1/4-20 SST
22	1	717326	IDLER SPACER	64	1	975106	SCREW SHLDR 3/8 X 3/8, 5/16-18 SST
23	2	717328	LINKAGE ROD	65	4	975210	SCREW SHLDR 1/2 X 5/8, 3/8-16 SST
24	1	717329	SPROCKET-35B20 15MM BORE, RWRK	66	2	976016	SCREW SOC HD CAP #4-40 X 1 SST
25	1	717330	SPROCKET, 35B18, 1.125 BORE	67	3	977732	SCREW SOC HD CAP 5/16-18 x 2 SST
26	1	717332	BLOCK MOUNT	68	22	978308	SCREW SOC HD CAP 1/4-20 X 1/2 SST
27	1	717340	NON-MOTOR END PLATE	69	1	978312	SCREW SOC HD CAP 1/4-20 X 3/4 SST
28	1	717341	MOTOR END PLATE	70	2	978320	SCREW SOC HD CAP 1/4-20 X 1 1/4 SST
29	1	717342	END PLATE	71	10	978908	SCREW SOC HD CAP #10-24 UNC X 1/2 SS1
30	1	717347	SIDE BLOCK	72	4	978916	SCREW SOC HD CAP #10-24 UNC X 1 SST
31	1	717348	END BLOCK	73	4	979516	SCREW SOC HD CAP #8-32 UNC X 1 SST
32	1		A/W PANEL, FRONT, FD1050	74	8	981616	SCREW FLT HD SOC 5/16-18 UNC X 1 SST
33	1		PANEL, REAR, FD1050	75	2	981732	SCREW FLT HD SOC 1/4-20 X 2 SST
34	1		A/W, AUGER W CHURN, FD1050	76	2	982306	SCREW FLT HD SOC #10-24 X 3/8 SST
35	1		A/W, HINGED PANEL, FRONT, FD1050	77	4	982912	SCREW FLT HD SOC #8-32 X 3/4 SST
36	1		A/W, LEVER ARM, FD1050	78	2	987504	SCREW BUTT HD SOC #6-32 X 1/4 SST
37	2		TEMPLATE MTG. BAR	79	1	988928	SCREW FIN HEX 3/8-16 X 1 3/4 SST
38	1	717360	END BEARING	80	6	989916	SCREW FIN HEX 1/4-20 X 1 SST
39	1	717362	A/W, CLEVIS	81	1	A05584	PLATE-SERIAL NUMBER
40	1		ROD INNER HOPPER EXT.	82	1		SENSOR, PROX, CAPAC, 30MM, 24V, PNP, NC
41	1		COVER, FD1150 DUSTER	83	1	C07678	SENSOR, INTLK, CODED MAGNETIC SAFETY
71	1	717304-030	BLOCK, SIDE ALIGN	84	4	MA0690	SCREW, FIN HEX, 6 X 90 MM

26


# FOLD OUT TO VIEW DRAWING



# Duster Conveyor Mount 211375-050 Rev B

ITEM #	QTY.	PART#	DESCRIPTION
1	4	712781	COLLAR, HALF REWORK, 1-1/2 SPLIT, SST
2	2	716079	PLATE CLAMPING BAR CONV MOUNT
3	1	716084	A/W, CONV. MNT, EL90 32-45"
4	1	716090	A/W, CONV. MNT, EL90 32"-45"
5	1	717288-050	BAR, FD1X50 CONV. CROSS MOUNT
6	8	955619	NUT HEX NYLOC 5/16-18 UNC SST
7	6	955939	WASHER, LOCK 5/16" SST
8	8	978332	SCREW SOC HD CAP 1/4-20 X 2 SST
9	8	989716	SCREW FIN HEX 5/16-18 X 1 SST
10	6	989724	SCREW FIN HEX 5/16-18 X 1 1/2 SST

# FOLD OUT TO VIEW DRAWING





## MPA Frame Mount Assembly 210443-008 Rev E

ITEM #	QTY.	PART #	DESCRIPTION
1	3	110423	FITTING, 1/4" NPT PLUG
2	4	111497	MUFFLER, 1/8" NPT
3	REF.	210430	ASSY, MPA-100, AUTO-FILL, 110V
4	REF.	210450	ASSY,MPA-100 AUTO-FILL,220VAC MOTOR
5	1	304268	BLOCK, 30MM, PROX MT, AUTO-FILL, 9840
6	1	304430	CABLE,SENSOR,M12,5WIRE,F,QC,STR
7	1	304431	CABLE,SENSOR,M12,5WIRE,F,QC,90
8	1	305772	INLET TUBE REWORK MPA-100
9	1	401152	FITTING,CONN,1/4MPT X 1/4T,ENP,Q.R.
10	1	610295	SENSOR,PROX,18MM,10-30VDC,PNP,N.O.
11	1	610507	FITTING,CONN,1/4NPT X 3/8T,ENP,Q.R.
12	2	610531	FITTING, 1/4"Y", Q.R.
13	3	610602	FITTING, ELL, 1/4NPT X 1/4T,ENP,Q.R
14	1	610673	FITTING "Y" 3/8 X 1/4 2X QR
15	1	610739	PLC,ML1500,I/O MODULE 6IN/4OUT
16	10'	610885-07	TUBING, 1/4" POLYURETHANE, CLEAR
17	15'	610886-07	TUBING, 3/8" POLYURETHANE, CLEAR
18	3	610954	CONNECTOR, CORD, .3956, DOME, NYLON
19	3	610955	CONNECTOR, SEAL RING, 1/2NPT, POLYETH
20	5'	611047	HOSE, 12" ID CLEAR VIEW, PVC
21	2	611051	HOSE CLAMP, 12"
22	2	611117	VALVE,SOL,24V,2 WAY,1/4P
23	REF	611950	VACUUM MOTOR 110V( MPA)
24	REF	611951	VACUUM MOTOR 220V ( MPA)
25	1	712432	A/W, MPA-100 SUPPORT FRAME, 9840S
26	2	712438	BLOCK, VAC. FRAME SPACER
27	REF.	712444	A/W, HOPPER COVER, 9840S / MPA-100
28	4	714312	AUGER, SPLIT COLLAR RIGHT
29	4	714313	AUGER, SPLIT COLLAR LEFT
30	2	955618	NUT HEX NYLOC 1/2-13 UNC SST
31	8	955619	NUT HEX NYLOC 5/16-18 UNC SST
32	2	988356	SCREW FIN HEX 1/2-13 X 3 1/2 SST
33	4	989732	SCREW FIN HEX 5/16-18 X 2 SST
34	4	989740	SCREW FIN HEX 5/16-18 X 2 1/2 SST
35	1	A05038	BRACKET, PROXIMITY MTG.
36	1	A05584	PLATE-SERIAL NUMBER
37	3	C00174	LOCKING NUT, 1/2 NPT, NYLON
38	1	C00398-002	PORTING, BLOCK INSERT KIT, 1/4NPT
39	1	C07626	SENSOR, CABLE, M8, 3WIRE, F, QC, 90
40	) DEE	C07670	SENSOR, CAPACITIVE, 30MM, DC, PNP-N/C
41*	REF.	C00892	CONNECTOR, CONDUIT, 1"PULL-ELBOW
42*	REF.	C00887	CONNECTOR, CONDUIT, 1"HUB
43*	REF.	715599	BRACKET, JUNCTION BOX MNT
44*	REF.	715611	REWORK, JUNCTION BOX, MPA
45*	REF.	715629-0950 715629-1928	CONDUIT, 1" RIGID, THREADED, 9.50"
46*	REF.		CONDUIT, 1" RIGID, THREADED, 19.25"
47*	REF.	174049	FITTING,ELL,1/8MPT X 1/4T,Q.R,SHORT


29 \*NOT SHOWN 30

## MPA Frame Mount Assembly 210443-008 Rev E





#### IN MAIN ENCLOSURE



SCALE 1:8

## HS-300 Assembly 306102 Rev E

ITEM #	QTY.	PART#	DESCRIPTION
1	1	211240	KIT MPHS-300/500
2	1	306100	HOPPER HS-300

## MPHS-300/500 Kit 211240 Rev C

ITEM #	QTY.	PART#	DESCRIPTION
1	1	611014	LANYARD, QUICK RELEASE PIN, CABLE
2	1	611097	CLAMP, TRI-CLOVER, 2 1/2"
3	1	611098	GASKET 2 1/2"
4	1	611285	CLAMP, HEAVYWEIGHT, 2"
5	1	612039	LANYARD, CABLE 6"
6	1	712514	PLATE DOWN TUBE MPH300
7	1	712516	A/W CONNECTOR HOPPER
8	1	716539	END CAP SOLID 2 1/2 RWK
9	1	716702	WAND PICK UP
10	4	955940	WASHER LOCK 1/4" SST
11	1	955941	WASHER LOCK #10 SST
12	4	955977	WASHER FLAT 1/4" SST
13	2	971204	SCREW SET SOC 1/4-20 UNC X 1/4 SST
14	2	971210	SCREW SET SOC 1/4-20 UNC X 5/8 SST
15	1	978906	SCREW SOC HD CAP #10-24 UNC X 3/8
16	4	989920	SCREW FIN HEX 1/4-20 X 1 1/4 SST
17	1	C00532	CAP # 16AMP-2 2"
18	1	C01005	GASKET 2"


## MPA Connecting Hose 210438-020 Rev B


ITEM #	QTY.	PART#	DESCRIPTION
1	2	268074	CLAMP HOSE 1 1/2 TO 3/4
2	20'	305084	HOSE, POLYWIRE, VAC TRANSFER 1.5 ID
3	1	712517	A/W CONNECTOR HOPPER


## HS-300 Assembly 306102 Rev E


#### MPHS-300/500 Kit 211240 Rev C


## MPA Connecting Hose 210438-020 Rev B















## Pump Cart Assembly C0600801 Rev R

ITEM #	QTY	PART#	DESCRIPTION
]	23'	103878	HOSE. AIR 1/4" DIA NEOPRENE
2	1	118871	FITTING,QC,STEM,AIR,1/4 NPTM
3	1	303674	GAUGE 0-200 PSI 1/4 NPT BACK MT SST
4	1	305716	FLOAT VALVE MINI ADJ 1/2"
5	2	610505	FITTING, ELL, 1/4NPT X 3/8T, ENP, Q.R
6	3'	610886-07	TUBING, 3/8" POLYURETHANE, CLEAR
7	1	611121	PUMP, AIR POWERED DBL DIAPHRAGM
8	6	611343	FITTING, ELL, 1/2NPT X 1/2, ENP, Q.R.
9	5'	611350-05	TUBING,1/2" POLYURETHANE,YELLOW
10	1	713714	REGULATOR BRACKET, PUMP CART
11	2	955409	NUT HEX JAM 1/4-20 UNC SST
12	2	955619	NUT HEX NYLOC 5/16-18 UNC SST
13	28	955661	NUT HEX NYLOC 1/4-20 UNC SST
14	2	955976	WASHER FLAT 5/16 SST
15	30	955977	WASHER FLAT 1/4" SST
16	2	989710	SCREW FIN HEX 5/16-18 X 5/8 SST
17	8	989910	SCREW FIN HEX 1/4-20 X 5/8" SST
18	20	989912	SCREW FIN HEX 1/4-20 X 3/4" SST
19	2	989956	SCREW FIN HEX 1/4-20 X 3 1/2 SST
20	4	A04225	CASTER, 3" LOCKING/SWIVEL, 145#
21	1	A06856	FITTING, REDUCING ELL 1/2F X 3/8M SS
22	2	A06859	FITTING, 1/2MPT X 1/2 TUBE
23	1	A07726	FITTING, PLUG 1/2" PVC
24	2	C00414	CLAMP 1/4" TO 5/8" SST
25	2	C00415	CLAMP #6 STAINLESS HOSE
26	24'	C00435	HOSE, 1/2" VINYL W/ POLYESTER
27	1	C00537	REGULATOR, AIR, 1/4 NPT PORTS
28	1	C00578	FILTER, WATER, 3/4" NPTF
29	1	C00579	FILTER REPLACEMENT # AP110
30	1	C00900	FITTING,COUPLING,1/4 NPTF,SST
31	4	C01013	FITTING, REDUCER, 3/4MPT X 1/2FPT, SST
32	1	C01018	FITTING,NIPPLE,HEX,1/2 NPTM,SST
33	1	C01958	FITTING,REDUCER, 1" MPT X 3/8FPT,SST
34	1	C03613	FITTING,COUPLING,1/2 NPTF,SST
35	1	C05339	FITTING, REDUCER, 1" x 1/2" PVC
36	1	C05431	VALVE, 1/2 NPT 2-WAY, BALL, SST
37	2	C05576	FITTING, 1/2 NPT BULKHEAD, PL.
38	1	C06171	TANK, WATER RECHARGER
39	1	C06174	FITTING, BULKHEAD 1" POLY
40	1	C06176	RWK, TANK & COVER
41	1	C06183	TEE MOUNT A/W
42	1	C06195	PLATE, COVER CLAMP
43	1	C06196	BRACKET, UPPER TANK
44	1	C06200	A/W, TANK BASE
45	1	C07623	QUICK CONNECT BODY, 1/2 MPT
46	2	C01953	FITTING,HOSE BARB,1/4MPT X 1/4H,SST




#### MPAS Vibrator Kit 211136 Rev B

ITEM #	QTY.	PART#	DESCRIPTION
1	1	113393	PLUG MALE 3 POLE TWIST LOCK
2	2	142007	CABLE, 16AWG, 3 COND., BLACK CORD
3	REF.	306102	HOPPER ASSEMBLY MPHS-300
4	2	612297	VIBRATOR 115V NEA5050
5	8	955941	WASHER LOCK #10 SST
6	8	955978	WASHER FLAT #10 SST
7	8	978912	SCREW SOC HD CAP #10-24 UNC X 3/4 SST
8	1	A05379	PLUG FEMALE 3 POLE TWIST LOCK
9	1	C07644	COVER, WEATHER PROOF - 113393
10	1	C07645	COVER, WEATHER PROOF - A05379


36

FOLD OUT TO VIEW DRAWING




## Conveyor Components 118568-100

10 1 118568-020 COVER, ENCODER MNT 11 1 118568-103 ASSY, CONV,DRIVE 48,SEW,LH 12 1 118568-103 ASSY, CONV,DRIVE 48,SEW,LH 13 2 714909 SHAFT, IDLER, TABLETOP CHAIN 14 6 955390 NUT HEX JAM 1-1/8-7 UNC SST 15 1 118568-300 ASSY, CATCH PANS, 948L1-160S 16 955619 NUT HEX NYLOC 5/16-18 UNC SST 17 1 1 210369 ASSY,MOTOR DISCONNECT,600V,15A 18 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 19 10 1102 ENCODER, 1,375 THRU BORE 19 10 611102 ENCODER, 1,375 THRU BORE 19 10 611723 SPROCKET, 16T, 3,11" OD EZ CLEAN 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 21 59 ft. 611725 BELT,6" WIDE X 1/2" PITCH,SERIES 1100 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 24 40 711757 COLLAR, SET, 1" SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP 26 20 712735-001 BAR, ROLLER /PACX (LAMP, ADJ.) 27 10 712744 SHAFT, ROLLER SHAFT 28 20 712745 ROLLER, IDLER, CHAIN 30 10 712745 ROLLER, IDLER, CHAIN 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST (53 1 A05584 PLATE-SERIAL NUMBER	ITEM #	QTY.	PART#	DESCRIPTION	ITEM #	QTY.	PART#	DESCRIPTION
3 4 107026-019 CHANNEL, CHAIN GUIDE MIT 140" SPLIT 4 2 107026-031 SHAFT, TRANSFER DRIVE, 48" 36 1 714358 T-NUT, TRANSFER DLER ADJ. 5 REF. 117781-407 ENCODER, EIHERNETI/P 37 1 714359 SHAFT, ECCENTRIC IDLER 6 8 118241 NUT, WELD ON 1/4-20 NC, SST. 7 1 118568-001 A/W, CONVEYOR FRAME, 94BL-160S 8 4 118568-006 CHANNEL, CHAIN GUIDE MMT 160" SPLIT 9 1 118568-001 A/W, CONV MOTOR GUARD 11 118568-001 A/W, CONV MOTOR GUARD 11 1 118568-002 COVER, ENCODER MNT 12 1 118568-003 ASSY, CONV.DRIVE 4B.SEW.LH 13 1 118568-003 ASSY, CONV.DRIVE 4B.SEW.LH 14 2 2 714908 ROLLER, IDLER, TABLETOP CHAIN 15 1 118568-200 ASSY, CATCH PANS, 94BL-160S 16 1 210369 ASSY, MOTOR DISCONNECT, 600V, 15A 16 1 20369 ASSY, MOTOR DISCONNECT, 600V, 15A 16 1 3030000 LABBELBURFORD LOGO, 4.25 SCRIPT 17 1 611102 ENCODER, 1.375 THRU BORE 18 12 611635 BEARING, 1" BORE 3 HOLE FLANCE 19 16 611723 SPROCKET, 24T, 4.65" OD EZ CLEAN 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 21 59 ftl. 6111725 BELTIG* WIDE & 1/2* PITCH, SERIES I 1100 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 24 40 711757 COLLAR, 5", SIST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 26 20 712735-DOI BAR, ROLLER, FRADER CLAMP 36 989910 SCREW FIN HEX 3/8-16 X 11/2 SST 37 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 37 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 38 1 989910 SCREW FIN HEX 3/8-16 X 11/2 SST 39 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 27 20 712735-DOI BAR, ROLLER/PROX CLAMP, ADJ. 39 2 712781 COLLAR, FILE, TABLETOP CHAIN 30 10 712745 SOLER, FILE, TABLETOP CHAIN 31 20 712741 SHARCH CREATER SHAFT 40 989912 SCREW FIN HEX 3/8-16 X 11/2 SST 30 10 712745 ROLLER, FICHER THAIN GUIDE CLAMP 30 989912 SCREW FIN HEX 1/4-20 X 13/4 SST 31 20 712781 COLLAR, FILE, TABLETOP CHAIN 31 20 712781 COLLAR, FILE, TABLETOP CHAI	1	5	107026-009	A/W, 48" CONV. CROSS BRACE	33	4	714329-001	GUARD, INFEED DRIVE, BBU
4 2 107026-031 SHAFT, TRANSFER DRIVE, 48"  5 REF. 117781-407 ENCODER, ETHERNET/IP  6 8 118241 NUT, WELD ON 174-20 NC, SST.  7 1 118568-001 A/W, CONVEYOR FRAME, 948L-160S  8 4 118568-006 CHANNEL, CHAIN GUIDE MNT 160" SPLIT  9 1 118568-011 A/W, CONV MOTOR GUARD  10 1 118568-011 A/W, CONV MOTOR GUARD  11 118568-011 A/W, CONV MOTOR GUARD  11 1 118568-103 ASSY, CONV, MOTOR GUARD  11 1 118568-103 ASSY, CONV, DRIVE 48.SEW, LH  12 1 118568-000 ASSY, AUTO PAN GUIDES, 946L-160S  13 1 118568-300 ASSY, CONV, DRIVE 48.SEW, LH  14 2 714909 SHAFT, IDLER, ROLLER, TABLETOP CHAIN  11 1 118568-300 ASSY, CATCH PANS, 946L-160S  14 6 955390 NUT HEX JAM 1-1/8-7 UNC SST  13 1 118568-300 ASSY, CATCH PANS, 946L-160S  14 1 210369 ASSY, MOTOR DISCONNECT, 600V, 15A  15 1 210647 ASSY, SPRT IDLER, 40-A-17, 3/8" BORE  16 1 303300 LABEL, BURPORD LOGO, 4.25 SCRIPT  17 1 611102 ENCODER, 1.375 THRU BORE  18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE  19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN  19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN  20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN  21 59 fft. 611725 BELT, 6" WIDE X 1/2" PITCH, SERIES 1100  22 6 611730 CASTER, 4" SWIDE X 1/2" PITCH, SERIES 1100  36 989920 SCREW SOC HD CAP 1/4-20 X 13 /4 S 2 988924 SCREW FIN HEX 3/8-16 X 5/8 SST  27 20 712735 PLATE, TOP CHAIN GUIDE CLAMP  38 1 988912 SCREW FIN HEX 3/8-16 X 5/8 SST  39 10 712734 PLATE, CHAIN GUIDE CLAMP  30 10 712745 ROLLER, TABLETOP CHAIN  40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST  40 712745 SCREW FIN HEX 3/8-16 X 5/8 SST  41 989910 SCREW FIN HEX 1/4-20 X 13 /4 SST  42 90 712735 PLATE, TOP CHAIN GUIDE CLAMP  43 989910 SCREW FIN HEX 1/4-20 X 3/4 SST  44 90 712745 SCREW FIN HEX 1/4-20 X 3/4 SST  46 10 712745 SCREW FIN HEX 1/4-20 X 5/8 SST  47 989910 SCREW FIN HEX 1/4-20 X 3/4 SST  48 989910 SCREW FIN HEX 1/4-20 X 3/4 SST  49 989912 SCREW FIN HEX 1/4-20 X 3/4 SST	2	8	107026-017	GUIDE, TABLETOP CHAIN, 140" SPLIT	34	4	714330	GUARD, TRANSFER CENTER DRIVE
5 REF. 117781-407 ENCODER, ETHERNET/IP 6 8 118241 NUT, WELD ON 1/4-20 NC, SST. 7 1 118568-001 A/W, CONVEYOR FRAME, 948LI-160S 8 4 118568-001 A/W, CONVEYOR FRAME, 948LI-160S 8 4 118568-001 A/W, CONVEYOR FRAME, 948LI-160S 9 2 714871 SHAFT, IDLER, M-QNIS SPROCKET 9 1 118568-011 A/W, CONV MOTOR GUARD 1 1 118568-011 A/W, CONV MOTOR GUARD 1 1 118568-020 COVER, ENCODER MNT 1 1 1 118568-020 COVER, ENCODER MNT 1 1 1 118568-030 ASSY, CONV.DRIVE 48,SEW.LH 1 1 1 118568-030 ASSY, CONV.DRIVE 48,SEW.LH 1 2 1 118568-200 ASSY, AUTO PAN GUIDES, 946LI-160S 1 1 118568-300 ASSY, CATCH PANS, 948LI-160S 1 1 10369 ASSY, MOTOR DISCONNECT, 600V,15A 1 1 2 10369 ASSY, MOTOR DISCONNECT, 600V,15A 1 1 2 104647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 1 1 303000 LABEL,BURFORD LOGO A.25 SCRIPT 1 1 6 11102 ENCODER, 1.375 THRU BORE 1 2 6 11635 BEARING, 1" BORE 3 HOLE FLANGE 1 3 1 FOR STORM SPROCKET, 16T, 3.11" OD EZ CLEAN 2 4 6 11723 SPROCKET, 16T, 3.11" OD EZ CLEAN 3 5 975597 WASHER FLAT 3/1" SST 2 6 6 117725 BELT, 6" WIDE X 1/2" PITCH, SERIES 1100 5 7 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 5 7 12735-001 BAR, ROLLER, FOR HAMP, ADJ. 5 9 10 712734 PLATE, CHAIN GUIDE CLAMP, ADJ. 5 9 10 712735 PLATE, CHAIN GUIDE CLAMP, ADJ. 5 9 10 712734 PLATE, CHAIN GUIDE CLAMP, ADJ. 5 9 10 712735 PLATE, CHAIN GUIDE CLAMP, ADJ. 5 9 10 712735 PLATE, CHAIN GUIDE CLAMP, ADJ. 5 9 10 712744 SHAFT, ROLLER, FLAIN GUIDE CLAMP, ADJ. 5 9 10 712745 ROLLER, IDLER, TABLETOP CHAIN 6 10 989910 SCREW FIN HEX 3/8-16 X 2 ST ST ST SCREW FIN HEX 3/8-16 X 2 ST ST ST SCREW FIN HEX 3/8-16 X 2 ST ST ST ST SCREW FIN HEX 3/8-16 X 2 ST ST ST ST SCREW FIN HEX 3/8-16 X 2 ST	3	4	107026-019	CHANNEL, CHAIN GUIDE MNT 140" SPLIT	35	2	714357	SPROCKET, RWK, 40-B-17, 5/8" B
6 8 118241 NUI, WELD ON 1/4-20 NC, SST. 38 1 714360 A/W, COVER INTERLACE DRIVE 7 1 118568-001 A/W, CONVEYOR FRAME, 948LI-160S 39 2 714871 SHAFT, IDLER SPACER, BBU 8 4 118568-001 A/W, CONV MOTOR GUARD 40 4 714872 SHAFT, IDLER, M-QNB SPROCKET 9 1 118568-001 A/W, CONV MOTOR GUARD 41 4 714904 GUARD, MAIN CHAIN DRIVE SPROCK 10 1 118568-020 COVER, ENCODER MIT 42 2 714908 ROLLER, IDLER, TABLETOP CHAIN 11 1 118568-103 ASSY, CONV.DRIVE 48,SEW.LH 43 2 714909 SHAFT, IDLER ROLLER, TABLETOP CHAIN 12 1 118568-200 ASSY, AUTO PAN GUIDES, 946LI-160S 44 6 955390 NUIT HEX JAM 1-1/8-7 UNC SST 13 1 118568-300 ASSY, CATCH PANS, 948LI-160S 45 16 955619 NUIT HEX NYLOC 5/16-18 UNC SST 14 1 210369 ASSY, MOTOR DISCONNECT, 600V, 15A 46 36 955620 NUIT HEX NYLOC 3/8-16 UNC SST 15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 47 5 955938 WASHER LOCK 3/8" WASHER LOCK 1/4" SST 17 1 611102 ENCODER, 1.375 THRU BORE 49 36 955975 WASHER FLAT 3/8" SST 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 50 16 975777 WASHER FLAT 3/8" SST 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 51 48 955977 WASHER FLAT 3/8" SST 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 52 16 9777728 SCREW SOC HD CAP 5/16-18 x 1 3/4: 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 54 24 983506 SCREW SOC HD CAP 5/16-18 x 1 3/4: 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 54 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 1/4 SST 25 10 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 59 16 989712	4	2	107026-031	SHAFT, TRANSFER DRIVE, 48"	36	1	714358	T-NUT, TRANSFER IDLER ADJ.
7 1 118568-001 A/W, CONVEYOR FRAME, 948LI-160S 8 4 118568-006 CHANNEL, CHAIN GUIDE MNT 160" SPLIT 9 1 118568-011 A/W, CONV MOTOR GUARD 41 4 714904 GUARD, MAIN CHAIN DRIVE SPROCKET 9 1 118568-011 A/W, CONV MOTOR GUARD 41 4 714904 GUARD, MAIN CHAIN DRIVE SPROCKET 10 1 118568-020 COVER, ENCODER MNT 42 2 714908 ROLLER, IDLER, TABLETOP CHAIN 11 1 118568-103 ASSY, CONV, DRIVE 48, SEW, LH 43 2 714909 SHAFT, IDLER, TABLETOP CHAIN 12 1 118568-200 ASSY, AUTO PAN GUIDES, 946LI-160S 44 6 955390 NUT HEX JAM 1-1/8-7 UNC SST 13 1 118568-300 ASSY, CATCH PANS, 948LI-160S 45 16 955619 NUT HEX NYLOC 5/16-18 UNC SST 14 1 210369 ASSY, MOTOR DISCONNECT, 600V, 15A 46 36 955620 NUT HEX NYLOC 3/8-16 UNC SST 15 1 210447 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 47 5 955938 WASHER LOCK 3/8" 16 1 303000 LABEL, BURFORD LOGO, 4.25 SCRIPT 48 90 955940 WASHER LOCK 1/4" SST 17 1 611102 ENCODER, 1.375 THRU BORE 49 36 955975 WASHER FLAT 3/8" SST 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 50 16 955976 WASHER FLAT 3/16 SST 20 4 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 51 64 611723 SPROCKET, 14T, 4.65" OD EZ CLEAN 52 6 611730 CASTER, 6" SWIVEL LOCKING, SST 54 24 983506 SCREW SOC HD CAP 5/16-18 x 1 3/4; SST 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 55 4 988910 SCREW SOC HD CAP 1/4-20 x 1 3/45; SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/4 SST 58 1 988932 SCREW FIN HEX 3/8-16 X 1 1/4 SST 59 16 989712 SCREW FIN HEX 3/8-16 X 1 1/4 SST 59 17 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 59 16 989912 SCREW FIN HEX 3/8-16 X 1 1/4 SST 59 10 712744 SHAFT, FOLLER FIDER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 61 989912 SCREW FIN HEX 1/4-20 X 1/2 SST 61 712745 ROLLER, FABLETOP CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 61 712745 ROLLER, FABLETOP CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 61 712747 SHAFT, FOLLER, FABLETOP CHAIN 61 8 989912 SCREW FIN HEX 1/4-20 X 1/2 SST	5	REF.	117781-407	ENCODER, ETHERNET/IP	37	1	714359	SHAFT, ECCENTRIC IDLER
8 4 118568-006 CHANNEL, CHAIN GUIDE MNT 160" SPLIT 40 4 714872 SHAFT, IDLER, M-GNB SPROCKET 9 1 118568-011 A/W. CONV MOTOR GUARD 41 4 714904 GUARD, MAIN CHAIN DRIVE SPROCK 10 1 118568-020 COVER, ENCODER MNT 42 2 714908 ROLLER, IDLER, TABLETOP CHAIN 11 1 118568-103 ASSY, CONV, DRIVE 48.5EW, LH 43 2 714909 SHAFT, IDLER, TABLETOP CHAIN 11 1 118568-200 ASSY, AUTO PAN GUIDES, 946L1-160S 44 6 955390 NUT HEX JAM 1-1/8-7 UNC SST 13 1 118568-300 ASSY, CATCH PANS, 948L1-160S 45 16 955549 NUT HEX NYLOC 5/16-18 UNC SST 14 1 210369 ASSY, MOTOR DISCONNECT, 600V, 15A 46 36 955620 NUT HEX NYLOC 3/8-16 UNC SST 15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 47 5 955930 WASHER LOCK 3/8" 16 11 303000 LABEL, BURFORD LOGO, 4.25 SCRIPT 48 90 955940 WASHER LOCK 1/4" SST 17 1 611102 ENCODER, 1.375 THRU BORE 49 36 955975 WASHER FLAT 3/8" SST 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 50 16 955976 WASHER FLAT 5/16 SST 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 51 48 955977 WASHER FLAT 1/4" SST 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 51 48 955977 WASHER FLAT 1/4" SST 20 4 611725 BELT, 6" WIDE x 1/2" PITCH, SERIES 1100 53 32 978328 SCREW SOC HD CAP 5/16-18 x 1 3/4 3/4 3/4 3/4 3/4 3/4 3/4 3/4 3/4 3/4	6	8	118241	NUT, WELD ON 1/4-20 NC, SST.	38	1	714360	A/W, COVER INTERLACE DRIVE
9 1 118568-011 A/W. CONV MOTOR GUARD 41 4 714904 GUARD, MAIN CHAIN DRIVE SPROCKE 10 1 118568-020 COVER, ENCODER MNT 42 2 714908 ROLLER, IDLER, TABLETOP CHAIN 11 1 118568-103 ASSY, CONV,DRIVE 48,SEW,LH 43 2 714909 SHAFT, IDLER ROLLER, TABLETOP CHAIN 12 1 118568-200 ASSY,AUTO PAN GUIDES, 946LI-160S 44 6 955390 NUT HEX JAM 1-1/8-7 UNC SST 13 1 118568-300 ASSY, CATCH PANS, 948LI-160S 45 16 955619 NUT HEX NYLOC 5/16-18 UNC SST 14 1 210369 ASSY,MOTOR DISCONNECT,600V,15A 46 36 955620 NUT HEX NYLOC 3/8-16 UNC SST 15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 47 5 955938 WASHER LOCK 3/8" 16 1 303000 LABELBURFORD LOGO,4.25 SCRIPT 48 90 955940 WASHER LOCK 1/4" SST 17 1 611102 ENCODER, 1.375 THRU BORE 49 36 955975 WASHER FLAT 3/8" SST 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 50 16 955976 WASHER FLAT 1/4" SST 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 51 48 955977 WASHER FLAT 1/4" SST 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 51 48 955977 WASHER FLAT 1/4" SST 21 59 ff. 611725 BELT,6" WIDE x 1/2" PITCH,SERIES 1100 53 32 978328 SCREW SOC HD CAP 5/16-18 x 1 3/4: 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 55 4 988910 SCREW FIN HEX 3/8-16 X 5/8 SST 24 40 711757 COLLAR, SET, 1" SST 56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, AAG, ET 26 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 59 16 989712 SCREW FIN HEX 3/8-16 X 1 1/2 SST 26 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 59 16 989910 SCREW FIN HEX 5/16-18 X 3/4 SST 29 10 712744 SHAFT, ROLLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 29 10 712745 ROLLER, TABLETOP CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 61 10 712745 ROLLER, TABLETOP CHAIN 61 8 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 61 10 712745 ROLLER, TABLETOP CHAIN 61 8 989912 SCREW FIN HEX 1/4-20 X 3/4 SST	7	1	118568-001	A/W, CONVEYOR FRAME, 948LI-160S	39	2	714871	SHAFT, IDLER SPACER, BBU
10 1 118568-020 COVER, ENCODER MNT 42 2 714908 ROLLER, IDLER, TABLETOP CHAIN 11 1 118568-103 ASSY, CONV,DRIVE 48,SEW,LH 43 2 714909 SHAFT, IDLER ROLLER, TABLETOP CHAIN 12 1 118568-200 ASSY, AUTO PAN GUIDES, 946LI-160S 44 6 955390 NUT HEX JAM 1-1/8-7 UNC SST 13 1 118568-300 ASSY, CATCH PANS, 948LI-160S 45 16 955619 NUT HEX NYLOC 5/16-18 UNC SST 14 1 210369 ASSY, MOTOR DISCONNECT,600V,15A 46 36 955620 NUT HEX NYLOC 3/8-16 UNC SST 15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 47 5 955938 WASHER LOCK 3/8" 16 1102 ENCODER, 1,375 THRU BORE 49 36 955975 WASHER LAT 3/8" SST 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 50 16 955976 WASHER FLAT 5/16 SST 19 16 611723 SPROCKET, 16T, 3,11" OD EZ CLEAN 51 48 955977 WASHER FLAT 1/4" SST 20 4 611724 SPROCKET, 24T, 4,65" OD EZ CLEAN 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4: 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 54 983506 SCREW FILT HD SOC #6-32 X 3/8 SST 23 8 611868 END CAP, BEARING (611635) 55 4 988910 SCREW FILT HD SOC #6-32 X 3/8 SST 24 40 711757 COLLAR, SET, 1" SST 56 12 988920 SCREW FIN HEX 3/8-16 X 5/8 SST 26 20 712735 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988920 SCREW FIN HEX 3/8-16 X 5/8 SST 26 20 712735 PLATE, CHAIN GUIDE CLAMP, ADJ. 59 16 989712 SCREW FIN HEX 3/8-16 X 2 SST 20 712744 SHAFT, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 3/4-16 X 2 SST 20 712744 SHAFT, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 3/4-16 X 5/8 SST 29 10 71274 SHAFT, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 1/4-20 X 1/2 SST 29 10 712745 ROLLER, IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 29 10 712745 ROLLER, IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, CHAIN 61 62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, CH	8	4	118568-006	CHANNEL, CHAIN GUIDE MNT 160" SPLIT	40	4	714872	SHAFT, IDLER, M-QNB SPROCKET
11 1 118568-103 ASSY, CONY, DRIVE 48, SEW, LH  12 1 118568-200 ASSY, AUTO PAN GUIDES, 946LI-160S  13 1 118568-300 ASSY, CATCH PANS, 948LI-160S  14 1 210369 ASSY, MOTOR DISCONNECT, 600V, 15A  15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE  16 1 303000 LABEL, BURFORD LOGO, 4.25 SCRIPT  17 1 611102 ENCODER, 1, 375 THRU BORE  18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE  19 16 611723 SPROCKET, 16T, 3, 11" OD EZ CLEAN  20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN  21 59 ft. 611725 BELT, 6" WIDE x 1/2" PITCH, SERIES 1100  22 6 611730 CASTER, 6" SWIVEL LOCKING, SST  23 8 611868 END CAP, BEARING (611635)  24 40 711757 COLLAR, SET, 1" SST  25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET  26 20 712735-001 BAR, ROLLER, IDLER, CHAIN  27 10 712744 SHAFT, ROLLER SHAFT  28 20 712745 ROLLER, IDLER, CHAIN  30 10 712745 ROLLER, IDLER, TABLETOP CHAIN  43 2 714909 SHAFT, IDLER ROLLER, TABLETOP CHAIN  44 6 955390 NUT HEX JAM 1-1/8-7 UNC SST  44 6 955619 NUT HEX JAM 1-1/8-7 UNC SST  45 16 955620 NUT HEX NYLOC 5/16-18 UNC SST  46 36 955620 NUT HEX NYLOC 5/16-18 UNC SST  47 5 955938 WASHER LOCK 3/8"  48 90 955970 WASHER LOCK 1/4" SST  48 90 955975 WASHER FLAT 3/8" SST  48 90 955975 WASHER FLAT 3/8" SST  49 955977 WASHER FLAT 5/16 SST  49 955977 WASHER FLAT 1/4" SST  50 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4: ST  51 49 983506 SCREW FLT HD SOC #6-32 X 3/8 SST  52 4 983506 SCREW FIN HEX 3/8-16 X 1 1/4 SST  55 4 988910 SCREW FIN HEX 3/8-16 X 1 1/4 SST  56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST  57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST  58 1 988932 SCREW FIN HEX 3/8-16 X 1 1/2 SST  59 16 989712 SCREW FIN HEX 1/4-20 X 1/2 SST  59 16 989908 SCREW FIN HEX 1/4-20 X 3/4 SST  50 10 712745 ROLLER, IDLER, CHAIN  50 10 712745 ROLLER, IDLER, CHAIN  51 10 A05584 PLATE-SERIAL NUMBER	9	1	118568-011	A/W. CONV MOTOR GUARD	41	4	714904	GUARD, MAIN CHAIN DRIVE SPROCKET
12 1 118568-200 ASSY, AUTO PAN GUIDES, 946LI-160S 44 6 955390 NUT HEX JAM 1-1/8-7 UNC SST 13 1 118568-300 ASSY, CATCH PANS, 948LI-160S 45 16 955619 NUT HEX NYLOC 5/16-18 UNC SST 14 1 210369 ASSY, MOTOR DISCONNECT, 600V, 15A 46 36 955620 NUT HEX NYLOC 3/8-16 UNC SST 15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 47 5 955938 WASHER LOCK 3/8" 16 1 303000 LABEL, BURFORD LOGO, 4.25 SCRIPT 48 90 955940 WASHER LOCK 1/4" SST 17 1 611102 ENCODER, 1, 375 THRU BORE 49 36 955975 WASHER FLAT 3/8" SST 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 50 16 955976 WASHER FLAT 5/16 SST 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 51 48 955977 WASHER FLAT 1/4" SST 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4: 21 59 ft. 611725 BELT, 6" WIDE x 1/2" PITCH, SERIES 1100 53 32 978328 SCREW SOC HD CAP 1/4-20 X 1 3/4 S 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 54 24 983506 SCREW FLT HD SOC #6-32 X 3/8 SST 23 8 611868 END CAP, BEARING (611635) 55 4 988910 SCREW FIN HEX 3/8-16 X 5/8 SST 24 40 711757 COLLAR, SET, 1" SST 56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST 20 712735-001 BAR, ROLLER, PROX CLAMP, ADJ. 59 16 989712 SCREW FIN HEX 3/8-16 X 2 SST 20 712735 PLATE, TOP CHAN GUIDE CLAMP 58 1 988932 SCREW FIN HEX 3/8-16 X 2 SST 20 712744 SHAFT, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 1/4-20 X 1/2 SST 29 10 712744 SHAFT, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, TABLETOP CHAIN 62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712745 ROLLER, IDLER, TABLETOP CHAIN 62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 63 1 A05584 PLATE-SERIAL NUMBER	10	1	118568-020	COVER, ENCODER MNT	42	2	714908	ROLLER, IDLER, TABLETOP CHAIN
13 1 118568-300 ASSY, CATCH PANS, 948LI-160S 14 1 210369 ASSY,MOTOR DISCONNECT,600V,15A 15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 16 1 303000 LABEL,BURFORD LOGO,4.25 SCRIPT 17 1 611102 ENCODER, 1.375 THRU BORE 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 21 59 ff. 611725 BELT,6" WIDLE X 1/2" PITCH,SERIES 1100 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 25 9 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 26 20 712735 PLATE, TOP CHAIN GUIDE CLAMP, MAGNET 27 29 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 28 20 712741 BRACKET, ROLLER IDLER, TABLETOP CHAIN 30 20 712745 ROLLER, IDLER, TABLETOP CHAIN 46 36 955619 NUT HEX NYLOC 5/16-18 UNC SST 47 5 955938 NASHER FLAT 1/4" SST 48 955978 WASHER LOCK 3/8" 47 5 955938 WASHER LOCK 3/8" 48 90 955979 WASHER FLAT 3/8" SST 49 36 955975 WASHER FLAT 3/8" SST 50 16 955976 WASHER FLAT 3/8" SST 51 48 955977 WASHER FLAT 1/4" SST 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 st 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 st 52 16 977728 SCREW SOC HD CAP 1/4-20 x 1 3/4 st 52 16 978328 SCREW FLIT HD SOC #6-32 x 3/8 SST 54 24 983506 SCREW FLIT HD SOC #6-32 x 3/8 SST 55 4 988910 SCREW FIN HEX 3/8-16 x 5/8 SST 56 12 988920 SCREW FIN HEX 3/8-16 x 5/16 SST 57 24 988924 SCREW FIN HEX 3/8-16 x 1 1/4 SST 58 1 988932 SCREW FIN HEX 3/8-16 x 1 1/4 SST 59 16 989712 SCREW FIN HEX 3/8-16 x 3/4 SST 59 16 989712 SCREW FIN HEX 3/8-16 x 3/4 SST 59 16 989912 SCREW FIN HEX 1/4-20 x 3/4 SST 50 10 712744 SHAFT, ROLLER IDLER, CHAIN 50 10 712745 ROLLER, IDLER, TABLETOP CHAIN 51 10 712745 ROLLER, IDLER, TABL	11	1	118568-103	ASSY, CONV,DRIVE 48,SEW,LH	43	2	714909	SHAFT, IDLER ROLLER, TABLETOP CHAIN
14         1         210369         ASSY,MOTOR DISCONNECT,600V,15A         46         36         955620         NUT HEX NYLOC 3/8-16 UNC SST           15         1         210647         ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE         47         5         955938         WASHER LOCK 3/8"           16         1         303000         LABEL,BURFORD LOGO, 4.25 SCRIPT         48         90         955940         WASHER LOCK 1/4" SST           17         1         611102         ENCODER, 1.375 THRU BORE         49         36         955975         WASHER FLAT 3/8" SST           18         12         611635         BEARING, 1" BORE 3 HOLE FLANGE         50         16         955976         WASHER FLAT 1/4" SST           19         16         611723         SPROCKET, 24T, 4.65" OD EZ CLEAN         51         48         955977         WASHER FLAT 1/4" SST           20         4         611724         SPROCKET, 24T, 4.65" OD EZ CLEAN         52         16         977728         SCREW SOC HD CAP 5/16-18 x 1 3/4 S           21         59 fft.         611725         BELT,6" WIDE x 1/2" PITCH,SERIES 1100         53         32         978328         SCREW SOC HD CAP 5/16-18 x 1 3/4 S           22         6         611730         CASTER, 6" SWIVEL LOCKING, SST         54 </td <td>12</td> <td>1</td> <td>118568-200</td> <td>ASSY, AUTO PAN GUIDES, 946LI-160S</td> <td>44</td> <td>6</td> <td>955390</td> <td>NUT HEX JAM 1-1/8-7 UNC SST</td>	12	1	118568-200	ASSY, AUTO PAN GUIDES, 946LI-160S	44	6	955390	NUT HEX JAM 1-1/8-7 UNC SST
15 1 210647 ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE 16 1 303000 LABEL, BURFORD LOGO, 4.25 SCRIPT 17 1 611102 ENCODER, 1.375 THRU BORE 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 21 59 ft. 611725 BELT, 6" WIDE x 1/2" PITCH, SERIES 1100 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 24 40 711757 COLLAR, SET, 1" SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 26 20 712735 PLATE, TOP CHAN GUIDE CLAMP, MAGNET 27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 28 20 712741 BRACKET, ROLLER SHAFT 29 10 712744 SHAFT, ROLLER SHAFT 30 10 712745 ROLLER, IDLER, CHAIN 303000 LABEL, BURFORD LOGO, 4.25 SCRIPT 48 90 955978 WASHER LOCK 1/4" SST 49 955975 WASHER FLAT 1/4" SST 49 955977 WASHER FLAT 1/4" SST 50 16 955977 WASHER FLAT 1/4" SST 51 48 955977 WASHER FLAT 1/4" SST 51 48 955977 WASHER FLAT 1/4" SST 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 ST 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 ST 53 32 978328 SCREW SOC HD CAP 1/4-20 x 1 3/4 ST 54 24 983506 SCREW FIN HEX 3/8-16 x 2 5/8 SST 55 4 988910 SCREW FIN HEX 3/8-16 x 2 5/8 SST 56 12 988920 SCREW FIN HEX 3/8-16 x 1 1/4 SST 57 24 988920 SCREW FIN HEX 3/8-16 x 1 1/4 SST 57 24 988924 SCREW FIN HEX 3/8-16 x 1 1/2 SST 58 1 988932 SCREW FIN HEX 3/8-16 x 1 1/2 SST 59 16 989712 SCREW FIN HEX 5/16-18 x 3/4 SST 59 16 989712 SCREW FIN HEX 1/4-20 x 1/2 SST 59 10 712744 SHAFT, ROLLER IDLER, CHAIN 50 712745 ROLLER, IDLER, TABLETOP CHAIN 51 A05584 PLATE-SERIAL NUMBER	13	1	118568-300	ASSY, CATCH PANS, 948LI-160S	45	16	955619	NUT HEX NYLOC 5/16-18 UNC SST
16         1         303000         LABEL,BURFORD LOGO, 4.25 SCRIPT         48         90         955940         WASHER LOCK 1/4" SST           17         1         611102         ENCODER, 1.375 THRU BORE         49         36         955975         WASHER FLAT 3/8" SST           18         12         611635         BEARING, 1" BORE 3 HOLE FLANGE         50         16         955976         WASHER FLAT 5/16 SST           19         16         611723         SPROCKET, 16T, 3.11" OD EZ CLEAN         51         48         955977         WASHER FLAT 1/4" SST           20         4         611724         SPROCKET, 24T, 4.65" OD EZ CLEAN         52         16         977728         SCREW SOC HD CAP 5/16-18 x 1 3/4 s           21         59 ff.         611725         BELT,6" WIDE x 1/2" PITCH,SERIES 1100         53         32         978328         SCREW SOC HD CAP 5/16-18 x 1 3/4 s           22         6         611730         CASTER, 6" SWIVEL LOCKING, SST         54         24         983506         SCREW FIT HD SOC #6-32 X 3/8 SST           23         8         611868         END CAP, BEARING (611635)         55         4         988910         SCREW FIT HD SOC #6-32 X 3/8 SST           24         40         711757         COLLAR, SET, 1" SST         56	14	1	210369	ASSY,MOTOR DISCONNECT,600V,15A	46	36	955620	NUT HEX NYLOC 3/8-16 UNC SST
17 1 611102 ENCODER, 1.375 THRU BORE 49 36 955975 WASHER FLAT 3/8" SST 18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 50 16 955976 WASHER FLAT 5/16 SST 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 51 48 955977 WASHER FLAT 1/4" SST 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 st 21 59 ft. 611725 BELT,6" WIDE x 1/2" PITCH,SERIES 1100 53 32 978328 SCREW SOC HD CAP 1/4-20 x 1 3/4 st 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 54 24 983506 SCREW FLT HD SOC #6-32 x 3/8 SST 23 8 611868 END CAP, BEARING (611635) 55 4 988910 SCREW FIN HEX 3/8-16 x 5/8 SST 24 40 711757 COLLAR, SET, 1" SST 56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST 26 20 712735 PLATE, TOP CHAN GUIDE CLAMP 58 1 988932 SCREW FIN HEX 3/8-16 X 2 SST 27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 59 16 989712 SCREW FIN HEX 5/16-18 x 3/4 SST 28 20 712741 BRACKET, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 1/4-20 X 1/2 SST 29 10 712744 SHAFT, ROLLER IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 5/8 SST 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 63 1 A05584 PLATE-SERIAL NUMBER	15	1	210647	ASSY, SPRKT IDLER, 40-A-17, 3/8" BORE	47	5	955938	WASHER LOCK 3/8"
18 12 611635 BEARING, 1" BORE 3 HOLE FLANGE 19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 21 59 ff. 611725 BELT,6" WIDE x 1/2" PITCH,SERIES 1100 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 24 40 711757 COLLAR, SET, 1" SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 26 27 712735-001 BAR, ROLLER / PROCKET, ADJ. 27 28 712735-001 BAR, ROLLER / PROX CLAMP, ADJ. 28 29 712741 BRACKET, ROLLER SHAFT 29 10 712744 SHAFT, ROLLER IDLER, CHAIN 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 48 985977 WASHER FLAT 5/16 SST 48 955977 WASHER FLAT 1/4" SST 50 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 ST 51 48 955977 WASHER FLAT 1/4" SST 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 SST 53 32 978328 SCREW SOC HD CAP 5/16-18 x 1 3/4 SST 54 24 983506 SCREW FIN HEX 3/8-16 X 5/8 SST 55 4 988910 SCREW FIN HEX 3/8-16 X 5/8 SST 56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST 57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST 58 1 988932 SCREW FIN HEX 3/8-16 X 2 SST 59 16 989712 SCREW FIN HEX 1/4-20 X 1/2 SST 59 16 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 59 10 712745 ROLLER, IDLER, TABLETOP CHAIN 50 10 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 51 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 50 11 A05584 PLATE-SERIAL NUMBER	16	1	303000	LABEL,BURFORD LOGO,4.25 SCRIPT	48	90	955940	WASHER LOCK 1/4" SST
19 16 611723 SPROCKET, 16T, 3.11" OD EZ CLEAN 20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 21 59 ff. 611725 BELT,6" WIDE x 1/2" PITCH,SERIES 1100 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 24 40 711757 COLLAR, SET, 1" SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 26 20 712735 PLATE, TOP CHAN GUIDE CLAMP 27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 28 20 712741 BRACKET, ROLLER SHAFT 29 10 712744 SHAFT, ROLLER SHAFT 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 48 955977 WASHER FLAT 1/4" SST 59 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 s 51 48 955977 WASHER FLAT 1/4" SST 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 s 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 s 52 16 977728 SCREW FLAT 1/4" SST 53 32 978328 SCREW SOC HD CAP 5/16-18 x 1 3/4 s 52 4 983506 SCREW FLT HD SOC #6-32 x 3/8 SST 54 24 983506 SCREW FIN HEX 3/8-16 x 5/8 SST 55 4 988910 SCREW FIN HEX 3/8-16 x 1 1/4 SST 56 12 988920 SCREW FIN HEX 3/8-16 x 1 1/4 SST 57 24 988924 SCREW FIN HEX 3/8-16 x 1 1/2 SST 58 1 988932 SCREW FIN HEX 3/8-16 x 2 SST 59 16 989712 SCREW FIN HEX 1/4-20 x 1/2 SST 59 16 989712 SCREW FIN HEX 1/4-20 x 1/2 SST 50 989908 SCREW FIN HEX 1/4-20 x 3/4 SST 50 10 712745 ROLLER, IDLER, TABLETOP CHAIN 50 10 989912 SCREW FIN HEX 1/4-20 x 3/4 SST 51 10 405584 PLATE-SERIAL NUMBER	17	1	611102	ENCODER, 1.375 THRU BORE	49	36	955975	WASHER FLAT 3/8" SST
20 4 611724 SPROCKET, 24T, 4.65" OD EZ CLEAN 21 59 ft. 611725 BELT,6" WIDE x 1/2" PITCH,SERIES 1100 22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 24 40 711757 COLLAR, SET, 1" SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 26 20 712735 PLATE, TOP CHAN GUIDE CLAMP 27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 28 20 712741 BRACKET, ROLLER SHAFT 29 10 712744 SHAFT, ROLLER IDLER, CHAIN 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 4 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 s 52 16 977728 SCREW SOC HD CAP 5/16-18 x 1 3/4 s 53 32 978328 SCREW SOC HD CAP 5/16-18 x 1 3/4 s 54 24 983506 SCREW FLT HD SOC #6-32 X 3/8 SST 55 4 988910 SCREW FIN HEX 3/8-16 X 5/8 SST 56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST 57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST 58 1 988932 SCREW FIN HEX 3/8-16 X 2 SST 59 16 989712 SCREW FIN HEX 5/16-18 X 3/4 SST 59 16 989712 SCREW FIN HEX 1/4-20 X 1/2 SST 59 10 712744 SHAFT, ROLLER IDLER, CHAIN 50 989910 SCREW FIN HEX 1/4-20 X 3/4 SST 51 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 50 10 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 51 1 A05584 PLATE-SERIAL NUMBER	18	12	611635	BEARING, 1" BORE 3 HOLE FLANGE	50	16	955976	WASHER FLAT 5/16 SST
21 59 ff. 611725 BELT,6" WIDE x 1/2" PITCH,SERIES 1100  53 32 978328 SCREW SOC HD CAP 1/4-20 X 1 3/4 S.  22 6 611730 CASTER, 6" SWIVEL LOCKING, SST  54 24 983506 SCREW FLT HD SOC #6-32 X 3/8 SST  23 8 611868 END CAP, BEARING (611635)  55 4 988910 SCREW FIN HEX 3/8-16 X 5/8 SST  24 40 711757 COLLAR, SET, 1" SST  56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST  25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET  57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST  26 20 712735 PLATE, TOP CHAN GUIDE CLAMP  58 1 988932 SCREW FIN HEX 3/8-16 X 2 SST  27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ.  59 16 989712 SCREW FIN HEX 5/16-18 X 3/4 SST  28 20 712741 BRACKET, ROLLER SHAFT  60 50 989908 SCREW FIN HEX 1/4-20 X 1/2 SST  29 10 712744 SHAFT, ROLLER IDLER, CHAIN  61 8 989910 SCREW FIN HEX 1/4-20 X 5/8 SST  30 10 712745 ROLLER, IDLER, TABLETOP CHAIN  62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST  31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST  63 1 A05584 PLATE-SERIAL NUMBER	19	16	611723	SPROCKET, 16T, 3.11" OD EZ CLEAN	51	48	955977	WASHER FLAT 1/4" SST
22 6 611730 CASTER, 6" SWIVEL LOCKING, SST 23 8 611868 END CAP, BEARING (611635) 24 40 711757 COLLAR, SET, 1" SST 25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 26 20 712735 PLATE, TOP CHAN GUIDE CLAMP 27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 28 20 712741 BRACKET, ROLLER SHAFT 29 10 712744 SHAFT, ROLLER IDLER, CHAIN 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 4 988910 SCREW FIN HEX 3/8-16 X 1 1/4 SST 5 4 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST 5 5 4 988920 SCREW FIN HEX 3/8-16 X 1 1/4 SST 5 7 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST 5 8 1 988932 SCREW FIN HEX 3/8-16 X 2 SST 5 9 16 989712 SCREW FIN HEX 5/16-18 X 3/4 SST 6 989908 SCREW FIN HEX 1/4-20 X 1/2 SST 6 1 989910 SCREW FIN HEX 1/4-20 X 1/2 SST 7 12745 ROLLER, IDLER, TABLETOP CHAIN 6 1 8 989910 SCREW FIN HEX 1/4-20 X 3/4 SST 7 12781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 6 3 1 A05584 PLATE-SERIAL NUMBER	20	4	611724	SPROCKET, 24T, 4.65" OD EZ CLEAN	52	16	977728	SCREW SOC HD CAP 5/16-18 x 1 3/4 SST
23 8 611868 END CAP, BEARING (611635)  24 40 711757 COLLAR, SET, 1" SST  25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET  26 20 712735 PLATE, TOP CHAN GUIDE CLAMP  27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ.  28 20 712741 BRACKET, ROLLER SHAFT  29 10 712744 SHAFT, ROLLER IDLER, CHAIN  30 10 712745 ROLLER, IDLER, TABLETOP CHAIN  31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST  55 4 988910 SCREW FIN HEX 3/8-16 X 5/8 SST  56 12 988920 SCREW FIN HEX 3/8-16 X 1 1/2 SST  57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST  58 1 988932 SCREW FIN HEX 3/8-16 X 2 SST  59 16 989712 SCREW FIN HEX 5/16-18 X 3/4 SST  60 50 989908 SCREW FIN HEX 1/4-20 X 1/2 SST  61 8 989910 SCREW FIN HEX 1/4-20 X 5/8 SST  62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST	21	59 ft.	611725	BELT,6" WIDE x 1/2" PITCH,SERIES 1100	53	32	978328	SCREW SOC HD CAP 1/4-20 X 1 3/4 SST
24       40       711757       COLLAR, SET, 1" SST       56       12       988920       SCREW FIN HEX 3/8-16 X 1 1/4 SST         25       10       712734       PLATE, CHAIN GUIDE CLAMP, MAGNET       57       24       988924       SCREW FIN HEX 3/8-16 X 1 1/2 SST         26       20       712735       PLATE, TOP CHAN GUIDE CLAMP       58       1       988932       SCREW FIN HEX 3/8-16 X 2 SST         27       20       712735-001       BAR, ROLLER/PROX CLAMP, ADJ.       59       16       989712       SCREW FIN HEX 5/16-18 X 3/4 SST         28       20       712741       BRACKET, ROLLER SHAFT       60       50       989908       SCREW FIN HEX 1/4-20 X 1/2 SST         29       10       712744       SHAFT, ROLLER IDLER, CHAIN       61       8       989910       SCREW FIN HEX 1/4-20 X 5/8 SST         30       10       712745       ROLLER, IDLER, TABLETOP CHAIN       62       40       989912       SCREW FIN HEX 1/4-20 X 3/4 SST         31       20       712781       COLLAR, HALF REWORK, 1-1/2 SPLIT, SST       63       1       A05584       PLATE-SERIAL NUMBER	22	6	611730	CASTER, 6" SWIVEL LOCKING, SST	54	24	983506	SCREW FLT HD SOC #6-32 X 3/8 SST
25 10 712734 PLATE, CHAIN GUIDE CLAMP, MAGNET 57 24 988924 SCREW FIN HEX 3/8-16 X 1 1/2 SST 26 20 712735 PLATE, TOP CHAN GUIDE CLAMP 58 1 988932 SCREW FIN HEX 3/8-16 X 2 SST 27 20 712735-001 BAR, ROLLER/PROX CLAMP, ADJ. 59 16 989712 SCREW FIN HEX 5/16-18 X 3/4 SST 28 20 712741 BRACKET, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 1/4-20 X 1/2 SST 29 10 712744 SHAFT, ROLLER IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 5/8 SST 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 63 1 A05584 PLATE-SERIAL NUMBER	23	8	611868	END CAP, BEARING (611635)	55	4	988910	SCREW FIN HEX 3/8-16 X 5/8 SST
26       20       712735       PLATE, TOP CHAN GUIDE CLAMP       58       1       988932       SCREW FIN HEX 3/8-16 X 2 SST         27       20       712735-001       BAR, ROLLER/PROX CLAMP, ADJ.       59       16       989712       SCREW FIN HEX 5/16-18 X 3/4 SST         28       20       712741       BRACKET, ROLLER SHAFT       60       50       989908       SCREW FIN HEX 1/4-20 X 1/2 SST         29       10       712744       SHAFT, ROLLER IDLER, CHAIN       61       8       989910       SCREW FIN HEX 1/4-20 X 5/8 SST         30       10       712745       ROLLER, IDLER, TABLETOP CHAIN       62       40       989912       SCREW FIN HEX 1/4-20 X 3/4 SST         31       20       712781       COLLAR, HALF REWORK, 1-1/2 SPLIT, SST       63       1       A05584       PLATE-SERIAL NUMBER	24	40	711757	COLLAR, SET, 1" SST	56	12	988920	SCREW FIN HEX 3/8-16 X 1 1/4 SST
27       20       712735-001       BAR, ROLLER/PROX CLAMP, ADJ.       59       16       989712       SCREW FIN HEX 5/16-18 X 3/4 SST         28       20       712741       BRACKET, ROLLER SHAFT       60       50       989908       SCREW FIN HEX 1/4-20 X 1/2 SST         29       10       712744       SHAFT, ROLLER IDLER, CHAIN       61       8       989910       SCREW FIN HEX 1/4-20 X 5/8 SST         30       10       712745       ROLLER, IDLER, TABLETOP CHAIN       62       40       989912       SCREW FIN HEX 1/4-20 X 3/4 SST         31       20       712781       COLLAR, HALF REWORK, 1-1/2 SPLIT, SST       63       1       A05584       PLATE-SERIAL NUMBER	25	10	712734	PLATE, CHAIN GUIDE CLAMP, MAGNET	57	24	988924	SCREW FIN HEX 3/8-16 X 1 1/2 SST
28 20 712741 BRACKET, ROLLER SHAFT 60 50 989908 SCREW FIN HEX 1/4-20 X 1/2 SST 29 10 712744 SHAFT, ROLLER IDLER, CHAIN 61 8 989910 SCREW FIN HEX 1/4-20 X 5/8 SST 30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 63 1 A05584 PLATE-SERIAL NUMBER	26	20	712735	PLATE, TOP CHAN GUIDE CLAMP	58	1	988932	SCREW FIN HEX 3/8-16 X 2 SST
29       10       712744       SHAFT, ROLLER IDLER, CHAIN       61       8       989910       SCREW FIN HEX 1/4-20 X 5/8 SST         30       10       712745       ROLLER, IDLER, TABLETOP CHAIN       62       40       989912       SCREW FIN HEX 1/4-20 X 3/4 SST         31       20       712781       COLLAR, HALF REWORK, 1-1/2 SPLIT, SST       63       1       A05584       PLATE-SERIAL NUMBER	27	20	712735-001	BAR, ROLLER/PROX CLAMP, ADJ.	59	16	989712	SCREW FIN HEX 5/16-18 X 3/4 SST
30 10 712745 ROLLER, IDLER, TABLETOP CHAIN 62 40 989912 SCREW FIN HEX 1/4-20 X 3/4 SST 31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 63 1 A05584 PLATE-SERIAL NUMBER	28	20	712741	BRACKET, ROLLER SHAFT	60	50	989908	SCREW FIN HEX 1/4-20 X 1/2 SST
31 20 712781 COLLAR, HALF REWORK, 1-1/2 SPLIT, SST 63 1 A05584 PLATE-SERIAL NUMBER	29	10	712744	Shaft, roller idler, chain	61	8	989910	SCREW FIN HEX 1/4-20 X 5/8 SST
	30	10	712745	ROLLER, IDLER, TABLETOP CHAIN	62	40	989912	SCREW FIN HEX 1/4-20 X 3/4 SST
32 12 712782 SHAFT SPACER CHAIN GUIDE 64 4 C03324 A/W ALL THREAD LEC CONV	31	20	712781	COLLAR,HALF REWORK, 1-1/2 SPLIT, SST	63	1	A05584	PLATE-SERIAL NUMBER
52 12 /12/52 STALL, STACES, CHAIR COIDE 64 6 C00524 A, W, ALL-THISEAD LEG, CONV.	32	12	712782	SHAFT, SPACER, CHAIN GUIDE	64	6	C03324	A/W, ALL-THREAD LEG, CONV.




## Catch Pan Assembly

ITEM #	QTY.	PART#	DESCRIPTION
1	1	118568-030	SHAFT, LOWER CONV. DRIVE, 48"
2	1	611388	BEARING, 1", 2 BOLT FLANGE, SST
3	1	611606	GEARMOTOR, 1/2HP, 400-50-3, RH
4	1	715348	PLATE, GEARMOTOR MOUNT, SEW
5	1	715349	SLEEVE, ENCODER MOUNT, SEW
6	1	715351	PLATE, ENCODER MOUNT, SEW
7	1	716891	PLATE, BEARING COVER
8	1	955470	KEY, SQ 3/16 X 1.00 .002 UNDERSIZE
9	2	955619	NUT HEX NYLOC 5/16-18 UNC SST
10	4	955939	WASHER LOCK 5/16" SST
11	5	955940	WASHER LOCK 1/4" SST
12	2	971206	SCREW SET SOC 1/4-20 X 3/8 SST
13	4	989712	SCREW FIN HEX 5/16-18 X 3/4 SST
14	2	989716	SCREW FIN HEX 5/16-18 X 1 SST
15	5	991312	SCREW FIN HEX M6-1 X 20 MM SST



## Pan Guide Assembly 118568-200


ITEM #	QTY.	PART#	DESCRIPTION
1	2	107026-014	SHAFT, PAN GUIDE, 48" DRIVE
2	1	118568-012	A/W, PAN GUIDE, AUTO, 160S
3	2	118568-013	3" J-LEG, UHMW EXTRUSION
4	1	118568-015	A/W, PAN GUIDE, AUTO, 160S
5	1	118568-018	BRACKET, PROX MOUNT
6	1	118568-201	SHAFT, PAN GUIDE, AUTO, 160" DIS
7	1	118568-202	SHAFT, PAN GUIDE, AUTO, 160"
8	1	304123-001	MOTOR,GEAR,1/8HP,200/230-50/6,3.6:1
9	2	304350-001	SENSOR,PROX,8MM,10-30V,PNP,NC,TURCK
10	1	610953	CONNECTOR, CORD, .2035, DOME, NYLON
11	1	610955	CONNECTOR, SEAL RING, 1/2NPT, POLYETH
12	1	610991	COUPLING, FLEXIBLE SHAFT, 5/8" BORE
13	8	611238	BEARING, 5/8, 2 BOLT FLANGE, SST
14	1	611469-010	ENCODER, .375 THRU BORE
15	4	612307	GUARD, WORM GEAR HOUSING
16	1	710832	SUPPORT, PAN GUIDE SHAFT
17	2	711938	RWK, WORM GEAR
18	2	711939	RWK, WORM STEEL, 5/8" B, 10 D.P.
19	2	712026	SPROCKET, REWORK,35B14, 5/8 BORE
20	1	712735-001	BAR, ROLLER/PROX CLAMP, ADJ.
21	3	712831	SUPPORT, PAN GUIDE SHAFT
22	1	712859	AW, GUARD, PAN GUIDE DRIVE
23	3	712860	BLOCK, BEARING MOUNT
24	2	712861	BLOCK, PAN GUIDE, 1" ACME, LH
25	2	712862	BLOCK, PAN GUIDE, 1" ACME, RH
26	4	712865	BRACKET, PAN GUIDE MNT
27	4	712866	PLATE, PAN GUIDE MNT
28	1	712870	PLATE, MOTOR MOUNT, PAN GUIDE
29	1	712876	STANDOFF, CHAIN GUARD COVER
30	1	712903	BRACKET, PROX MNT, 9840
31	1	712988	BLOCK RWK, BEARING MOUNT
32	2	714869	BLOCK, PROX TRAVEL, SHORT
33	2	716468	CHANNEL, WORM GEAR END PLATE
34	1	C00174	LOCKING NUT, 1/2 NPT, NYLON
35	2	C07626	SENSOR,CABLE,M8,3WIRE,F,QC,90



#### Catch Pans 118568-300

ITEM #	QTY.	PART#	DESCRIPTION
1	2	107026-020	A/W, WATER DEFLECTOR END
2	2	107026-024	A/W, DRIP PAN SUPPORT, 48" CONV.
3	1	107026-026	A/W, CENTER DEFL, WET-DRY, 48"
4	2	107026-028	A/W, CATCH TRAY, 48" CONV.
5	8	712792	COLLAR, HALF REWORK, 2" SPLIT, SST
6	2	A07726	FITTING, PLUG 1/2" PVC

FOLD OUT TO VIEW DRAWING



## Drive Settings/ Electrical Schematics

## Drive Settings

Parameters not listed below should remain at the manufacturer's default values. Verify the Inverter that is installed in your unit before checking the settings below.

	9840/9940													
		SMART TOPP	ER (POWERFLEX 52	25)										
DRV1	Mandrel	DRV2	Automation	DRV3	Duster									
		P031	230 V	P031	230 V									
				P036	1600 RPM									
P041	0.10 Sec	P041	2.00 Sec	P041	0.10 Sec									
P042	0.10 Sec	P042	0.10 Sec	P042	0.10 Sec									
P045	6	P045	6	P045	3									
P046	5	P046	5	P046	5									
P047	15	P047	15	P047	15									
P048	1													
C128	1	C128	1	C128	1									
C129	10	C129	10	C129	10									
C130	10	C130	10	C130	10									
C131	50	C131	50	C131	50									
C132	164	C132	162	C132	165									
C133	255	C133	255	C133	255									
C134	255	C134	255	C134	255									
C135	255	C135	255	C135	255									
C137	10	C137	10	C137	10									
C138	10	C138	10	C138	10									
C139	50	C139	50	C139	50									
C140	1	C140	1	C140	1									
T434	0.2 Sec	T434	0.2 Sec											
T435	0.5 A	T435	0.5 A											

<sup>\*</sup>Power cycle inverter for any changes to take affect.

## Electrical BOM 118568-WD


_					_	_	_	_				_	_			_			_	_		_	_			_					_		_	_				_
OPTION (118568-210645-011-014)	CABLE, YE	0.	ئ	ذ	ئ	DRIVER, PWR-FLEX 525,440-3PH,440-3PH.	خ	SENSOR, PHOTO, DIFFUSE, 500MM, 24VDC	SENSOR, CABLE, M12, 5WIRE, STR	DESCRIPTION	LIFT CIRCUIT (210395-002)	SENSOR, PROX, 8MM, 10-30VDC, PNP, NC	$\overline{}$	$\overline{}$	SUPPRESSOR, TRANSIENT, 25VAC/31VDC	DESCRI	SENSOR CIRCUIT (210397)	C06752-001 SENSOR,PROX,80MM,10-55VDC,PNP,EDDY	SENSOR, CABLE, M12, 5WIRE, STR	DESCRIPT	TER NOZZLE CIRCUIT (210390)	VALVE, APPLICATOR HEAD	CABLE, MICRO-CHANGE, M12, SWIRE, W/SUP	CABLE, BULKHEAD, M12, 5WIRE, F, Q/C.	CABLE, CAP, BULKHEAD, M12, F, Q/C.	DESCRIPTION	LIFT CIRCUIT (210395-001)		-	SENSOR, PROX, 8MM, 10-30VDC, PNP, NC	SENSOR, PROX, 8MM, 10-30VDC, PNP, NC, SM	SENSOR, CABLE, MB, 3WIRE, 90*	CABLE, 16AWG, 4 COND.	DESCRIPTION		•	SENSOR, CABLE, M12, 5WIRE, STR	DESCRIPTION
DUSTER ASSY	304502-003	C07670-001	629200	C07678	304431	612045-004	ر.	611027	304430	PART #	WATER SPLIT LI	304350-001	C07626	304238-001	C05724	14-1	WATER SPLIT	C06752-001	304430	ART #	WATER SPLITTE	612008	610187-002	610169	610174	PART #	WATER SPRAY	304123-001	611393	304350-003	304350-003	C07626		PART #	WATER SPRAY	C06752-001		PART #
- I	-	-	1	-	-	-	-	-	-	ΔĮ	WA	2	2	2	2	ΔI	>	-	,	QTY	×	14	14	14	14	ě	>	-	-	2	1	3	20,	ΔI	>	-	-	ĕ,
MOD*FLOUR	CBL6	PRS30	INTLK2	INTLK2		DRV4	MTR7	PSC3	PSC3 P/0	SYMBOL		PRS18,19	PRS18,19	SOL23,24	SUP23,24	SYMBOL		PRS22	PRS22	SYMBOL		SOL9-16A	SOL9-16A	SOL9-16A	SOL9-16A	SYMBOL		MTDE		PRS15,16	PRS17	PRS15,16,17		SYMBOL		PRS9	PRS9	SYMBOL

MOD* WA	WATER	10ZZ	ZLE CIRCUIT (118568-110) 5 PIC POINTIO 1734 FTH MODILLE
PLC2	M	17227-410 17006-417 17006-418	PLC, FOINTIO, 1734, PWM OUT PLC, POINTIO, 1734, BPT INPUT PLC, POINTIO, 1734, 8PT OUT, PRO
PLC2		612183 612224 612224	PLC, POINTIO, 1734, 4PT OUT, PRO PLC, COMPACTLOGIX, FDP MODULE PLC, COMPACTLOGIX I/O TERMINAL BASE
CR1A-8A CTRL1	2	610404-001 611573 611569	RELAY,TERMINAL MTG,24VDC (WHITE) VALVE,CONTROLLER,DRIVER,PULSAJET VALVE PHILSALET INF FILTER
SOL1-8	- ω ω	612008	VALVE, APPLICATOR HEAD CARI F MICRO-CHANGE M12 5WIRF W/SUP
SOL1-8	0 00 00	6101	CABLE, MICHEAD, M12, SWIRE, F, Q/C. CABLE RAP RUI KHFAD M12, SWIRE, F, Q/C.
SYMBOL MOD* FNC	OL QIY	PART #	SPEAY CIPCLITT (118568—800)
4	-	8568-91	PANIC CINCOLL (118568–410)
TB6	20,	*I	PANEL, ELEC (118988-411) RAIL, DIN, MOUNTING
TB6	18	612545	TERMINAL, BLOCK, DUAL TERMINAL, BLOCK, DUAL, IND
36	9 -		ANCHOR, END CLAMP JUMPER, TERMINAL, 3—POS
36	112		TERMINAL, GROUNDING, TERMINAL MARKERS
CR7,8	2	100-	TELAY, TE
SYMBOL	- ₹		3
FNCO1	-		300
ENCO1		304431	ENCODER, INCREMENTAL, 3 CHANNEL, WD SENSOR, CABLE, M12, 5WIRE, F, QC, 90
MTR2		611906	MOTOR, GEAR, 1/2HP, 230/460–60–3, RH MOTOR, GEAR, 1/2HP, 230/460–60–3, LH
MTR2 SYMBOI	<b>-</b> ≥	304570 PART #	MOTOR,1/2HP,230/460-50/60-3,
600	21	0369 REMOTE	DISCONNECT ENCLOS
SC2	-	611537	AUX. CONTACT, SWITC
SC2 SC2		611538	BULKHEAD, CHANGE—OUT, 14—4, 600V, 15A CABLE, CHANGE—OUT, 14—4, 600V, 15A, 6'
DISC2 SYMBOL	1 VI	304666 PART #	PLATE, MOUNT, SWITCH DESCRIPT
2007	-		R CIRCUIT (210383) ENCODER, DIRECTIONAL, 2 CHANNEL
ENCO3		611249-025 304431	ENCODER, DIRECTIONAL, 2 CHANNEL, WD SENSOR, CABLE, M12, 5 WIRE, F. OC. 90
MTR4		181	MOTOR, GEAR, 1 / 8HP, 100RPM, 3.6:1 MOTOR, GEAR, 1 / 8HP, 100RPM, 3.6:1, WD
PRS10,11	2 2	350-00	OVDC, PNP
SYMBOL	ΔI	# 2	DESCRIPTION FT CIRCUIT (210384)
ENC02		010	SIE FIE
ENC02			SENSOR, CABLE, M12, 5WIRE, F, QC, 90
MTR3	- -	504123-001 611393	MOTOR, GEAR, 1/8HP, 100RPM, 3.6:1 MOTOR, GEAR, 1/8HP, 100RPM, 3.6:1, WD
SYMBOL	5, 0IY	##	CABLE,16AWG,4 COND. DESCRIPTION
ACO	FREO		CIRCUIT CTOR, ETHE
	4 -	3 23	CIRCUIT BREAKER, 3AMP, 600V CIRCUIT BREAKER, CONN—RAIL 18POS.
CB4 P/0 CBL2,7,8	20	$\circ$	CIRCUIT BREAKER,TERMINAL CAP CABLE, YELLOW PATCH,2' SHIELDED
CBL3,4,5 CR2,CR3,CR4	9 3		LE, YELLOW PATCH, 3' SHIELDED AY, TERMINAL MTG, 24VDC (WHITE)
CR2,CR3,CR4 DRV1,2,3	2 5	612045-004	RATION P
FU1,2,3 FU1,2,3	J W -	5 2	HOLDER, AC, 600V, 13/32X1-1/3 LPCC, 20A, 600V, 13/32×1-1/2
SYMBOL	ďΥ	PART #	POWER SUPPLY,340/5/6-24VDC,104,3PH DESCRIPTION

CB7 M1	≥	PA-100 AUI C07650-203 C06702-001	OFILL CIRCUII (210443—001) ICIRCUIT BREAKER, 3AMP, 600V IREAY MOTOR STARTER, 24VDC
MTR6 OL1 PLC1 PRS25		210450 C06735-001 C06597-001 610739 610295	MOTOR, VACUUM, 100 RELAY OVER LOAD, 3PH ADJ, 10—16AMP RELAY OVER LOAD, 3PH ADJ, 15—8. OAMP PP.C.MI, 1500, IN YOUT MODULE GIN 4AUT SENSOR, PROX M12, 3MRE, PNP, NO, QC.
S0125.26 S0125.26 T1 T1 P/O SYMBOL	922-		SENSOK, CABLE, M. Z., SWIKE, 30 SENSOK, CABLE, M. B., SWIKE, 30 SENSOK, CABLE, M. B., 3WIRE, 90 TRANSFORMER, 1. SKVA, 190/480—50/60 TRANSFORMER, MOUNT, PLATE (A06997) DESCRIPTION
PRS20.21 PRS20.21 PRS20.21 PRS20.21 PRS20	000	C07670 304431 304268 A05038 A05018	SENSOR, PROX, 30MM, 10—30VDC, PNP, N.C. SENSOR, CABLE, M12, 5WIRE, 90 SENSOR, PROX, MOUNT BLOCK SENSOR, PROX, MOUNT PLATE, EMPTY SENSOR, PROX, MOUNT PLATE, LOW
SYMBOL PL* PL*	¥	1 1 1 1 1 1	DESCRIPTION CONNECTOR, TWISTLOCK, MALE 3POLE CONNECTOR, TWISTLOCK, FEMALE, 3POLE COVER, WEATHER PROOF (113393) COVER, WEATHER PROOF (A05379)
PRS14 PRS14 SYMBOL	<u> </u>	PER DUMP \( \) 610962 \( 611267 \) 611268 \( \) PART #	2 4 NN MO
SOL21 SYMBOL ASS	SY,EN	AGITATOR 611365 PART # CLOSURE, SEE	9-001/002) 0.24VDC.2 WAY SRIPTION 10386-003/004)
ENCL3 PNL3 PSC1/PRS14 SOL 19/21		715536-00 715536-002 P/0 ENCL3 304430 611364	ENCLOSURE, REWORK, SEED HOPPER L/H JENCLOSURE, REWORK, SEED HOPPER R/H PANEL, ELEC, REWORK, SEEDER, HOPPER SENSOR, CABLE, M.12, 5WIRE, STR VALVE, SOLE HOUD, BASE WANTE, SOLE HOUR J. R. BOBT 24/DC
SUP 19-22 TB5 TB5 TB5 TB5	4 2 2 2 4 t	610362 610361 610362 610363 610363	VÄRISTOR, SURGE, 125A, 25VAC, 31VDC RAIL, DIN, MOUNTING, MINI TERMINAL, BI OCK, MINI END COVER, TERMINAL, MINI ANCHOR, END CLAMP, MINI ANCHOR, END CLAMP, MINI
SYMBOL AS	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	610534 303056 C07066 PART #	TERMINAL GROUNDING MINI PLUG HOLE SST 7/8 DIA. CABLE 22AWG 25 COND. DESCRIPTION
NTLK1 NTLK1 NTLK1 PRS1-4(5) PSC1 PRS12	5	C07219 C07220 C07220 610151 611027 C06752-00	K (2 10404–007 / 1005 / 005 / 010) INTER LOCK MAGNETIC.KEYED ACTUATOR MAGNET SENSOR, PROX. 6. 5MM, 10—30VDC. PNP. NO SENSOR, LASER, RETRO—REF. 10—24VDC SENSOR, PROX. 80MM, 10—55VDC. PNP. EDDY
SYMBOL	QIT ASSY,	304239 PART # SEEDER FRAI 611603	CLUTCH,SHAFT MTG,24VDC   DESCRIPTION   ME (210381/210382-007/008)   MOTOR,1/34P,230/460-50/60-3.LH
PRS6.7		304570 304570 304350-001 C07626 712217	MOTOR, 1/24P, 230/460-30/80-3.KH MOTOR, 1/24P, 230/460-50/60-3.WD SENSOR, PROX. 8MM, 10-370/DC, PNP.NC SENSOR, CABLE, M8, 3WIRE, 90' BRACKET, HEIGHT, ADJ, PROX.
PRS13 PRS13 SOL17.18		504022 610962 611267 611119 C07626	ANGLE, PROX MOUNTLIFT CIRMBA) SENSOR, REED, 3WIRE, 24VDC (SIMBA) SENSOR, REED, 2WIRE, 24VDC (SIMC) SENSOR, REED, 2WIRE, 24VDC SENSOR, REED, 2WIRE, 24VDC VALVE, SOLEMOID, DUAL, 24VDC SENSOR, CARLE MR, 3WIRE, 30°
	123.20	610360 610361 610362 610363	RAIL DIN, MOUNTING, MINI TERMINAL, BLOCK, MINI END COVER, TERMINAL, MINI ANCHOR, END CLAMP, MINI JUMPER, TERMINAL, 10 - POS, MINI
SYMBOL MO	6, 0TY 0*AS	710161 C01237 PART # SY,ENCLOSUR	TERMINAL STRIP COVER CABLE, 2AWG, 15 COND. DESCRIPTION E, DISPLAY (118568–210401–001/002)
CBL1 DISP1 ENCL2 ENCL2		304502-014 612563 115704-901 712044	CABLE YELLOW PATCH, 14FT SHIELDED PIC, DISPLAY, PANELVIEW + 700, ETHERNET A/W, ENCLOSURE, DISPLAY, 9940 L/H A/W, TRICLAMP, 1.50"
ENCI2 P/0	<del>-</del>	610/60 C07/16 111231 C07/15 C05/39/	GASKET I FET FOWN 1.50 NAMEPLATE POWER ON 8001 BULB REPLACEMENT 24VDC 800E LED SWITCH PUSH/PULL RED MUSHROOM 800T NAMEPLATE PUSH STOP / PULL START
SYMBOL	20 <u>,</u>	610967 113315 C07277 PART # 10122 ASSY	I ERMINAL BREAK A – PART, 12POS.  DECAL_24 VOLTS  CABLE, 20AWG, 8COND.  DESCRIPTION  DISC – ROX ARC. FI ASH
DISC1 DISC1 ENCL5 FU1.2.3 GND	1W	C07631 C07632 C07633 C07740 C07062 C07062	UISCONNECT.CIRCUIT BREAKER.FUSIBLE TOISCONNECT.CIRCUIT BREAKER.HANDLE DISCONNECT.CIRCUIT BREAKER.SHAFT ENCLOSURE.FWORK,SST FUSE.LPCC.20A,600V,13/32x1-1/2 LUG.GROUNDING.ENCLOSURE
SYMBOL MOD*	OTY ASSY, REF	C07741 PART # MAIN ENCLOS 210122 C07649_010	PANEL, ELEC, REWORK  DESCRIPTION SURE CIRCUIT (118568-210400-BBU) ASSY, DISC-BOX ARC FLASH
CBL1,2,7,8 CRM,CR9,CR10 CR1,CR5-8,10 CR 1 1	4//-	504466 504466 610404-001 610452-001	CIRCUIT BREAKER, 230V. 104MP CONNECTOR, X1–45 CAT5 RELAY, TERMINAL MTG. 24VDC (WHITE) RELAY, TERMINAL MTG. 24VDC (BLACK) RELAY, TERMINAL MTG. 110VAC (BLACK)
CRM.1-11 P/C CRM.1-11 P/C CRM.1-11 P/C CRM.1-11 P/C	-0	610387-001 610387-001 610443-011 610443-012 304425	RELAY IERMINAL MIG. 220VAG. (BLACK) RELAY IERMINAL MIG. SEPARATION PLATE RELAY IERM JUMPER. 32A. 500MM. RED RELAY IERM JUMPER. 32A. 500MM. BLUE RELAY IERM JUMPER. 32A. 500MM. GREY ENCLOSURE, REWORK, MAIN (304460)
ENCL1 EXC1 EXC1 FB21,22,23,24 FB24 P/0 FU21,22,23	4-N	611811 610741-001 611163 C06731 C06732 111925	ENCLOSURE. LOCK. COVER. 1/4 TURN HEAT EXCHANGER. 24VDC HEAT EXCHANGER. AR FILTER, HOUSING FUSE. HOLDER. AC. 70C. 1/4x1—1/4 FUSE. HOLDER. FUSE. FUSE. HOLDER. FUSE. HOLDER. SA. 250V, 1/4x1—1/4 FUSE. MDL. 5A. 250V, 1/4x1—1/4
FU24 GND HUB1 LT2/AH1		111667 C06488 304500 611591 C01298-004	FUSE,MDL,1A,250V,1/4×1-1/4 GROUND LUG EPLCETHERNET MODULE,N-TRON LIGHT TREE,24VDC,W/HORN TOP MTG LIGHT TREE,MODULE,BLUE
		610494 611937 610682 610632 611722	PIC.COMPACTIOGX.END.CAP IPIC.COMPACTIOGX.PROCL.30FR.1M IPIC.COMPACTIOGX.PROF.BED.COUNTER PIC.COMPACTIOGX.POWER SUPPLY.PB4 IPIC.COMPACTIOGX.POWER SUPPLY.PB4 IPIC.CP.OUTPUT MODULE.16 OUT
	1-28-180	304463 C06387 C05843 C06369 C06461	
188   188	772 <mark>00</mark> 00	CUP492 CO6463 CO6464 CO6465 CO6525 CO7117-00	END COVER, IERMINAL JUMPER, TERMINAL, 10—POS RAIL, DIN, MOUNTING ANCHOR, END CLAMP TERMINAL, GROUNDING TERMINAL, GROUNDING
TB2	1 12" 18"	611660 611661 611661 C07687 C06739	TERMINAL END COVER DUAL, 10AWG NOLTAGE PRE-TEST POINTS KIT VOLTAGE VISION (R-3W) KIT DUCT,WIRE.1, x 1, x 6 DUCT,WIRE.1, x 2, x 6 DUCT,WIRE.1, x 2, x 6
SYMBOL	156" QTY	C07689 PART #	DÚČÍ, COVER, WÍRE, 1" × 6' DESCRIPTION

Electrical Ladder

# Electrical Ladder 118568-WD



Electrical Layout 118568-WD Electrical Layout

