

Important--Use These Remote Codes

The codes on this sheet supersede the codes in the user's guide. Please refer to your user's guide for the instructions on how to program the remote using these codes. The remote is already programmed to operate most PROSCAN, RCA, and GE product.

TV	
Abex	1172
Admiral	1001, 1173
Adventura	1174
Aiko	1016
Akai	1002
Alleron	1046
Amtron	1038
Anam National	1003, 1038
AOC	1004, 1005, 1006, 1007, 1175, 1176
Audiovox	1038
Belcor	1004
Bell & Howell	1001, 1083, 1162
Bradford	1038
Brokwood	1004
Candle	1004, 1006, 1008, 1174
Capohart	1175
Celebrity	1002
Centurion	1009
Citizen	1004, 1006, 1008, 1016 1038, 1105, 1171, 1174, 1177
Clairtone	1176
Colortyme	1004, 1006
Concerto	1004, 1006
Contec/Cony	1012, 1013, 1014, 1038, 1176
Craig	1038
Crown	1038, 1171
Curtis Mathes	1000, 1004, 1006 1015, 1105, 1162, 1171
CXC	1038
Daewoo	1004, 1005, 1006, 1016 1017, 1018, 1127, 1171
Daytron	1004, 1006, 1171
Dimensia	1000
Dumont	1004, 1151
Dynatech	1178
Electroband	1002, 1176
Electrohome	1003, 1004, 1006, 1019, 1022
Emerson	1004, 1006, 1012 1014, 1023, 1024, 1025, 1026, 1027, 1028, 1029 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037 1038, 1039, 1041, 1042, 1043, 1044, 1046, 1047 1123, 1124, 1162, 1171, 1176, 1177, 1179, 1191
Envision	1004, 1006
Fisher	1048, 1049, 1050, 1051, 1162, 1180
Fujitso	1046
Funai	1038, 1046
Futuretec	1038
GE	1000, 1003, 1004, 1006, 1022, 1052, 1054 1055, 1087, 1164, 1165, 1166, 1167, 1168, 1181
Gibraltar	1004, 1151
Goldstar	1004, 1005, 1006, 1012, 1019 1056, 1057, 1058, 1155, 1156, 1171, 1172
Grundig	1038, 1046, 1171
Hallmark	1004, 1006
Harvard	1038
Hitachi	1004, 1006, 1012, 1013, 1059, 1060, 1061 1135, 1136, 1137, 1138, 1139, 1140, 1141 1142, 1143, 1144, 1145, 1146, 1148, 1150, 1179
IMA	1038
Infinity	1062
Janeil	1174
JBL	1062
JCB	1002
JC Penny	1000, 1004, 1005, 1006, 1008 1022, 1052, 1054, 1058, 1063, 1064 1072, 1087, 1105, 1128, 1171, 1172, 1181
Jensen	1004, 1006
JVC	1012, 1013, 1054, 1060, 1065 1066, 1067, 1089, 1157, 1158, 1159, 1182
Kawasho	1002, 1004, 1006
Kaypani	1175
Kenwood	1004, 1006, 1019
Kloss Novabeam	1068, 1069, 1174, 1183
KTV	1038, 1070, 1171, 1176, 1177
Loewe	1062
Logik	1083
Luxman	1004, 1006
LXI	1000, 1006, 1049, 1062 1071, 1072, 1073, 1162, 1181
Magnavox	1004, 1006, 1008, 1019, 1062, 1068, 1069, 1074, 1075, 1076, 1077, 1088, 1089 1130, 1131, 1132, 1133, 1134, 1183, 1184
Majestic	1083
Marantz	1062
Marantz	1004, 1006, 1062, 1078
Megatron	1006, 1059
MEI	1176
Memorex	1001, 1006, 1082, 1083, 1162
MGA	1004, 1005, 1006, 1019 1022, 1051, 1079, 1080, 1082
Midland	1054, 1151, 1171, 1172, 1181
Minutz	1052
Mitsubishi	1004, 1005, 1006, 1019, 1022 1051, 1079, 1080, 1081, 1082, 1083, 1125
Montgomery Ward	1083
Motorola	1003, 1173
MTC	1004, 1005, 1006, 1105, 1176, 1178
Multitech	1038, 1178
Multivision	1084
NAD	1006, 1071, 1072, 1185
NEC	1003, 1004, 1005, 1006, 1089
Nikko	1006, 1016
NTC	1016
Onwa	1038
Optimus	1185
Optonica	1095, 1173
Orion	1035, 1191
Panasonic	1003, 1054, 1062, 1170
Philco	1003, 1004, 1005, 1006, 1008, 1012, 1019 1062, 1068, 1069, 1074, 1075, 1077, 1183, 1184
Philips	1003, 1004, 1008, 1012, 1019, 1062, 1068 1069, 1074, 1075, 1076, 1086, 1087, 1088, 1089
Pilot	1004, 1171
Pioneer	1004, 1006, 1090, 1091, 1092, 1179, 1185
Portland	1004, 1005, 1006, 1016, 1171
Price Club	1105
Prism	1054
PROSCAN	1000, 1181
Proton	1004, 1006, 1012, 1093, 1175
Pulsar	1151
Pulser	1004
Quasar	1003, 1054, 1070, 1094
Radio Shack/Realistic	1000, 1004, 1006, 1012 1038, 1049, 1095, 1162, 1171, 1172
RCA	1000, 1003, 1004, 1005, 1006, 1007 1019, 1096, 1098, 1099, 1100, 1101, 1102, 1103 1129, 1179, 1181, 1187, 1188, 1190, 1198, 1199
Rhapsody	1176
Runco	1151
Sampo	1004, 1006, 1171, 1172, 1175
Samsung	1004, 1005, 1006, 1012, 1015 1019, 1104, 1105, 1106, 1171, 1172
Samsux	1171
Sansui	1191
Sanyo	1004, 1048, 1049, 1050 1080, 1107, 1108, 1162, 1180, 1189
Scotch	1006
Scott	1004, 1006, 1012, 1024, 1035, 1038, 1046
Sears	1000, 1004, 1006, 1013, 1019 1046, 1048, 1049, 1050, 1051, 1066 1071, 1072, 1109, 1110, 1162, 1180, 1181, 1189
Sharp	1004, 1006, 1012, 1029, 1095 1111, 1112, 1113, 1122, 1171, 1173
Shogun	1004
Signature	1001, 1083, 1115
Simpson	1008
Sonic	1176
Sony	1002
Soundesign	1004, 1006, 1008, 1038, 1046
Squareview	1189
SSS	1004, 1038
Starlite	1038
Supre-macy	1174
Supreme	1002
Sylvania	1004, 1006, 1008 1019, 1062, 1068, 1069, 1074, 1075 1076, 1077, 1088, 1116, 1161, 1183, 1184
Symphonic	1033, 1038, 1189
Tandy	1173
Tatung	1003, 1178
Technics	1054
Techwood	1004, 1006, 1054
Teknika	1004, 1005, 1006, 1008, 1012, 1013, 1016 1038, 1046, 1076, 1082, 1083, 1105, 1170, 1171
Telecaption	1117
TMK	1004, 1006
Toshiba	1049, 1071, 1072, 1089 1105, 1109, 1117, 1118, 1160, 1162
Totevision	1171
Universal	1052, 1087
Victor	1066, 1182
Vidtech	1004, 1005, 1006
Viking	1174
Wards	1000, 1001, 1004, 1005, 1006, 1019, 1024 1033, 1046, 1052, 1062, 1069, 1074, 1075 1076, 1083, 1087, 1088, 1095, 1119, 1120, 1184
Yamaha	1004, 1005, 1006, 1019
Zenith	1004, 1083, 1151, 1152, 1153, 1154

RCA

USER'S GUIDE

satellitereceiversatellitereceive
rsatellitereceiversatelliterecei
versatellitereceiversatelliterec
eiversatllitereceiversatelliterecei
versatellitereceiversatelliterece
iversatellitereceiversatelliterec
eiversatellitereceiversatellitere
ceiversatellitereceiversatelliter
eceiversatellitereceiversatellite
receiversatellitereceiversatellit
ereceiversatellitereceiversatell
itereceiversatellitereceiversatel
litereceiversatellitereceiversate
litereceiversatellitereceiversate
litereceiversatellitereceiversate
littereceiversatellitereceiversat
ellitereceiversatellitereceiversa
tellitereceiversatellitereceivers
atellitereceiversatellitereceiver
satellitereceiversattelitereceive
rsatellitereceiversatellitereceiv
ersatellitereceiversatelliterecei
versatellitereceiversatelliterec
eiversatellitereceiversatellitere
ceiversatellitereceiversatellite
receiversatell iterec
eitorsatellite rece
iversatellite re
ceiversa te
littere cei
versat ellit
ereceiv ers
atellite r
eceive



SAFETY INFORMATION

WARNING

To reduce risk of fire or shock hazard, do not expose this receiver to rain or moisture.

WARNING

RISK OF ELECTRIC SHOCK
DO NOT OPEN



This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.



This symbol indicates important instructions accompanying the product.

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Cautions

Do not stack electronic components or other objects on top of the receiver. The slots on top of the receiver must be left uncovered to allow proper airflow to the unit. Blocking the airflow to the unit could impair performance or damage your receiver and other components.

Do not stack the receiver on top of a "hot component" such as an audio power amplifier.

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.

Note to Cable TV Installer:

This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Note to Satellite Dish Installer:

This reminder is provided to call your attention to Article 810 and in particular article 810-15 of the National Electrical Code which covers proper installation and grounding of television receiving equipment as well as to article 820-40 of the National Electrical Code which specifies that the satellite dish cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

IMPORTANT NOTICE:

This device incorporates an anticopy process technology that is protected by U.S. patents and other intellectual property rights. The anticopy process is licensed for non-commercial, home use only. Reverse engineering or disassembly is prohibited.

Care and Cleaning:

Use a soft cloth or the dusting attachment of your vacuum cleaner to dust your receiver. Remove dust from the ventilation holes on the top and bottom.

Plastic surfaces are easily scratched and can be marred by alcohol and various solvents. Avoid excessive use of oil-based furniture polishes since the materials used in the cabinet will accumulate more dust. A non-abrasive, anti-static cleaner/polisher is recommended.

Product Registration

Please fill out the product registration card and return it immediately. Returning the card allows us to contact you if needed.

Keep your sales receipt to obtain warranty parts and service and for proof of purchase. Attach it here and record the serial and model numbers in case you need them. The numbers are located on the back of the player.

Model No. _____

Serial No. _____

Purchase Date: _____

Dealer/Address/Phone: _____

TABLE OF CONTENTS

Setup and Connections	3
Step 1: Unpack the System	4
Step 2: Connect Your Receiver to Your TV and VCR.....	4
Things to Know Before Connecting Components	4
Jacks and Cables.....	5
Back of the Receiver	6
Basic Connection	7
Advanced Connection	8
Step 3: Find the Video Input Channel on your TV.....	10
Step 4: Interactive Setup	10
Step 5: Place Batteries in the Remote Control	10
Step 6: Plug in and Turn on the System	10
Step 7: Order Programming	10
Using the Remote	11
Remote Control Buttons	12
The Point and Select Method	13
Programming the Remote Control	13
Testing the Remote	13
Modes of Operation	14
Program Guides	15
Anatomy of a Program Guide	16
Bringing Up the Program Guides	16
The Channel Banner.....	17
Using the GUIDE Button	18
Getting Around in the Guides	18
Tuning to a Program	19
Additional Program Guides	20
Sorting the Guides	22
The Menu System	27
Using the Menu System	28
Back and Help	28
Menu Descriptions	29
The Mailbox	31
How to Tell When You Have Mail	31
Checking your Mail	31
Pay-Per-View Programs	32
Purchasing and Previewing	32
Tuning to a PPV Program	32

TABLE OF CONTENTS

Using the Attractions Guide	33
Using the Purchases Menu	34
Reviewing and Canceling an Upcoming Purchase	35
Spending Limits	35
Timers Feature	36
Profiles	36
Creating a Profile Channel List	37
Setting the Ratings Limit	37
Viewing Hours	38
Setting Up Spending Limits	39
Locking a User’s Profile	39
Locking the System	40
Choosing Your Profile	41
Options	41
Look and Feel	42
System Options	43
Audio Language	43
Alternate Data	43
The Dish Pointing Menu Screen	44
Using the On-Screen Signal Meter	45
Home Control	46
Edit Fetch Menu	48
Customizing the Fetch Menu	49
Customizing the FETCH Button	50
Tips & Troubleshooting	51
Appendix A: Warranty Information	55
Appendix B: FCC Regulations	58
Appendix C: Accessories	59
Index	61

StarSight-Licensed: The manufacture and sale of the television schedule feature of this product was licensed under one or more of the following patents of StarSight Telecast, Inc.; U.S. Patent Nos. 4,706,121; 4,977,455; 5,151,789; 5,335,277; and 5,353,121.

SETUP AND CONNECTIONS

GETTING STARTED

This manual is designed to get you started quickly. The first three sections of the manual introduce you to your satellite system and show you how to use the on-screen guides and menus.

In *Setup and Connections*, you'll learn:

- about the jacks and cables
- things to know before connecting the components
- different ways to connect the receiver to your TV
- how to order programming

Using the Remote defines the buttons of the remote and how to program it.

Program Guides details the items and features associated with the different guides.

THE REST OF THE MANUAL

The rest of the book includes menu information, troubleshooting information—such as running a system test—and an index.

1 SETUP AND CONNECTIONS



2 USING THE REMOTE



3 PROGRAM GUIDES



4 THE MENU SYSTEM



5 TIPS & TROUBLESHOOTING

SETUP AND CONNECTIONS

STEP 1: UNPACK THE SYSTEM

Make sure to locate the remote control.

STEP 2: CONNECT YOUR RECEIVER TO YOUR TV AND VCR

During the satellite dish antenna installation, the receiver may have been connected to your TV with just a coaxial cable for the system test. Depending on what components you have, another connection may provide better picture and audio quality. The following sections provide cable and connection information to help you decide what connection is best for you.

THINGS TO KNOW BEFORE CONNECTING COMPONENTS

Protect Your Components from Power Surges

- Connect all components before plugging any power cords into the wall outlet.
- Always turn off the receiver, TV and other components before you connect or disconnect any cables.

Position Cables Correctly to Avoid Audio Hum or Interference

- Insert all cable plugs firmly into their jacks.
- Place the audio/video cables to the sides of the TV's back panel instead of straight down the middle after you connect your components.
- Try not to coil any twin-lead cables and keep them away from the audio/video cables as much as possible.
- Make sure all antennas and cables are properly grounded. Refer to the Safety sheet packed with your unit.

SETUP AND CONNECTIONS

Protect Your Components from Overheating

- Do not block ventilation holes in any of the components. Arrange the components so that air can circulate freely.
- Do not stack components.
- Allow adequate ventilation when placing your components in a stand.
- Place an amplifier or receiver on the top shelf of the stand so heated air rising from it will not flow around other components.

JACKS AND CABLES

Below is a description of the jacks and cables you can use to make connections. Note that not all cables may come with your system.

S-Video Jack and Cable

The S-Video jack provides the best picture quality for your system.

This jack is available on many TVs and is used in conjunction with audio cables to connect the receiver to your TV. Remember also to connect the left and right audio cables because the S-Video jack carries only the picture signal, not the sound.



S-Video Jack




RF Jacks and Coaxial Cables (F-type)

The RF jacks provide good picture and mono sound quality, and are to be used if audio/video connections are not available for your TV.

These jacks are required for antenna or cable-TV connections. The RF jacks on the receiver are labeled IN FROM ANT and OUT TO TV.




RF Jack



SETUP AND CONNECTIONS


BACK OF THE RECEIVER

The diagram below describes each of the back panel jacks found on your receiver. When connecting A/V cables, be sure to connect corresponding OUTPUTS and INPUTS (Video to Video, Right Audio to Right Audio, etc.).



SETUP AND CONNECTIONS

BASIC CONNECTION



How to View Your Components

To watch programming received via satellite with this connection, tune the TV to either channel 3 or 4. (The default is channel 3. You may change the output channel to 4 by choosing *Systems Options* from the Main menu and selecting *Output Channel*.)

To record programming, tune the receiver to the desired channel and set your VCR to record on channel 3 or 4.


To view VCR recordings, tune the TV to the VCR output channel (usually CH 3 or 4) and set your VCR to play. If your VCR is a brand other than RCA, GE, or ProSCAN, you may need to program the remote to control the VCR. See the next section, "Programming the Remote."

CAUTION

Do not stack electronic components or other objects on top of the receiver. See "Safety Information" inside the front cover.

SETUP AND CONNECTIONS

ADVANCED CONNECTION



How to View Your Components

To watch the satellite receiver in this connection, tune the TV to the video input channel. (To find your TV's video input channel, follow Step 3 on the next page). Then tune the receiver to the desired channel.

To record programming, tune the receiver to the desired channel. Then set your VCR to record on channel 3 or 4.

To view VCR recordings, tune the TV to the VCR output channel (usually channel 3 or 4) and set your VCR to play. If your VCR is a brand other than RCA, GE, or ProSCAN, you may need to program the remote to control the VCR. See the next section, "Programming the Remote."

CAUTION

Do not stack electronic components or other objects on top of the receiver. See "Safety Information" inside the front cover.

SETUP AND CONNECTIONS

STEP 3: FIND THE VIDEO INPUT CHANNEL ON YOUR TV

- Note: You do not need to complete this step if you used the basic connection.

If you used the advanced connection, you must tune your TV to the video input channel to see the satellite screens. Since there are so many brands and models of TVs, there are just as many ways to access a TV's video input channel. Below are some things you can try.

- If your TV brand is RCA, GE, or PROSCAN, press TV on the remote that came with your receiver. Then press the WHO•INPUT button on the remote.
- If your TV brand is not RCA, GE, or PROSCAN, consult your TV Owner's Manual.

If you cannot find your TV Owner's Manual, you will have to investigate. You might access the TV's video input channel by:

- pressing a button on the remote
- finding it through the TV's menu system
- tuning directly to it by pressing a specific channel number
- going through all channels in the list by pressing the channel up or down buttons on the TV

Below are lists of some of the different ways manufacturers label the video input channel.

Video Channel Variations

Button/switch on the TV	Button on the TV Remote	Channel #
VIDEO	VID 1	00
SIGNAL	LINE	90
VID 1	VID	91
VID 2	VIDEO	92
S-VID	S-VID	VID 1
S-VIDEO	INPUT	VID 2
	SOURCE	
	AUX	

Signal Flow

The whole idea of choosing a video input channel can be explained by the way the signal flows through your components and ends up as a picture on your TV screen.

To learn more about how signal flow works, see the example in the "Troubleshooting" section.

SETUP AND CONNECTIONS

STEP 4: INTERACTIVE SETUP

If you self-installed your satellite dish antenna, you may have already used the interactive setup to find the dish pointing coordinates, acquire and fine-tune the signal, and run a system test.

If you need to run the interactive setup again, select *Options* from the Main menu, then select *Interactive Setup*.

If you did not self-install the satellite dish antenna, you may just want to check your dish pointing coordinates, or run the signal strength meter. Select *Dish Pointing* from the Main menu.

STEP 5: PLACE BATTERIES IN THE REMOTE CONTROL

Follow these steps whenever you need to install or change the batteries in your receiver remote.

1. Remove the cover from the battery compartment.
2. Insert batteries in the battery compartment, matching the + and – end of each battery.
3. Replace the cover.

STEP 6: PLUG IN AND TURN ON THE SYSTEM

Plug the end into the wall outlet, matching the wide blade of the plug with the wide slot in the outlet. Be sure to insert the plug completely.

To turn on the system, press the DIRECTV button on the remote or the ON•OFF button on the front panel. If your TV brand is RCA, GE, or PROSCAN, press the TV button on the remote to turn on the TV. If your TV brand is not RCA, GE, or PROSCAN, see the next section, "Using the Remote," for details on how to use the remote to control your TV.

STEP 7: ORDER PROGRAMMING

After you have installed your system, you should contact the service providers, DIRECTV or USSB, to receive programming.

Programming with DIRECTV: Call 1-800-347-3288

Programming with USSB: Call 1-800-204-USSB

When you order programming, you need to know your Access Card number. To get the number, select *Options* from the Main menu, then *System Options*, and then select *System Test*.

Wait for the system to run all of its tests. The Access Card number is displayed at the end of the system test.

Write the Access Card number in the space below for easy reference:

USING THE REMOTE

HOW TO USE YOUR UNIVERSAL REMOTE

This section defines the buttons on the remote and describes how to program it.

The universal remote can be programmed to control most brands of remote controllable TVs. If you have an RCA, GE, or ProSCAN TV, you probably don't need to program it at all.

1 SETUP AND CONNECTIONS



2 USING THE REMOTE



3 PROGRAM GUIDES



4 THE MENU SYSTEM



5 TIPS & TROUBLESHOOTING

USING THE REMOTE

REMOTE CONTROL BUTTONS

ON•OFF Turns the device you are controlling on or off. You can also use the power button on the top of the receiver to turn it on and off.

DIRECTV Tells the remote to control the satellite receiver.

TV Tells the remote to control the TV.

VOL UP/DOWN Adjusts the audio volume.

FETCH Either brings up the Fetch menu or executes the function you assign to the button.

CHAN UP/DOWN Use to scan up and down through the channels in the current channel list. If you are in the program guide or menu system, use the CHAN UP/DOWN buttons to page up and down a screen at a time. You can also use the CHAN UP/DOWN buttons on the top of the receiver to change channels.

MUTE Reduces the TV's volume to its minimum level. Press again to restore the volume.

GO BACK Moves you back and forth between your last two selected channels. In the menu system, returns you to the previous screen.

GUIDE Brings up the on-screen program guide. Press the GUIDE button several times to toggle through the different types of guides.

INFO Brings up the on-screen channel banner. Press again to get program details.

ARROWS Use the navigation arrows to move the on-screen highlight up, down, left, or right. Using the arrows to highlight a menu item is also called "pointing."

OK Selects a highlighted choice in the menu system.


MENU Brings up the Main menu. If you are already in the menu system, press OK or MENU to select a highlighted choice.

CLEAR Removes the on-screen displays and returns to normal viewing.

DIGIT KEYS (0 - 9) Use the digit keys to tune directly to a channel. If you are in the menu system, use the digit keys to enter numbers for the time, date, channel and passwords.

WHO•INPUT Press the WHO•INPUT button one or more times to toggle through your user profiles. It also accesses the line input channel.

ANTENNA Lets you switch the source of the video signal from satellite signals to an off-air antenna or cable signal when using the OUT TO TV jack.



USING THE REMOTE

THE POINT AND SELECT METHOD

Point and Select is the two-step method you use to navigate through the satellite system's menu system and program guides. Once you know how to point and select, you can explore the menus.

1. Point


You point by pressing the arrow keys on the remote. Pressing the arrow keys moves the on-screen highlight to different items in the program guide and the menu screens. Pressing an arrow once moves the highlight one space in the direction of the arrow.

For example, to point down (that is, to move the highlight toward the bottom of the screen), press the down arrow. To point right, press the right arrow.

2. Select

Once you have pointed to an item on the screen, select it by pressing the OK button on the remote. Selecting an item tells the menu system to go ahead and make the change you have indicated.

For example, the instructions in the User's Manual might tell you to Point to the *Back* button and press OK.



PROGRAMMING THE REMOTE CONTROL

The satellite receiver's remote can be programmed to control most brands of remote controllable TVs. The remote is programmed to control most RCA, GE and ProSCAN TVs. The remote needs to be programmed to control other manufacturers' brands.

TESTING THE REMOTE

To determine whether the universal remote needs to be programmed, turn on the TV, point the remote at the TV, and press the TV button. Then press ON•OFF or CH ^ (channel up) or CH v (channel down) to see if the TV responds to the remote commands. If not, the remote needs to be programmed.

PROGRAMMING THE REMOTE

1. Turn on the TV.
2. Look up the brand and code number(s) for the component on the code list on the next page.
3. Press and hold the TV button.
4. Enter the code from the code list.

Don't worry about getting stuck inside a menu. Pressing the CLEAR button on the remote takes you out of the menu system and back to the program you were watching.

This remote may not operate all models of the brands that are shown. Use the codes shown in this manual, or on the sheet packed with your remote.

USING THE REMOTE

- Release the button, and then press ON•OFF to see if the component responds to the remote commands. If it doesn't, try pressing the component button and then ON•OFF again.
- If you get no response, repeat these steps using the next code listed for your brand until the component responds to the remote commands.

MODES OF OPERATION

Because this universal remote can control both the TV and the receiver, it uses operational modes triggered by the component buttons. For example if you want the remote to control the TV, you would press the TV button to put the remote into TV mode before you can control the TV.

TV Codes

A-Mark	102	Mitsubishi	006,011,014,019,022,027,041,055,056,061,068,108
Admiral	005,114	MTC	011,019,027
Amtron	064	Multivision	081
Akai	002,103	NAD	018,023
Anam	104,105	NEC	011,014,019,027,038,084
Anam National	038,106	Panasonic	012,013,038,086,111
AOC	011,019,027,088,107	Penney	000,008,011,019,027,040,068,077,086,088
Bell&Howell	005,013	Philco	006,007,010,011,013,016,019,027,033,035,037,038,043,087,089
Candle	011,027,033	Philips	002,006,007,010,011,013,016,033,035,037,038,043,066,073
Citizen	011,027,033,064	Pioneer	011,027,045,062,093,113
Colortyme	011,027,084	Portland	011,019,027,037
Concerto	011,027	ProScan	000
Contec/Cony	036,037,040,042,064	Proton	011,027,037,072
Craig	064	Quasar	012,038,092,111
Curtis Mathes	000,011,015,027,037	Radio Shack	000,021,025,036,037,059,064,078
CXC	064	RCA	000,006,011,019,027,034,038,044,046,088,100,101,109
Daewoo	011,019,027,0112,116	Realistic	021
Daytron	011,027	Sampo	011,027
Dimensia	000	Samsung	006,011,014,015,019,027,036,037,077,110
Electrohome	006,011,014,027,038,061,068	Sanyo	017,021,039,056,057,058
Emerson	011,026,027,028,029,030,031,032,037,042,053, 064,065,067,075,076,078,079,094,095,096	Scott	028,037,064
Envision	011,027	Sears	000,006,011,014,017,018,021,023, 027,039,040,041,051,071,083,095
Fisher	017,021,039,041	Sharp	011,020,025,027,037,052,053,059,060,108
Funai	064	Signature	005,094,108
GE	000,008,009,011,012,027,038,068,086,089,091,116	Sony	002
Goldstar	003,004,006,011,019,027,037,050	Soundesign	011,027,033
Hallmark	011,027	Sylvania	006,007,010,011,013,016,027,033,035,043,049,066,087,089
Hitachi	009,011,027,036,037,040,047,048,063,080,094,097,098	Symphonic	064,076,115
Infinity	013	Tatung	038
JBL	013	Technics	012
Jensen	011,027	Techwood	011,027
JVC	012,024,036,037,040,048,051,074	Teknika	011,019,027,033,036,037,040,066
Kawasho	002,011,027	Telecaption	090
Kenwood	006,011,014,027	TMK	011,027
Kloss Novabeam	035,043	Toshiba	018,021,023,040,071,077,085,090
KTV	078	Universal	008,009
Loewe	013	Victor	051
Luxman	011,027	Vidtech	019,027
LXI	000,013,018,021,023,054	Wards	000,005,006,007,008,009,010,011,013,019,025,027,028,035, 043,059,066,076,082,089
Magnavox	006,007,010,011,013,016,027,033,035,043,049,066,087,089	Yamaha	006,014,019,027
Marantz	013	Zenith	001,099,114
Marantz	011,013,027,069		
Memorex	005		
MGA	006,011,014,019,022,027,041,056,061,068		

PROGRAM GUIDES

WHAT IS A PROGRAM GUIDE?

A program guide is an on-screen programming schedule. There are several types of guides, each presenting the schedule in a different format.

Using the program guide is easy as long as you remember the Point and Select rule. Point to items on the screen by pressing the arrow keys on the remote or front panel. Then, press OK to tune to that program.

1 SETUP AND CONNECTIONS



2 USING THE REMOTE



3 PROGRAM GUIDES



4 THE MENU SYSTEM




5 TIPS & TROUBLESHOOTING

PROGRAM GUIDES

ANATOMY OF A PROGRAM GUIDE

The following diagram shows you the kind of information you will see in the program guides.



BRINGING UP THE PROGRAM GUIDES

You can access the program guides by pressing MENU on the remote and selecting *Program Guide*, or by using the GUIDE button on the remote.




PROGRAM GUIDES

THE CHANNEL BANNER

The channel banner appears whenever you tune to a channel, exit a guide, or press INFO on the remote. Use the arrow buttons and OK to choose an item.

On-screen icons represent frequently-used menu items. Some icons also change appearance to show the item's status. Some of the items you select in the guides can also be selected in the channel banner.



Main menu icon When selected, will take you to the Main menu.

Green Unlock icon The system is unlocked. Spending, viewing and other limits can be accessed and changed.

Yellow Unlock icon A password has been entered to override family or profile limits. No limits can be accessed or changed.

Yellow Unlock icon with a "P" A password has been entered to override limits for the current program. After the program ends, limits are restored.

Red Lock icon No limits can be accessed or changed. A password is required to override limits or access the system.

AlphaSort icon When selected, allows you to sort program titles alphabetically.

Highlighted Scout (binoculars) icon A Scout has found program information.

Highlighted Mail icon Indicates a message in your mailbox.

Home Control or Data Port icons The icon changes appearance depending on how the Home Control jack on the back panel is used.

Alternate Audio icon When selected, cycles through the alternate audio choices.

PROGRAM GUIDES

USING THE GUIDE BUTTON

Each press of the GUIDE button takes you to an alternate type of program guide.

The Grid Guide

The Grid Guide shows seven channels in a time-and-channel format, with the full title of the highlighted program at the top of the guide.

The Detail Guide

The Detail Guide shows five channels in a time-and-channel format, with program information for the highlighted program at the top of the guide.

The SurfGuide

The SurfGuide displays seven channels in a half-hour time-and-channel format. Press the right arrow button to extend the SurfGuide to show the next two hours.

GETTING AROUND IN THE GUIDES

This section describes how to change channels and move around the program guide.

Point to Channels with the number keys (0-9)

You can point quickly to any channel in the program guide by entering the channel number with the number keys (0-9). For example, to point to channel 228, press the numbers 2-2-8 on the remote. To point to channel 530, press 5-3-0.

Scrolling Channel By Channel


The programs that you see on the TV screen make up one section—or page—of the total program guide. You can scroll to other sections using the arrows: point to other times with the left and right arrows; point to other channels with the up and down arrows.

Scrolling Page By Page

If you want to scroll up or down through the program guide faster, press the CHAN UP/DOWN buttons on the remote control. The highlight scrolls a page at a time.



Grid Guide



Detail Guide



SurfGuide

By default, the Detail Guide appears when you press GUIDE on the remote. You can change the default guide from the Detail Guide to the Grid Guide or SurfGuide.

Select *Options* from the Main menu. Select *Look and Feel*, then set the *Default Guide*.

PROGRAM GUIDES

TUNING TO A PROGRAM

To tune directly to a current program listed in the guide, point to the program and press OK.

To see information about a program in the guide, press INFO.



The Program Details screen appears and gives you several options.

Then, you can select:

- *View Channel* to tune to that channel
- *Buy Program* to purchase the program
- *Other Times* to see what other times the program is available. The program title is automatically entered and sorted in the AlphaSort control panel.

The options available to you may vary according to the type of program you select.

PROGRAM GUIDES

ADDITIONAL PROGRAM GUIDES

Besides the Detail Guide, Grid Guide, and SurfGuide, there are a few more guides: the Channel Guide, the Logo Guide and the Attractions Guide.


You can access these guides by selecting the *Other Guides* button at the bottom of the Detail Guide and Grid Guide.



Other Guides button

The Channel Guide

Displays a channel's programming schedule in a channel-by-channel format.



The Logo Guide

Displays channel logos for the current user's profile.



You can point to any program then tune to that channel or get more information by pressing the OK or INFO buttons.

Exiting A Program Guide

There are three ways to exit a guide:

- Point to a channel and press OK.
- Point to *Back* and press OK.
- Press CLEAR or GO BACK on the remote.

PROGRAM GUIDES

The Attractions Guide

Displays a list of channels that show coming attractions and special events information.




The *Other Guides* button also lets you sort the guide by different variables, such as future times, user profile channel lists, and channel groups. You can then choose a guide format to view the program information.

Select the *Other Guides* button. You can select multiple sort parameters. For example, you could sort the guide by pay-per-view movies that are available at a future time.

Select *Guide Data* and use the arrow and OK buttons to choose the *Guide Data* group.



Other Guides button



Guide Data lets you see what's on in the future.

PROGRAM GUIDES

Then, select *PPV* in the *Channel Groups* category.




Channel Groups is another way to sort types of programming.

Select *Back*, or press the GO BACK button on the remote to return to the previous guide. You can also choose another guide format from the category list.

SORTING THE GUIDES

Sorting the guide is a way of organizing the guide to show only the types of programs that interest you. There are several on-screen buttons that sort the guide in different ways.



The Sorting buttons appear at the bottom of the Grid Guide and Detail Guide.

PROGRAM GUIDES

Topics

The *Topics* button sorts the guide according to the current user's preferences. Select the *Topics* button to sort the guide.

The *Topics* button changes to the *Topics Themes* button. Press the *Topics Themes* button to edit the current user's themes preferences. These preferences are saved in each user's profile.



Checkmark the themes that interest you.

Select the categories, and checkmark the themes you would like to appear when you select the *Topics* button in the guides. Programming that fits the description of checkmarked themes will appear in the guide when you sort by the *Topics* button.

Movies

Select the *Movies* button to list movies only. After selecting *Movies*, the *Movies* button changes to a *Movies Themes* button.

Select the *Movies Themes* button to sort the guide to list specific types of movies, such as comedies or musicals.



Select a Movies Themes that interests you.



Topics button



Topics Themes button



Movies button



Movies Themes button

PROGRAM GUIDES

Sports

Select the *Sports* button to list sporting events only. After selecting *Sports*, the *Sports* button changes to a *Sports Themes* button.

Select the *Sports Themes* button to sort the guide to list specific types of sports, such as basketball or soccer.



Select a *Sports Theme* that interests you.



Sports button



Sports Themes button

All

The *All* button resets the guide to show all available topics, channels and listings for the current Profile.



All button


AlphaSort

AlphaSort lists in alphabetical order all the program titles in the current guide. Select the *AlphaSort* button to search for specific program titles that are in the current program guide. Use the arrow button to highlight a character, then press OK.

For example, to search for the program, *Auto Racing*, the first letter you should point to and select is "A". (Words like "The", "A" and "An" appear at the end of a title.) All titles that begin with "A" appear in the *AlphaSort* list. Next, enter the letter "U". All titles beginning with "AU" appear in the list.



AlphaSort button



AlphaSort searches for specific titles in the guide.

PROGRAM GUIDES

Continue entering the specific title's letters until it appears in the *AlphaSort* list. If you enter the wrong letter, select either *Backspace* or *Clear All*.

Use the arrow buttons to highlight the title you are looking for. Press the OK button to select it, or the INFO button to see more information. Only titles that are in the current program guide can be found by AlphaSort.

Scout


The *Scout* button lets you assign "Scouts" to search the guide for very specific program information, such as actors' names or program descriptions. Select the Scout button from the Program Guide to view the available scouts.

Point to an available Scout, and select it. Select the *Enter Text* button to set up the information the *Scout* will look for in the program guide. Use the on-screen keyboard to enter the desired search parameters.

For example, if you are interested in National Basketball Association events, enter a common term you might see in program information, like "NBA."




Scout button




Select *Enter Text* to set up a Scout.

If "NBA" appears within a program title or program description, the program will be included in the Scout Results program list.

The Scout will search for information when the receiver is off. (This may take up to 30 minutes for a full guide search.) You can check a Scout's results by selecting a Scout button.



Scouts look for specific program information.



A checkmark next to the Scout means it is in use.
A highlighted binocular icon means the Scout has found something.

PROGRAM GUIDES

The Other Buttons

Back

Exits the guide and returns you to normal viewing on the current channel. Press OK to continue.

Help

Brings up additional information about the guide. Press OK to continue.

Down Arrow

The arrow button allows you to scroll down through other channels in the guide. Point to the down arrow, and then press OK to scroll down through the program guide.

The Main menu

Brings up the system Main menu. Press OK to continue.



Back button



Help button



Arrow button



Main menu button

THE MENU SYSTEM

WHAT'S A MENU?

The on-screen menu is a list of choices, just like a menu in a restaurant. And, just as a restaurant menu is divided into sections such as appetizers, entrees, and desserts, the on-screen menus are also separated into sections to help you find the information you need.

DON'T FORGET POINT AND SELECT

As with all of the on-screen displays, you use Point and Select to navigate.

1 SETUP AND CONNECTIONS



2 USING THE REMOTE



3 PROGRAM GUIDES



4 THE MENU SYSTEM



5 TIPS & TROUBLESHOOTING

THE MENU SYSTEM

USING THE MENU SYSTEM

To bring up the Main menu, press MENU on the remote.



Use point and select to choose an item from the Main menu.

To use the menu system, you need to know the Point and Select rule. Use the arrows on the remote to point to an item on the screen, and then press OK to select it.

BACK AND HELP

There are *Back* and *Help* buttons at the top of most screens. Point to *Back* and press OK to leave that screen. Point to *Help* to see more information about that screen.

Exiting a Screen

There are three ways to exit a menu:

- Point to *Back* and press OK.
- Press the CLEAR button on the remote control. The on-screen displays clear from the screen and you return to TV viewing.
- Press the GO BACK button on the remote. You return to the previous on-screen display or normal programming.

Using Help

All menus have a *Help* button. For example, selecting the *Help* button from the Main menu shows you information about using the Main menu screen.

The rest of the *Help* buttons in the menu system bring up helpful information explaining one aspect of that menu.

Use the MENU button to bring up the Main menu, and then use Point and Select to choose a menu option.

If the Main menu doesn't appear when you press MENU, the remote might not be in satellite mode. Try pressing the DIRECTV button on the remote, and then OK.

Context-Sensitive Help

Most of the screens contain information to help you decide what to do next. If you get stuck, look for the help text.

THE MENU SYSTEM

MENU DESCRIPTIONS

This section briefly describes each of the available Main menu options. More information about each menu and its features is included later in this chapter.

Program Guide

Shows the on-screen programming schedules.

Mailbox

Use to read mail messages from your program providers.

Purchases

Use to review or cancel upcoming purchases, and to review past purchases.

Timers

Allows you to schedule the satellite system to tune to a specific channel at a specific time.

Profiles

Allows you to set ratings limits, spending limits, and viewing hours, as well as create favorite channel lists.

Options

Allows you to find out more about the receiver and remote, change how your system looks, run the system test, and install a new access card.

Dish Pointing

Use to find your dish pointing coordinates, and to access the on-screen signal strength meter.

Home Control

With the proper equipment, this feature lets you control certain devices and appliances in your house.

DON'T BE AFRAID TO EXPLORE

Once you've learned the basics, feel free to poke around the menu system—exploring is the best way to learn. The context-sensitive help at the bottom of the screen provides instructions for getting through any particular menu or control panel. Remember, press CLEAR at any time to leave the menu system and return to regular system viewing.

Back Help

- 1 Program Guide...
- 2 Mailbox...
- 3 Purchases...
- 4 Timers...
- 5 Profiles...
- 6 Options...
- 7 Dish Pointing...
- 8 Home Control...

Don't Forget About the CLEAR Button

Press the CLEAR button on the remote to remove the on-screen menus and return to normal viewing.

THE MENU SYSTEM


THE PROGRAM GUIDE

1 Program Guide...

Selecting *Program Guide* brings up your default program guide: the Detail Guide, the Grid Guide or SurfGuide.

ANATOMY OF A PROGRAM GUIDE

The following diagram shows you the kind of information you will see in the Detail Guide and Grid Guide.



BRINGING UP THE PROGRAM GUIDES

Besides selecting *Program Guide* in the Main menu, you can press the GUIDE button on the remote.

Want More Information?

Read the section in this book called Program Guides for all the details.

THE MENU SYSTEM

THE MAILBOX

The mailbox shows you messages that are sent—or “mailed”—from your program providers. For example, you may receive a message calling your attention to a new service.

2 Mailbox...

HOW TO TELL WHEN YOU HAVE MAIL


There are two ways to tell if you have mail, depending on whether the satellite receiver is turned on or off.

- If the receiver is turned on, the mail icon in the channel banner is highlighted.
- If the receiver is turned off, the power light on the front panel of the receiver flashes.

CHECKING YOUR MAIL

Select *Mailbox* on the Main menu or channel banner to view your mail.

1. Point to a message and press OK. The message is opened for you to read.



Mail provides the latest information from program providers.

2. Press OK again to close the letter.

After you read a message and want to erase it, point to *Erase Message* and press OK. When you exit the display screen, messages not erased are saved in memory.

THE MENU SYSTEM

PAY-PER-VIEW PROGRAMS

Pay-per-view programs (PPV) are programs that you purchase—like a movie ticket—on an event-by-event basis. For instance, a channel with pay-per-view programs may run nothing but previews for movies. After previewing the movie, you can purchase it or find out more details about it. PPV programs are labeled “PPV” in the Program Guide.


PURCHASING AND PREVIEWING

There are several ways to purchase and preview PPV movies and events:

- Tune to a PPV program’s channel. Program providers may offer on-screen purchase instructions, usually as the PPV program begins.
- Choose a PPV program from the program guide.
- Preview a coming attraction by selecting a channel from the Attractions Guide.

TUNING TO A PPV PROGRAM

When you use the channel buttons or digits on the remote to tune to a Pay-Per-View channel, you need to press the INFO button to bring up the *Program Details* screen in order to purchase a program.



Use the program guide to get to the *Program Details* screen.

Follow the on-screen instructions to purchase the selected program.


3 Purchases...

You may need to enter your four-digit password to order a PPV program if it costs more than the spending limit you set up in the Profiles menu.

THE MENU SYSTEM

USING THE PROGRAM GUIDE FOR PPV PROGRAMS

Another way to get to the Program Details screen is by using the program guide. Highlight the program name in the guide and press INFO.



The Program Details screen gives you several options.

You can select:

- *View Channel* to tune to that channel
- *Buy Program* to purchase the program
- *Other Times* to see what other times the program is available. The program title is automatically entered and sorted in the AlphaSort control panel. If no other times are available, this option will not be available.

The options available to you may vary according to the type of program you select.

USING THE ATTRACTIONS GUIDE

Your program providers may offer future programming events not currently listed in your Program guide. These events are called “coming attractions,” and can be previewed in the Attractions Guide.

1. Press the GUIDE button on the remote until the Detail Guide or Grid Guide appears on-screen.
2. Use the down arrow button to move the highlight to the bottom of the screen.
3. Point to and select the *Other Guides* button.
4. Point to and select the *Attractions Guide*.

3 Purchases...

You need to connect your phone line to your satellite receiver to be able to order PPV programs using the on-screen menus.

THE MENU SYSTEM



The Other Guides menu provides several guide formats.

5. Point to a channel and select it.




The Attractions Guide is accessed through the Other Guides menu.

3 Purchases...

USING THE PURCHASES MENU

The Purchases menu allows you to review upcoming and past purchases.



The Purchases menu shows you upcoming or past purchases, and spending limits.


The list of purchases may be longer than one screen; use the down arrow keys to see more items. The display also shows the title, channel, date, time, and cost of each program.

- Note that the Past Purchases list might be modified after each billing cycle and show purchases for which you have already paid.

THE MENU SYSTEM

REVIEWING AND CANCELING AN UPCOMING PURCHASE

Use Point and Select to choose an upcoming purchase from the *Future Purchases* screen. You can review the program description, as well as cancel an upcoming purchase.



The Purchase Edit screen lets you cancel an upcoming purchase.

SPENDING LIMITS

Use the *Spending Limit* option to indicate a per-event spending limit for pay-per-view programs.

1. Point to *Spending Limit*, and press OK.



You can set a per-event spending limit for each Profile.

2. Use the digits on the remote or use the arrow keys to enter a single-program spending limit.

After a spending limit is set *and* the system is locked, you must enter a password to purchase a pay-per-view program that costs more than your spending limit allows.

3 Purchases...

Important!

Spending limits are in effect only when the system is locked. See the section "Locking the System" for details.

THE MENU SYSTEM

TIMERS FEATURE

The Timers feature allows you to preset your system to automatically tune to a particular channel at a predetermined time.

To use the Timers feature, select *Timers* from the Main menu to bring up the Timers screen. Select a Timer (1-8) and then use the arrow keys to complete the on-screen sentence. When the sentence is complete, select *Run Timer*.



Complete the on-screen sentence to set up a timer.

PROFILES

When you select *Profiles* from the Main menu, the first screen you see is the *Master Edit* control panel. In addition to the Family profile, you can create as many as four different profiles that can be easily accessed by using the WHO button on the remote control.

You can personalize the profile by entering a name.






You can personalize each profile.

You can also edit the user profiles. Select a profile from the *Edit Users* control panel. By moving down the options you can create or edit the user's channel list, set a ratings limit, viewing hours, per-event spending limits and assign a profile password.

Timers...

On-screen icons are an easy way to understand the timers:

-  Indicates the timer is set.
-  Indicates the timer is set for a PPV.
-  Indicates a timer conflict.

Editing or Canceling a Timer

From the Timers screen, select the Timer you want to edit or cancel, and then do the following:

- Use the arrows keys to edit the Timer, then select *Run Timer*.
- Select *Clear Timer* to cancel the timer.
- To watch the program daily or weekly, edit that program's timer.

THE MENU SYSTEM

CREATING A PROFILE CHANNEL LIST

5 Profiles...

1. Point to and select a user.
2. Point to *Edit Channels* and press OK.



To start, you can add or delete all channels.

3. Use the arrow keys to point to a channel, and press OK to remove (or replace) the check mark. Checkmarked items appear in the channel list.

Add or Delete All Channels

You might be able to save time when creating a channel list by using the *Add All Chans* option or the *Delete All Chans* option to either add all channels or delete all channels before removing or adding individual channels.

Also, program providers may make additional channels available. To prevent new channels from appearing in a profile channel list, choose *Delete All Chans* and checkmark only the channels you want to appear in the list.

SETTING THE RATINGS LIMIT

The Ratings Limit menu enables you to set a maximum viewing limit for rated movies (based on the MPAA ratings system), as long as the program provider has transmitted the proper code.

- Note that the ratings limit cannot be enforced if a program has not been rated, if rating information for that program is not transmitted by the program provider, or if the system has not been locked.

THE MENU SYSTEM

1. Point to *Set Rating Limit* and press OK.



Use the arrow keys to move the selector up and down.

2. Use the up and down arrows to move the rating selector to the highest rating you want to be able to view. In the preceding illustration, movies that are rated up to and including a “PG-13” rating can be viewed.

After the *Rating Limit* is set *and* the system is locked, you must enter the system password to watch programs with a rating higher than your limit.

VIEWING HOURS

Use the *Viewing Hours* option to limit the total amount of time, as well as the viewing hours that a user can watch programming.

1. Point to *Viewing Hours*, and press OK.



You can limit viewing seven days a week.

2. Use the digits on the remote or point to the + or – and press OK to complete the on-screen sentence. Choose the days to view, how many hours can be viewed each day (0-24 hours) and when programming can be viewed. Be sure to lock the system for these limits to take effect.

5 Profiles...

Important!

You need to lock the system in order for rating limits, channel limits, viewing hours, and spending limits to go into effect.

After you lock the system, you need to enter the system password to edit the limits. See “Locking the System” for details.

THE MENU SYSTEM

SETTING UP SPENDING LIMITS

Select the *Spending Limit* option to indicate a per-event spending limit for pay-per-view programs.

1. Point to *Spending Limit*, and press OK.



You can set a per-event spending limit for each profile.

2. Use the digits on the remote or use the arrow keys to enter a single-program spending limit.

After a *Spending Limit* is set and the system is locked, you must enter the system password to purchase a pay-per-view program that costs more than your *Spending Limit* allows.

LOCKING A USER'S PROFILE

Each user can be assigned a personal password to lock his or her profile. When a password is assigned, the user must enter the password before he or she can view programs using that profile. Profile passwords do not allow access to, or editing of the profile limits. You must enter the system password to edit profile limits.

1. Point to *Lock User* and press OK.



Each user can have a password.

2. Use the arrow or digit keys to select each number of the password.

5 Profiles...

After the system has been locked, you must enter the correct password in order to access the *Edit Users* control panel.

Don't Forget Your Password

If you forget a **USER** password, you need to unlock the system and then assign a new user password.

If you forget the **SYSTEM** password, contact your program provider's authorization center.

THE MENU SYSTEM

LOCKING THE SYSTEM

You can lock the system activate the ratings, spending, viewing, and channel limits you have set up. When you lock the system, no one can modify any of these settings without first entering the four-digit system password.

1. Point to *Lock System* and press OK.



Locking the system protects the limits you set up.

2. Use the arrows or the digits to enter a four-digit system password.
3. Enter the password a second time to confirm it.

For the changes to take effect, you must exit out of the menu system.

Unlocking the System

When the system is unlocked, the channel, spending, viewing, and ratings limits that you set are no longer in effect. To unlock:

1. Point to *Unlock System* in the *Profiles* menu and press OK.
2. Point to *Yes* and press OK to confirm that you want to unlock the system.

When you attempt to access a channel that is blocked by one or more limits and the system is locked, you will be asked to unlock the system by entering the four-digit system password.

If you enter the password to override a limit, all limits are unlocked until you turn off the receiver. When you turn on the receiver again, the system will be locked, and the Family profile channel list will be selected. If you want to re-lock the system without turning off the receiver, you can select the lock icon in the channel banner.

Program Unlock

If the system is locked and you want to access a blocked program without unlocking all settings, press INFO and highlight the Lock icon in the channel banner. Make sure to check the box beside "Unlock this program only," and enter the system password. This program is no longer blocked, but all other settings remain in effect.

5 Profiles...



The Lock/Unlock icons in the channel banner provide an easy way to lock or unlock the system. Just press INFO and select the icon to change the lock status.

Green Unlock icon The system is unlocked. Spending, viewing and other limits can be accessed and changed.

Yellow Unlock icon A password has been entered to override family or profile limits. No limits can be accessed or changed.

Yellow Unlock icon with a "P" A password has been entered to override limits for the current program. After the program ends, limits are restored.

Red Lock icon No limits can be accessed or changed. A password is required to override limits or access the system.

THE MENU SYSTEM

CHOOSING YOUR PROFILE

5 Profiles...

Each time you turn on the receiver, the Family profile is selected by default. To select a different Profile:

1. Press the WHO•INPUT button to scroll through the profiles.



The WHO•INPUT button toggles through the profiles.

2. When your profile appears, enter your four-digit personal password to activate your profile.
 - If the profile is not password protected, you can just press OK to activate it.

The channel, spending, ratings and viewing limits associated with the chosen profile will be active only when the system is locked.

OPTIONS

The Options menu lets you set up preferences for the look and feel of the system as well as how some of the features work.



The Options menu lets you change how the system works.

The following sections explain your options when changing your personal preferences. Follow the on-screen instructions to make changes to the system.

THE MENU SYSTEM

INTERACTIVE SETUP

If you self-installed your satellite dish antenna, you may have already used the interactive setup to find the dish pointing coordinates, acquire and fine-tune the signal, and run a system test. If you just want to check your dish pointing coordinates, or run the signal strength meter, select *Dish Pointing* from the Main menu.

A grey arrow-shaped button pointing to the right. On the left side of the arrow is a small circular icon containing a satellite dish symbol. To the right of the icon, the text "Options..." is written in a light grey font.

SYSTEM INFO

Select *System Info* from the *Options* menu to choose from a list of on-line Help topics. Point and select to find out about the specific parts of the satellite system.

Program Guide shows a screen-by-screen overview of the Program Guide features.

Menu System shows a screen-by-screen overview of the satellite system menus.

Remote Control shows a descriptive list of the remote control buttons.

Front Panel shows a list of the receiver's front panel features. Point to an item to see a brief description.

Back Panel shows a list of the receiver's back panel features. Point to an item to see a brief description.

Glossary shows a list of common satellite system and TV terms. Point to a glossary item to see a brief description.

LOOK AND FEEL

Default Guide lets you choose which guide appears first when you press the GUIDE button on the remote. The choices are Grid Guide, Detail Guide and SurfGuide.

Color Scheme lets you pick which color appears in the guides and menu system.

Translucency lets you choose the translucency of the menu displays. Slide the indicator bar to make the screens more opaque or less opaque.

Animation lets you select which graphics are displayed and also lets you select the animation time-out.

Edit Fetch lets you combine your favorite menu items onto one menu, or assign one function to the Fetch button on the remote.

THE MENU SYSTEM

SYSTEM OPTIONS

A grey arrow-shaped button pointing to the right. On the left side of the button is a small circular icon containing a gear symbol. To the right of the icon, the text "Options..." is written in a light grey font.

System Test The System Test display screen is accessed through the *Options* menu, and allows you to initiate diagnostic procedures on the satellite system. You should use this feature to get your Access Card number, or when your receiver doesn't seem to be working correctly.

A message screen appears, telling you whether the system passed each test. If your system fails a test, run the system test several times before concluding that there is a problem. Occasional fluctuations in the phone line or satellite signal can give temporary false readings.

New Access Card Periodically, your program provider may issue you a replacement Access Card. The New Access Card Setup display screen allows you to transfer the information from the old card onto the new one. The Access Card fits into the receiver through the front panel.

Follow the display screen prompts to initialize your new card. Once you have transferred the information to the new card, your old card becomes invalid.

Because your specific account information is stored in the access card, power failures should have no effect on your satellite system.

Remote Setup Lets you choose which remote button will control the satellite system if you are using a universal remote that did not come with the system.

Output Channel Lets you choose on which channel to view satellite programming, either channel 3 or channel 4.

Picture Size The Picture size display screen allows you to choose between a standard TV screen and a Cinema option. A standard TV screen has an aspect ratio of 4:3; the Cinema option has an aspect ratio of 16:9.

Data Port Lets you choose whether the low speed data port is used for low speed data or communicating with the Home Control Base accessory. See the Home Control section in this book for more information.

AUDIO LANGUAGE

When you select *Audio Language* from the *Options* menu, the Audio Language display screen comes up.

Point to the audio language or audio type you want and press OK. The satellite system audio will then automatically be set to the selected language (when the language is available).

ALTERNATE DATA

Selects from among the available data on the current channel.

THE MENU SYSTEM

THE DISH POINTING MENU SCREEN

7 Dish Pointing...

Follow these steps to obtain your dish pointing coordinates:


1. Turn on your television and satellite receiver.
2. Tune your television to the satellite receiver's output channel.
3. Press MENU on the remote to bring up the Main menu.
4. Use the arrows to highlight *Dish Pointing*, and then press OK to access the dish pointing screen.

NOTE: The menu screen that you see may be slightly different from the one pictured here.




5. Use the arrows on the remote or the front panel to highlight *Zip Code*, and then press OK.
6. Enter the zip code for the dish installation location.
7. Record the elevation and azimuth numbers below.

Elevation _____ Azimuth _____



Elevation is the up/down angle that the dish is pointed.



Azimuth is the side-to-side direction that the dish is pointed.

You only need to use one of the available methods to find your dish pointing coordinates. If you know the zip code for the dish location, use that.


THE MENU SYSTEM

USING THE ON-SCREEN SIGNAL METER

The signal strength meter is used to determine whether or not you are receiving the satellite signal; it also indicates the strength of the satellite signal.

Follow these steps to bring up the on-screen signal meter:

1. Turn on your television and satellite receiver.
2. Tune your television to the satellite receiver's output channel.
3. Press MENU on the remote to bring up the Main menu.
4. Use the arrows to highlight *Dish Pointing*, and then press OK to access the dish pointing screen.
5. Use the arrows on the remote to highlight *Signal Meter* and then press OK.



If the dish is pointed to the correct azimuth and elevation, the signal meter will show you the current signal strength (and you should hear a continuous tone).

If you are not receiving a signal, you need to incrementally adjust the azimuth setting on the dish. After you receive a signal, you will want to continue to adjust the azimuth to try to get the best possible signal.

Important

Changing transponders is not the same as fine-tuning the dish. Although the signal strength may appear to change, this may be due to different types of interference. To fine-tune the dish, consult the Installation Guide and follow the instructions on adjusting the dish elevation and azimuth.

7 Dish Pointing...

Peak Signal

The "Peak Signal" indicates the highest signal strength you have obtained, which is not necessarily the highest possible signal.

While the maximum signal strength is 100, the signal strength you achieve will probably be less. Although there is no difference in picture quality between signal strengths of 60 and 85, the higher the signal, the less likely you are to experience negative effects in degraded conditions such as rain or snow (called "rain fade").

THE MENU SYSTEM

HOME CONTROL

Home Control lets you remotely control several lamps and devices through your receiver.

Home Control Setup

The Home Control Data Interface connects to the HOME CONTROL jack on the back of the receiver. Once connected, you must tell the receiver to use this port for Home Control.

1. Press OK to bring up the Main menu.
2. Point to and select *Options*.
3. Point to and select *System Options*.
4. Point to and select *Data Port* and choose *Home Control* as the default setting.

Device Setup

1. From the Main menu select *Home Control*.




Home Control can control several devices.

2. Select a device you would like to control.
3. Complete the on-screen sentence using the arrow buttons and OK. Press OK to scroll through the lists of devices and locations.

 Home Control...


To use the home control feature, you must connect one end of the Home Control Data Interface to a remote module attached to the appliance you want to control. The other end should connect to the HOME CONTROL jack on the back of the receiver via a coiled telephone handset cord (available from most retailers).



Home Control Jack on the Back Panel

Home control modules are available as accessories sold through your satellite dealer or the accessories order form at the back of this book.

THE MENU SYSTEM



Keep track of devices by assigning a label.

4. Use the arrow buttons and OK to select the house and module codes that match the device's remote module and label the module. Select *Save Setup* to complete the setup.

Device Control

Once the device is set up, there are two ways to control it: with the menu system or with a timer. Select a device from the Home Control menu screen. You can then turn it on, turn it off, or adjust the brightness for lamp modules.

Select *Edit Setup* to change a device.



Control the device from the menu.

To schedule a timer:

1. Select *Set Timer*.
2. Schedule a timer by completing the on-screen sentence.

Home Control...

On-screen icons are an easy way to understand the timers:



Indicates the timer is set.



Indicates the timer is suspended.

You can schedule several timers to control the same device at different times.

THE MENU SYSTEM



Complete the on-screen sentence to schedule a timer.

3. Use the arrows and OK to enter an *on* and *off* time.
4. Point to and select *Run Timer*.

Clear Timer removes all the timer information.

Suspend turns off the timer, but saves the timer information.

EDIT FETCH MENU

The Edit Fetch menu gives you the option of using Fetch in two ways:

- You can customize eight functions on the Fetch menu, or
- You can customize the Fetch button on the remote to take a certain action each time it is pressed.

To view the Edit Fetch Menu, press MENU to bring up the Main menu, select *Options*, select *Look and Feel*, and then select *Edit Fetch*.



The Edit Fetch menu is a convenient way to call up frequently used menu items.

THE MENU SYSTEM

CUSTOMIZING THE FETCH MENU

To customize your Fetch menu:

1. Press MENU to bring up the Main menu.
2. Point to and select *Options, Look and Feel*, and then *Edit Fetch*.
3. Select *Fetch Control*.
4. Press OK to choose *Show Fetch Menu*.
5. Select *Fetch List* from the Edit Fetch menu.
6. Choose which eight menu items you would like to include in your customized menu by checkmarking them with the OK key.



Choose which menu items to include in your customized Fetch menu.

7. Press the left arrow key to confirm your selections and return to the menu.

When you would like to access your customized menu, press the FETCH button on the remote control.

THE MENU SYSTEM

CUSTOMIZING THE FETCH BUTTON

To customize the FETCH button on the remote so it performs one function when pressed:

1. Press MENU to bring up the Main menu.
2. Point to and select *Options, Look and Feel*, and then *Edit Fetch*.
3. Select *Fetch Control*.
4. Choose *Assign One Function*.
5. Select *Fetch List* from the Edit Fetch menu.
6. Choose which menu item you would like to assign to the FETCH button by pointing and selecting.



Choose which menu item to assign to the FETCH button.

7. Press the left arrow key to confirm your selection and return to the menu.

You may press the FETCH button on the remote and execute the assigned function at any time while viewing satellite programming.

TIPS & TROUBLESHOOTING

TIPS FOR SOLVING PROBLEMS

You may have some questions about using your satellite system that you are unsure how to answer. This section provides the answers to such questions. You will find how to run a system test, and how to diagnose and correct problems.

1 SETUP AND CONNECTIONS



2 USING THE REMOTE



3 PROGRAM GUIDES



4 THE MENU SYSTEM



5 TIPS & TROUBLESHOOTING

TIPS & TROUBLESHOOTING

RUNNING THE SYSTEM TEST

The System Test allows you to run a basic diagnostics check on your satellite system. If you are experiencing any trouble with your system, run the system test. It will allow you to get your Access Card number, or to initiate diagnostic procedures on the satellite system.

First make sure that:

- All connections—jacks, cables, etc.—are correctly in place. See the section “Setup and Connections” for more information.
- There are batteries in the remote, and they are working correctly.
- The Access Card is installed in the receiver.

Follow these steps to run the system test:

1. Turn on your TV and the receiver.
2. Press the DIRECTV button on the remote to put the remote in satellite system mode, then press MENU to bring up the Main menu.
3. Point to and select *Options*.
4. Point to and select *System Options*.
5. Point to and select *System Test*.
6. If your system does not pass the system test, check these potential trouble areas: cabling, pointing the satellite dish, phone connection, and access card.
7. If you continue to have problems, call 1-800-679-4776.

You should run a system test several times before concluding that there is a problem. Occasional fluctuations in the phone line or satellite signal can give temporary false readings.

FINE-TUNING THE SIGNAL


If you self-installed your satellite dish antenna, you may have already used the interactive setup to find the dish pointing coordinates, acquire and fine-tune the signal, and run a system test.

If you need to run the interactive setup again, select *Options* from the Main menu, then select *Interactive Setup*.

If you just want to check your dish pointing coordinates, or run the signal strength meter, select *Dish Pointing* from the Main menu.

TIPS & TROUBLESHOOTING

HOW SIGNAL FLOW WORKS



How the Satellite Signals get to Your TV

In the example above:

1. Program providers send signals to your antenna dish.
2. The antenna dish sends the signal to the receiver's SATELLITE IN jack.
3. The signal continues through the coaxial cable to the VCR and then to the TV. (The VCR may seem like an unnecessary link in the chain, but this setup lets you record programming and off-air antenna/cable programming.)

If you use audio/video cables, the satellite signal also flows through the audio/video cables to the TV's line inputs (left, right, and video or S-video).

How Off-Air Antenna/Cable Signals get to Your TV

In the example above:

1. Off-air/cable broadcasters send signals to your off-air antenna or through cable to your home.
2. The signal continues through the coaxial cable to the receiver and then to the VCR. The signal can also pass through the VCR to the TV. (The VCR may seem like an unnecessary link in the chain, but this setup lets you record programming and off-air antenna/cable programming.)

TIPS & TROUBLESHOOTING

Wrong picture

The receiver and most VCRs let you toggle between pictures: one is the picture from the receiver and one is from the VCR. If you don't see the picture you think you should be seeing, try using these buttons to toggle between the pictures:

- Press the TV/VCR button on the VCR remote or on the VCR's front panel.
- Press the ANTENNA button on the remote control.

Taking either of these actions lets you switch the source of the video signal from satellite to the off-air antenna or cable, and vice versa.

Problems with the remote

- Maybe something is between the remote and the remote sensor.
- Maybe the remote is not in satellite mode. Press the DIRECTV button so the remote will control the satellite receiver.
- Maybe the batteries in the remote are weak, dead or installed incorrectly. Try replacing batteries. (Note, if you remove the batteries, you may have reprogram the remote to control other components.)
- Remove the batteries and hold the number 1 button for at least 60 seconds to drain the microprocessor inside the remote. Release the button, replace the batteries, and (if necessary) reprogram the remote.
- Remove all batteries for approximately 12 hours. Then replace batteries and (if necessary) reprogram the remote.

Blank screen

- Maybe the device (VCR, receiver, DVD, etc.) connected to the input jacks is not on.
- Try another channel, because there may just not be any programming on at that time.

Receiver will not turn on

- Check to make sure it is plugged in.
- Check the wall receptacle (and extension cord, if applicable) to make sure it is "live" by plugging in something else.
- Maybe batteries in remote control are "dead."
- Maybe remote control is not aimed at remote sensor.
- The front panel controls may be locked (disabled). Use the remote control to unlock the front panel controls by selecting the *Front Panel Lockout* in the Parental Controls menu and choosing *Unlock*.

LED Light Flashes on front panel

- You have mail. Read the message by selecting *Mailbox* from the Main Menu and selecting the message. Flashing will stop.

Turns off while playing

- Schedule off function may have been activated.
- Electronic protection circuit may have been activated because of a power surge. Wait 30 seconds and then turn on again. If this happens frequently, the voltage in your house may be abnormally high or low.

TV Turns on or changes channels unexpectedly

- Scheduled Watch from the Timers menu may have been activated.

APPENDIX A: WARRANTY INFORMATION

Repair Help

Thomson Consumer Electronics offers hardware repair service should you encounter any problems with your satellite system. Many problems can be diagnosed over the phone, or if necessary, a replacement unit can be shipped to you. **Please have your satellite system model, serial number and date of purchase ready when you call.** If your unit is out of warranty, we will quote the cost of an exchange unit to you. Refer to RCA Satellite System Limited Warranty for the repair service phone number.

Returning Equipment to Thomson for Repair or Exchange

If we are unable to resolve your problem over the phone we will gladly service your unit or exchange it for a new or refurbished unit. Refer to the limited warranty included in the booklet to learn about your specific rights and responsibilities. *Always consult Thomson and get a Return Authorization number before returning anything.* Obtain a Return Authorization (RA) number from the telephone representative before returning your equipment to avoid delays, accounting errors, or even loss of your unit.

Important Information to Customers Who Ship Defective Equipment to Thomson Consumer Electronics

The Thomson representative who authorizes the return of your equipment will give you an RA number over the phone. The representative will also provide you with instructions on where and how to return your unit. Write the number in large, clear characters on the outside of the box. *To avoid confusion and misunderstandings, shipments without an RA number clearly visible on the outside of the box will be returned to you at your expense.*

Include a brief note describing the problem and any conversations you have had with Thomson personnel about the problem. Include your name, address and model/serial number of your unit. These numbers are located on the back of your receiver. If your satellite system is within the warranty period, please provide a copy of the bill of sale to verify purchase date. Use the original box and packing material to protect the equipment from damage in shipment. **For your protection, insure all shipments for full replacement value and use a reliable shipper.** Thomson assumes no responsibility for warranty shipments from the customer to the factory if not shipped in the manner prescribed by Thomson.

RCA SATELLITE SYSTEM LIMITED WARRANTY

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- 90 days - Unit exchange, which includes parts and labor.
- 91 days to 1 year - Unit exchange, which includes parts only; you pay the labor.
- The warranty for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.

What we will do:

- **During the initial 90 days:**
Exchange the defective portion of your satellite receiver with a new or, at our option, refurbished unit.
- **After the 90 days and within one year:**
Exchange the defective portion of your satellite receiver with a new or, at our option, refurbished unit. We will charge you a flat exchange cost to replace a defective receiver. This charge covers the labor cost for its repair.

APPENDIX A: WARRANTY INFORMATION

How you get service:

- Call 1-800-679-4776 and have your unit's date of purchase and model/serial number ready. The model/serial number information is on the back of your receiver.
- A representative will troubleshoot your problem over the phone.
- If the representative determines that you should receive a replacement receiver you will be provided with a Return Authorization (RA) number and the location of a nearby exchange point if one exists. No returns will be accepted without the RA number.
- If the representative determines that your antenna/dish is defective he or she will arrange for its repair or replacement.

Option 1

1. Provide your Discover, Mastercard or Visa account number and expiration date to your phone representative. This is for security purposes only and your account will not be charged at this time.
2. We will send you a replacement unit.
3. If you return the unit to us within 14 days from the date you were provided a RA number, only items not covered by warranty will be charged to your account. If your unit is not received within 14 days, the suggested retail value of the receiver will be charged to your credit card. This amount will be credited, less a \$10 handling fee, if the unit is subsequently received.
4. Ship your defective unit back to us using the replacement unit's carton. Shipping instructions will be included on the carton along with your RA number which will allow you to easily ship the unit back to us. Make sure you insure your shipment in case of damage or loss. Include with the shipment:
 - Evidence of purchase date such as a bill of sale.
 - A brief note describing your receiver problem.
 - Your name, address and phone number.

Option 2

1. We will send a replacement unit to our exchange point.
2. The exchange location will notify you of its arrival.
3. Take your unit and evidence of purchase date, such as a bill of sale, to the exchange location and you will be provided the new or refurbished unit. Please retain all accessories such as the remote control hand unit.
4. If the repairs are covered by your warranty, you will not be billed.

Thomson assumes no responsibility of warranty shipments from the customer to the factory if not shipped in the manner prescribed by Thomson.

To receive a replacement receiver after we have received your unit:

- Write the RA number on the outside of the carton used to return the unit. Make sure you insure your shipment in case of damage or loss.
- Carefully pack the unit using the original box and packing material if possible. Please retain all accessories that were included with your unit such as the remote control hand unit.
- Include with the shipment:
 1. Evidence of purchase date such as a bill of sale.
 2. A brief note describing your receiver problem.
 3. Your name, address and phone number.
- The representative will advise the address to mail a cashier's check or money order for payment if there are any out of warranty labor or parts charges, and you elect not to use your credit card.
- After we receive your product, a new or refurbished unit will be shipped to you.

APPENDIX A: WARRANTY INFORMATION

What your warranty *does not* cover:

- Acts of God, such as but not limited to lightning damage.
- Adjustment of customer controls.
- Damage from misuse or neglect.
- A unit that has been modified or incorporated into other products or is used for institutional or other commercial purposes.
- Batteries.
- Units purchased, serviced or operated outside the U.S.A. and Alaska.
- For units intended for use in Alaska, this warranty does not cover installation or the dish antenna. It only covers the satellite receiver.
- Loss of programming.
- Installation.
- Shipping damage if the unit was not packed and shipped in the manner prescribed by Thomson.
- Storage fees may be charged by the exchange point if you fail to pickup the replacement unit in a timely manner.

Product Registration:

- Please complete and mail the Product Registration Card packed with your product. It will make it easier to contact you should it ever be necessary. The return of the card is not required for a warranty coverage.

How state law relates to warranty:

- This warranty gives you specific legal rights and you may have other rights that vary from state to state.

If you purchased your product outside the United States:

- This warranty does not apply. See your dealer for warranty information.

APPENDIX B: FCC REGULATIONS

FCC Registration Information

Your satellite system equipment is registered with the Federal Communications Commission and is in compliance with parts 15B and 68, FCC Rules and Regulations.

1. Notification to the Local Telephone Company.

On the bottom of this equipment is a label indicating among other information, the FCC Registration number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful to determine the number of devices you may connect to your telephone line and still have all these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

Note: This equipment may not be used on coin service provided by the telephone company. Party lines are subject to state tariffs, and therefore you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

Notice must be given to the telephone company upon permanent disconnection of your equipment from your line.

2. Rights of the Telephone Company.

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance (2) afford you the opportunity to correct the situation and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations of procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

Radio Interference

This equipment has been type tested and found to comply with the limits for a Class B Digital Device in accordance with the specifications in Part 15 of FCC Rules. These rules are designed to provide reasonable protection against radio and television interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television reception (which you can determine by turning the equipment off and on), try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Change the position of the satellite receiver with respect to the radio or television equipment that is receiving interference.
- Move the satellite receiver away from equipment receiving interference.
- Plug the satellite receiver into a different wall outlet so the receiver and equipment receiving interference are on different branch circuits.

If these measures do not eliminate interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.


APPENDIX C: ACCESSORIES



RG-6 Coaxial Burial Cable with weatherproof "F" connectors



Self-Installer's Kit contains cable and hardware to install the dish and connect the system.



Remote Control replaces a lost remote. Or, order a second remote for convenience.



HCDSS10 Home Control Kit contains a Data Interface that connects to the receiver and a lamp module.



HC10LM Lamp module lets you control incandescent lamps. Use to dim/brighten and turn lamps on/off.



HC20AM or HC30AM Appliance modules turn small appliances, like coffee pots, popcorn makers, or stereo, on or off. Also controls non-incandescent lamps. Choose 2 prong (HC20AM) or 3 prong (HC30AM).

Accessory Order Form for Satellite Systems

Description	Part No.	Price	Qty	
RG-6 Coaxial Cable				
12 feet	D912	\$12.95		
25 feet	D925	\$15.95		
50 feet	D950	\$21.95		
75 feet	D975	\$29.95		
100 feet	D901	\$35.95		
S-Video Cable 12 feet	D913	\$12.95		
Weatherproof "F" Connector (2)	D905	\$ 5.30		
TVRO Bullet Amplifier	D903	\$24.95		
Self-Installer's Kit	DKIT96	\$69.95		
Remote Control	240968	\$34.95		
Home Control Kit	HCDSS10	\$59.95		
Lamp Module	HC10LM	\$14.95		
2-Prong Appliance Module	HC20AM	\$16.95		
3-Prong Appliance Module	HC30AM	\$16.95		

Prices are subject to change without notice.

Total Merchandise \$ _____

Sales Tax \$ _____

We are required by law to collect the appropriate sales tax for each individual state, country, and locality to which the merchandise is being sent.

Shipping, Handling, and Insurance \$ 5.00


Total Amount Enclosed \$ _____

Use VISA, MasterCard, or Discover preferably.
 Money order or check must be in U.S. currency only.
 No COD or CASH.



Detach Here

All accessories are subject to availability.




APPENDIX C: ACCESSORIES

Charge your order on your VISA, MasterCard, or Discover Card by filling in below


USE YOUR CREDIT CARD

IMPORTANT: Copy complete account number from your VISA card




My card expires:

IMPORTANT: Copy complete account number from your MasterCard



Copy Number above your name on MasterCard My card expires:

IMPORTANT: Copy complete account number from your Discover Card



My card expires:

AUTHORIZED SIGNATURE
 (Credit card order will not be processed without signature)
 Prices are subject to change without notice.

Print or type your name and address clearly.



A complete and correct order will save you days of waiting.

Name: _____

Street: _____

_____ Apt: _____

City: _____

State: _____ Zip: _____

Please make sure that both sides of this form have been filled out completely.

- Allow 4 weeks for delivery.
- All accessories are subject to availability.
- Prices are subject to change.

United States and Canada Orders

To place your order by phone, have your Visa, MasterCard or Discover Card ready and call the toll-free number listed below between 8AM and 10PM (EST) Monday through Friday or between 9AM and 5PM (EST) Saturday.

Use this number only to place an order for accessory items listed on this order form.

1-800-338-0376

To place your order by mail, detach and mail the completed order form with credit card information, money order or check in US currency (made payable to Thomson Consumer Electronics, Inc.) to the following address:

Video Accessories
PO Box 8419
Ronks, PA 17573

INDEX

A

Access Card
 entry 43
 number 10
Accessories 59
All button 24
AlphaSort button 24
Alternate data 43
Attractions Guide 21, 33
Audio Language 43

B

Back panel controls 6
Batteries
 installing in remote 10
Buttons 12

C

Cancelling purchases 35
Channel banner 17
 anatomy 17
 icons 17
Channel Guide 18
Channel lists 37
 add channels 37
 delete channels 37
Codes 13
Connections 7-8
 audio/video quality 8
 jacks and cables 5

D

Data port 17, 46
Default guide 18
Detail Guide 18
Digital satellite receiver
 back panel 6
 connecting 7-8
DIRECTV button 12, 28, 52,
 54
Dish Pointing 44
 azimuth 44
 elevation 44
 menu 44

E

Exiting
 menus 28, 29
 program guides 16, 20

F

Fetch
 button 50
 customizing 48-49
 menu 49
Front panel controls 6, 12

G

Glossary 42
Grid Guide 18
GUIDE button 16, 18

H

Help 26
Home Control 46
 accessories 46, 59
 icon 17
 menu 46
 setup 46
 timers 47

I

Icons 16, 40, 47
Interactive setup 10

L

Light on front panel 31, 54
Locking
 a profile 39
 the system 40
Logo Guide 20
Look and feel 42

M

Mailbox
 checking your mail 31, 54
 icon 17
Main menu 28
Menu system 28
 exit 28
 help 28
 navigation 13
Menus
 Dish Pointing 44
 Fetch 48
 Home Control 46
 Mailbox 31
 Options 43
 Profiles 36
 Program Guide 16
 Purchases 32
 Timers 36
Movies button 23

O

Options menu 41
Other Guides
 Attractions Guide 21
 button 21

P

Passwords 32
Pay-per-view programs 32
 tuning to 32
Power (on/off) 12, 54
Profiles
 channel lists 37
 choosing 41
 locking 39
 menu 29, 38
 ratings limits 37
 spending limits 39
 unlocking 40
 viewing hours 38

Program guides 16, 18

 anatomy 16
 Attractions Guide 21
 buttons 18
 Channel Guide 18
 default 18
 Detail Guide 18
 exiting 18
 Grid Guide 18
 Logo Guide 20
 scrolling 18
 sorting 22
 SurfGuide 18

Programming the Remote 13

 to control a TV 13

Purchases 32
 cancelling 35
 menu 34
 reviewing 35
 spending limits 35

R

Ratings limit 37
Remote control
 batteries 10
 buttons 12
 programming 13
Reviewing purchases 35

S

Scout 25
Screen, blank 54
Scrolling 18

Signal meter 45
 peak signal 44

Sorting

 program guides 22
Sorting by
 All button 22
 AlphaSort button 24
 Movies button 23
 Other Guides button 20
 Scout button 25
 Sports button 22
 Topics button 21

Spending limits 35, 38

Sports button 24
SurfGuide 18
System Info 42
System lock 40
System options 42
System test 43, 53
System unlock 40

T

Timer feature
 editing or cancelling 36, 54
Timers
 Home Control 47
 icons 46
Timers menu 36
Topics button 23
Troubleshooting 52
Tuning to a program 19

U

Unlocking
 a profile 39
 the system 40

V

Viewing hours limit 38

W

Warranty information 55

If your satellite system needs service, please contact your dealer or the nearest Servicenter from the Yellow Pages. Please do not send any products to the Indianapolis address listed in this manual or on the carton. This will only add delays in service for your product.

10330 North Meridian Street
Indianapolis, IN 46290

 **THOMSON CONSUMER ELECTRONICS**

©1998 Thomson Consumer Electronics, Inc.
Trademark(s)® Registered
Marca(s) Registrada(s)
Printed in USA
TOCOM 15351410



100%
RECYCLED PAPER
MINIMUM 40% POST CONSUMER

