

JPP-SCC-30

**MPPT Solar Charge Controller
User Manual**


Please read the instructions carefully before installation and use.

1. General Description

- 1.1 Charge current up to 30(50) A and PV voltage up to 100 V**
The JPP-SCC-30 MPPT solar charge controller is able to charge a lower nominal-voltage battery from a higher nominal voltage PV array. The controller will automatically adjust to a 12 or 24V nominal battery voltage.
- 1.2 Ultra-fast Maximum Power Point Tracking (MPPT)**
Especially in case of a clouded sky, when light intensity is changing continuously, an ultrafast MPPT controller will improve energy harvest by up to 30% compared to PWM charge controllers and by up to 10% compared to slower MPPT controllers.
- 1.3 Advanced Maximum Power Point Detection in case of partial shading conditions**
If partial shading occurs, two or more maximum power points may be present on the power-voltage curve. Conventional MPPT's tend to lock to a local MPP, which may not be the optimum MPP. The innovative JPP-SCC-30 algorithm will always maximize energy harvest by locking to the optimum MPP.
- 1.4 Outstanding conversion efficiency**
No cooling fan. Maximum efficiency exceeds 98%. Full output current up to 40°C (104°F).
- 1.5 Flexible charge algorithm**
Eight preprogrammed algorithms, selectable with a rotary switch.

- 1.6 Extensive electronic protection**
Over-temperature protection and power derating when temperature is high. PV short circuit and PV reverse polarity protection. PV reverse current protection.
- 1.7 Internal temperature sensor**
Compensates absorption and float charge voltages for temperature.
- 1.8 Automatic battery voltage recognition**
The JPP-SCC-30 will automatically adjust itself to a 12V or a 24V system.
- 1.9 Adaptive three-step charging**
The JPP-SCC-30 is configured for a three-step charging process: Bulk - Absorption - Float.
- 1.9.1. Bulk stage**
During this stage, the controller delivers as much charge current as possible to rapidly recharge the batteries.
- 1.9.2. Absorption stage**
When the battery voltage reaches the absorption voltage setting, the controller switches to constant voltage mode. When only shallow discharges occur, the absorption time is kept short in order to prevent overcharging of the battery. After a deep discharge the absorption time is automatically increased to make sure that the battery is completely recharged. Additionally, the absorption period is also ended when the charge current decreases to less than 2 A.
- 1.9.3. Float stage**
During this stage, float voltage is applied to the battery to maintain it in a fully charged state.

2. Safety instructions



WARNING

- please read this manual carefully before the product is installed and put into use.
- This product is designed and tested in accordance with international standards. The equipment should be used for the designated application only.
- Ensure that the equipment is used under the correct operating conditions. Never operate it in a wet environment.
- Never use the product at sites where gas or dust explosions could occur.
- Ensure that there is always sufficient free space around the product for ventilation.
- Refer to the specifications provided by the manufacturer of the battery to ensure

- **danger of explosion from sparking**
- **danger of electric shock**

- that the battery is suitable for use with this product. The battery manufacturer's safety instructions should always be observed.
- Protect the solar modules from incident light during installation, e.g. cover them.
 - Never touch uninsulated cable ends.
 - Use only insulated tools.
 - Connections must always be made in the sequence described in section 3.5.
 - The installer of the product must provide a means for cable strain relief to prevent the transmission of stress to the connections.

3. Installation

3.1 General

- Mount vertically on a non-flammable surface, with the power terminals facing downwards.
- Mount close to the battery, but never directly above the battery (in order to prevent damage due to gassing of the battery);.
- Use cables with at least 10 AWG cross section. The recommended maximum length of the cable is 5 m, in order to restrict cable loss. (If the cables to the PV panels must be longer than 5 m, increase cross section or use parallel cables and install a junction box next to the controller and connect with a short 10 AWG cable to the controller);.
- Grounding: the heatsink of the MPPT solar charge controller should be connected to the grounding point.

3.2 PV configuration

- The MPPT solar charge controller will operate only if the PV voltage exceeds battery voltage (Vbat).
- PV voltage must exceed Vbat + 5V for the MPPT solar charge controller to start.
- Thereafter minimum PV voltage is Vbat + 1V.
- Maximum open circuit PV voltage: 100V.
- The MPPT solar charge controller can be used with any PV configuration that satisfies the three above mentioned conditions.

For example:

- 12V battery and mono- or polycrystalline panels
- Minimum number of cells in series: 36 (12V panel);.
- Recommended number of cells for highest

controller efficiency:

- 72 (2x 12V panel in series or 1x 24V panel).
- Maximum: 144 cells (4x 12V or 2x 24V panel in series), 24V battery and mono-or polycrystalline panels
- Minimum number of cells in series: 72 (2x 12V panel in series or 1x 24V panel).
- Maximum: 144 cells.

Remark: at low temperature the open circuit voltage of a 144 cell solar array may exceed 100 V, depending on local conditions and cell specifications. In that case the number of cells in series must be reduced.

3.3 Cable connection sequence (see figure 1)

First: connect the battery.

Second: connect the solar array (when connected with reverse polarity, the controller will heat up but will not charge the battery).

3.4 More about automatic battery voltage recognition

The system voltage is stored in non-volatile memory.

3.5 Configuration of the controller

Fully programmable charge algorithm (see the software page on our website) and eight preprogrammed charge algorithms, selectable with a rotary switch:

Note: divide all values by two in case of a 12V system.

Pos	Suggested battery type	Absorption V	Float V	Equalize V@%Inom	dV/dT mV/°C
0	Gel long life (OPzV) Gel oxide A600 (OPzV) Gel MK	28,2	27,6	31,8@8%	-32
1	Gel deep discharge Gel Exide A200 AGM deep discharge Stationary tubular plate (OPzS) Rolls Marine (flooded) Rolls Solar (flooded)	28,6	27,6	32,2@8%	-32W
2	Default setting Gel deep discharge Gel Exide A200 AGM deep discharge Stationary tubular plate (OPzS) Rolls Marine (flooded) Rolls Solar (flooded)	28,8	27,6	32,4@8%	-32
3	AGM spiral cell Stationary tubular plate (OPzS) Rolls AGM	29,4	27,6	33,0@8%	-32
4	PzS tubular plate traction batteries or OPzS batteries	29,8	27,6	33,4@25%	-32
5	PzS tubular plate traction batteries or OPzS batteries	30,2	27,6	33,8@25%	-32
6	PzS tubular plate traction batteries or OPzS batteries	30,6	27,6	34,2@25%	-32
7	Lithium Iron Phosphate (LiFePo 4) batteries	28,4	27,0	n.a.	0

3.6 Battery charging information

The MPPT solar charge controller starts a new charge cycle every morning, when the sun starts shining.

The maximum duration of the absorption period is determined by the battery voltage measured just before the solar charger starts up in the morning:

Battery voltage Vb @start-up	Maximum absorption time
Vb < 12V	6 h
Vb < 12V	4 h
Vb < 12.2V	2h
Vb > 12.6V	1 h

(divide voltages by 2 for a 12 V system)

If the absorption period is interrupted due to a cloud or due to a power-hungry load, the absorption process will resume when absorption voltage is reached again later in the day, until the absorption period has been completed. The absorption period also ends when the output current of the solar charger drops to less than 2 Amps, not

because of low solar array output but because the battery is fully charged (tail current cut-off).
This algorithm prevents over charge of the battery due to daily absorption charging when the system operates without load or with a small load.

3.6.1 Automatic equalization

Automatic equalization is default set to "OFF". It is critical to confirm that your battery bank allows for equalization. By using the configuration tool mppiprnts the equalization setting can be configured with a number between 1 (every day) and 250 (once every 250 days). When automatic equalization is active, the absorption charge will be followed by a voltage limited constant current period (see table in section 3.5). The current is limited to 8% of the bulk current for all VRLA (Gel or AGM) batteries and some flooded batteries, and to 25% of the bulk current for all tubular plate batteries and the user defined battery type. The bulk current is the rated charger current unless a lower maximum current setting has been chosen. In case of all VRLA batteries and some flooded batteries (algorithm number 0, 1, 2 or 3) automatic

equalization ends when the voltage limit maxV has been reached, or after $t = (\text{absorption time})/8$, whichever comes first. For all tubular plate batteries and the user defined battery type automatic equalization ends after $t = (\text{absorption time})/2$. When automatic equalization is not completely finished within one day, it will not resume the next day, the next equalization session will take place as determined by the day interval.

4 Setting and display

SETUP	Cancel / back	
SELECT	Select / confirm	
	Change item or value	
	On	There is a connection with the MPPT solar charge controller.
	Blinking	There was a connection with the MPPT solar charge controller but the connection is lost. The last known values will be shown.
	Off	There has not been a connection with a MPPT solar charge controller.



A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R
S	T	U	V	W	X	Y	Z	0	1	2	3	4	5	6	7	8	9

Navigation Status

This shows the current status of the MPPT solar charge controller. By pressing the up and down button, one can switch between the following values:

##### W	PANEL POWER	
##### V	PANEL VOLTAGE	
##### kWh	YIELD TODAY	
##### I	CHARGERERROR	This is only visible when there is an actual error
#####	CHARGERSTATE	Possible value: OFF, FAULT, BULK, ABSORPTION, FLOAT
##### A	BATTERY CURRENT	
##### V	BATTERY VOLTAGE	

History

By pressing SELECT in the status menu, the history menu is entered. Here, the history stored in the MPPT solar charge controller can be viewed. This contains both overall history and well as a day to day history. This is a 30 day history.

When viewing values, one can select a different day by pressing the up and down button. The MPPT solar charge controller will first show the value for a short time, then the currently selected day, and then the value again. When viewing an overall history value, pressing the up or down button will cause the MPPT solar charge controller to show "TOTAL". Pressing SETUP causes the MPPT solar charge controller to go back to the status menu topics when viewing topics or go back to the topics menu when viewing values.

The topics are listed in the table below. Only topics marked with a * are visible in case of 2 day history.

Overall topics

##### kWh	TOTAL YIELD*	The cumulative yield since the last history reset
##### V	MAX PANEL VOLTAGE	The maximum panel voltage since the last history reset
##### V	MAX BATTERY VOLTAGE	The maximum battery voltage since the last history reset
##### V	MIN BATTERY VOLTAGE	The minimum battery voltage since the last history reset. (Only available for MPPT solar charge controller software version >= 1.17)
##### I	LAST ERRORS	The last 4 errors since the last history reset. The number of blocks in the lower right of the screens determines which error is currently shown with 1 block being the latest and 4 blocks being the oldest.


Daily topics

##### kWh	YIELD*	The daily yield
##### W	MAX POWER*	The maximum power per day
##### V	MAX PANEL VOLTAGE	The maximum panel voltage per day
##### A	MAX BATTERY CURRENT	The maximum battery current per day
##### V	MAX BATTERY VOLTAGE	The maximum battery voltage per day
##### V	MIN BATTERY VOLTAGE	The minimum battery voltage per day
##### h	BULK TIME	The time spend in bulk per day
##### h	ABSORPTION TIME	The time spend in absorption per day
##### h	FLOAT TIME	The time spend in float per day
##### I	LAST ERROR	The last 4 errors per day. The number of blocks in the lower right of the screens determines which error is currently shown.

Settings

By pressing SETUP for 2 seconds in the status menu, the settings menu is entered. Here, the MPPT solar charge controller setting can be viewed and changed. First the topic is shown and when SELECT is pressed, the corresponding value is shown. When SELECT+EDIT is OFF, the value is shown before it can be changed by pressing SELECT again. When SELECT TO EDIT is ON, the current value is shown and a new value can immediately be selected. When LOCK SETUP is ON, settings only be

changed after setting LOCK SETUP to off. When editing a value, one can change its value by pressing the up and down buttons. When changing numeric values, pressing SELECT will go to the next digit, until the last digit. In this case, pressing SELECT will save the setting. When editing non-numeric values, pressing SELECT will save the setting. Pressing SETUP causes the MPPT solar charge controller to go back to the status menu topics when viewing topics or go back to the topics menu when viewing values.



The topics are listed in the table below.

01 LOCK SETUP	When this is ON, other settings cannot be changed. When trying to change a setting (except LOCK SETUP), the MPPT solar charge controller will show "LOCK" and show the value of that setting.
02 BATTERY VOLTAGE	The battery voltage that the MPPT solar charge controller is working with. When the setting is AUTO, it will show the A character in front of the voltage. 5.0 A 12 V
03 BATTERY TYPE	The battery type that the MPPT solar charge controller is working with. This can be set to FIXED or USER. When set to fixed, the rotary switch on the MPPT solar charge controller determines the actual battery type. When set to USER, all other charging related settings can be edited. It will be automatically set to USER when editing a charger related setting.
04 MAXIMUM CURRENT	The maximum charging current
05 BULK TIME LIMIT	The maximum time continuously spent in bulk
06 ABSORPTION TIME LIMIT	The maximum time continuously spent in absorption
07 ABSORPTION VOLTAGE	Battery voltage at which the MPPT solar charge controller switches to the absorption phase
08 FLOAT VOLTAGE	Battery voltage at which the MPPT solar charge controllerswitches to the float phase
09 TEMP COMPENSATION	
13 CLEAR HISTORY	Cleans the history of the MPPT solar charge controller
14 FACTORY DEFAULTS	Resets the MPPT solar charge controller back to factory defaults
15 BACKLIGHT INTENSITY	Sets the backlight intensity of the LCD
16 BACKLIGHT ALWAYS ON	Determines whether the backlight of the LCD always on
17 SCROLL SPEED	Determines the scroll speed of the LCD
18 SELECT TO EDIT	When set to OFF, the MPPT solar charge controller first shows the value of a setting and SELECT has to be pressed to be able to edit the value
19 AUTO LOCK	When set to ON, LOCK SETUP will be automatically set to ON, 2 minutes after changing a setting.

5. Troubleshooting

Problem	Possible cause	Solution
Charger does not function	Reversed PV connection Reverse battery connection	Connect PV correctly Non-replaceable fuse blown. Return to VE for repair
The battery is not fully charged	A bad battery connection Cable losses too high Large ambient temperature difference between charger and battery (Tambient_chrg > Tambient_batt)	Check battery connection Use cables with larger cross section Make sure that ambient conditions are equal for charger and battery
The battery is being overcharged	A battery cell is defect Large ambient temperature difference between charger and battery (Tambient_chrg < Tambient_batt)	Replace battery Make sure that ambient conditions are equal for charger and battery
	Only for a 24V system: wrong system voltage chosen (12V instead of 24V) by the MPPT solar charge controller	Disconnect PV and battery, after making sure that the battery voltage is at least >19V, reconnect properly (reconnect battery first)

6. Specifications

Solar Charge Controller	MPPT 100/30D(50D)
System voltage	12/24 V Auto Select
Maximum battery current	30A(50)A
Maximum PV power, 12V 1a,b)	440(720) W (MPPT range 15 V to 80 V)
Maximum PV power, 24V 1a,b)	880(1440) W (MPPT range 30 V to 80 V)
Maximum PV open circuit voltage	100V
Peak efficiency	98%
Self-consumption	20mA
Charge voltage 'absorption'	Default setting: 14,4 V / 28,8 V (adjustable)
Charge voltage 'equalization'	Default setting: 16,2 V / 32,4 V (adjustable)
Charge voltage 'float'	Default setting: 13,8 V / 27,6 V (adjustable)
Charge algorithm	multi-stage adaptive (eight preprogrammed algorithms)
Temperature compensation	-16mV / °C resp. -32mV / °C
Protection	Battery reverse polarity (fuse, not user accessible) Output shortcircuit / Over temperature
Operating temperature	-30 to +60°C (full rated output up to 40°C)
Humidity	95 %, non-condensing
Maximum altitude	2000m
Environmental condition	Indoor, unconditioned
Pollution degree	PD3
ENCLOSURE	
Power terminals	13mm ² / AWG6
Protection category	IP22 (connection area)
Weight	1,25kg
Dimensions (X x Y x Z)	186x130 x 70mm
STANDARDS	
Safety	EN/IEC 62109

1a) If more PV power is connected, the controller will limit input power to 440(720)W resp. 880(1440)W
 1b) PV voltage must exceed Vbat + 5V for the controller to start. Thereafter minimum PV voltage is Vbat + 1V.