

# Panasonic Telephone Systems



www.voicesonic.com  
Phone 877-289-2829

KX-TDE100  
KX-TDE200  
KX-TDE600

## Programming Manual for Virtual SIP CO Line Card Pure IP-PBX

Panasonic KX-TDE100, KXTDE100, TDE100, KX-TDE200, KXTDE200, TDE200, KX-TDE600, KXTDE600, TDE600



Thank you for purchasing a Panasonic Pure IP-PBX.  
Please read this manual carefully before using this product and save this manual for future use.

**KX-TDE100/KX-TDE200: PMMPR Software File Version 3.0000 or later**  
**KX-TDE600: PGMPR Software File Version 3.0000 or later**

Document Version: 2009-12

# Table of Contents

<b>1</b>	<b>Overview</b>	<b>3</b>
1.1	Information about IP Telephony Service	4
1.2	Important Notice for Subscription and Installation	7
1.2.1	Port Requirements	7
1.2.2	Firewall Requirements	7
1.2.3	Bandwidth Requirements	8
1.3	Specifications	9
<b>2</b>	<b>Preparations for PC Programming</b>	<b>10</b>
2.1	Maintenance Console Operating Instructions	11
2.1.1	Installing and Starting the Maintenance Console	11
2.2	Installing the V-SIPGW16 Card to the PBX	15
<b>3</b>	<b>Programming the V-SIPGW16 Card</b>	<b>16</b>
3.1	Programming the V-SIPGW16 Card—Port Property	17
3.1.1	Main	18
3.1.2	Account	20
3.1.3	Register	22
3.1.4	NAT	24
3.1.5	Option	25
3.1.6	Calling Party	27
3.1.7	Called Party	30
3.1.8	Voice/FAX	31
3.1.9	RTP/RTCP	34
3.1.10	T.38	37
3.1.11	T.38 Option	39
3.1.12	DSP	40
3.1.13	Supplementary Service	42
3.2	Programming the V-SIPGW16 Card—Card Property	45
3.2.1	Card Property	45
3.3	Programming the V-SIPGW16 Card—Shelf Property	48
3.3.1	Main	48
3.3.2	Timer	51
<b>4</b>	<b>Maintenance</b>	<b>53</b>
4.1	Configuration Management	54
4.1.1	Importing/Exporting V-SIPGW16 Configuration Data and Provider Profiles	54
4.1.2	V-SIPGW16 Protocol Trace	55
<b>5</b>	<b>Appendix</b>	<b>56</b>
5.1	Revision History	57
5.1.1	KX-TDE100/KX-TDE200 PMMPR Software File Version 3.0xxx	57
5.1.2	KX-TDE600 PGMPR Software File Version 3.0xxx	57
	<b>Index</b>	<b>58</b>

---

# 1 Overview

*This section provides an overview of the V-SIPGW16 card.*

## 1.1 Information about IP Telephony Service


The Virtual 16-Channel SIP CO Line Card (V-SIPGW16) is a virtual CO line card which is designed to be easily integrated into an Internet Telephony Service provided by an ITSP (Internet Telephony Service Provider).

As a major SIP Provider, an ITSP provides its telephony service partly through the conventional telephone network (e.g., ISDN and Mobile), which is fee-based. An ISP (Internet Service Provider), another major SIP Provider, does not provide telephone connection itself. However, providing its users with Internet access, an ISP provides voice communication on the Internet for free. In this way, with VoIP technology based on the SIP protocol, the cost of voice communication can be much cheaper than conventional telephone networks.

The maximum of two V-SIPGW16 cards can be installed to the virtual CO line slots of the PBX. Therefore, the channel capacity of the card allows users to connect to up to 32 each different ISP/ITSPs.

### V-SIPGW16 Connection Outline

The following diagram illustrates a simple VoIP network connecting the V-SIPGW16 card to the Internet.



### Requirements for Internet Telephony Service

- You need to subscribe with an ISP for Internet connection.
- You need to subscribe with an ITSP for telephone connection. The ISP and ITSP may be part of the same company.

**Note**

- VoIP communication using the V-SIPGW16 card may deteriorate depending on the ITSP being used.
- VoIP communication using the V-SIPGW16 card may deteriorate depending on the network conditions.

## DNS (Domain Name System)

A DNS server normally provides the name resolution service for your computer. As domain names are alphabetic, they are easier to remember. The Internet, however, is based on IP addresses. Therefore, every time a domain name is used, a DNS server must translate the name into the corresponding IP address, and vice versa. For example, the domain name *www.example.com* may be translated to *192.0.34.166*. If one DNS server does not know how to translate a particular domain name, it asks another one, and so on, until the correct IP address is returned.

## NAT (Network Address Translation) Traversal


When NAT/NAPT (Network Address Port Translation) is enabled, the router translates a local IP address from the PBX into a global IP address. However, the router with NAT enabled does not translate local IP addresses stored in SIP messages into global IP addresses.

Therefore, the address which the SIP Server recognizes as the destination IP address to reply to is actually the local IP address of the PBX, not the global IP address of the router. Therefore, if the SIP server receives a SIP message from the PBX and sends a message back to the PBX using the address stored in the SIP message, the packet information will not reach the PBX.

STUN Servers function to solve the global IP address problem under certain NAT conditions, for example, in case of full duplex communication. A STUN Server, used alongside the SIP Server, finds out the global IP address of the router with NAT enabled. With the STUN feature enabled, the packet information sent by the SIP Server is able to "traverse" NAT and reach the PBX.

The settings can be configured to specify whether to enable the NAT Traversal feature for each ISP/ITSP. In addition, the NAT Traversal method can be selected from "STUN" and "Fixed IP Address" (refer to 3.3.1 Main, NAT Traversal).

The V-SIPGW16 card may require the NAT Traversal feature to be enabled to connect to the WAN via a router. The following diagram illustrates how VoIP communication is enabled between the V-SIPGW16 card and the SIP Server (SIP Receiver) via a router with NAT enabled.



### Note

- If an ISP/ITSP uses a device such as SBC (Session Border Controller), you may not have to enable the NAT Traversal feature.
- A STUN Server is supplied by an ISP/ITSP, and not included with the PBX.

## 1.2 Important Notice for Subscription and Installation

### 1.2.1 Port Requirements

#### Required Ports for Each Channel

When configuring a router with NAT enabled, you need to secure a certain number of ports for each SIP and RTP/RTCP channel. For RTP/RTCP, the number of required ports is double the number of activated SIP CO lines (Ch). For SIP signaling, the number of required ports is always one regardless of the number of activated SIP CO lines (Ch).

<Example>

If 4 SIP CO line channels are activated, you need the following number of ports:

Protocol Type	Required Port
RTP	4
RTCP	4
SIP	1
Total	9

### 1.2.2 Firewall Requirements

If the VoIP network contains a firewall, you must configure the firewall to allow VoIP packets to pass through certain ports of the ports listed below without being blocked by filtering. The ports for which you need to configure the firewall may vary depending on the network conditions.

For more information, consult your network administrator.

#### [IP Packets to V-SIPGW16 Card]

Port	TCP/UDP	Default Port No.
SIP Client Port	UDP	35060
STUN Client Port	UDP	33478
NAT Voice (RTP) UDP Port	UDP	16000 to N
DNS (Client) Port	UDP	30053

#### [IP Packets from V-SIPGW16 Card]

Port	TCP/UDP	Default Port No.
SIP Server Port	UDP	5060
Registrar Server Port	UDP	5060
STUN Server Port	UDP	3478
Manual DNS Server Port	UDP	53

## Router Requirements

- Port Forwarding:  
It may be necessary to set the NAT router so that it forwards the incoming packets to the IP address of the V-SIPGW16 card if all of the following conditions are met:
  - the PBX uses a STUN server;
  - a V-SIPGW16 card is located under a NAT router;
  - incoming packets are routed to a SIP Client port or NAT Voice (RTP) UDP port indicated in the **[IP Packets to V-SIPGW16 Card]** table above.

- SIP-NAT Feature:  
When a V-SIPGW16 card is located under a NAT router that supports the SIP-NAT feature<sup>1</sup>, it is recommended to disable this feature.

<sup>1</sup> When NAT is enabled, the router translates the IP address stored in the IP header and the port number stored in the UDP header. When SIP-NAT is enabled, the router also translates the IP address and port number stored in SIP messages.

## 1.2.3 Bandwidth Requirements

When using the V-SIPGW16 card, you must ensure that the WAN has enough bandwidth to support VoIP communications. Refer to the table below and ensure that the sum of the required bandwidth for each channel is smaller than the amount the WAN (e.g., ADSL network) can provide.

Note that the amount in the table is only a guide. Subscribe to a network that has enough bandwidth. If the amount of bandwidth required for VoIP communications is larger than what the network can accommodate, speech quality will be compromised.

### Required Bandwidth for Each Channel

The required bandwidth depends on what combination of codecs and packet sending interval is used. Keep in mind the following points about the type of codec and packet sending interval, in terms of the speech quality:

- The speech quality of the codecs varies as follows: G.711 (High), G.729A (Low)
- The shorter the packet sending interval, the higher the speech quality.
- The higher the speech quality the V-SIPGW16 card provides, the more bandwidth the WAN requires.

Codec	Packet Sending Interval					
	10 ms	20 ms	30 ms	40 ms	50 ms	60 ms
G.711	110.4 kbps	87.2 kbps	79.5 kbps	75.6 kbps	73.3 kbps	71.7 kbps
G.729A	54.4 kbps	31.2 kbps	23.5 kbps	19.6 kbps	17.3 kbps	15.7 kbps



## 1.3 Specifications

For details about the RFCs and protocols for the V-SIPGW16 card, refer to the following specifications.

Items	Specification
SIP RFCs	RFC3261 (UDP only)
	RFC3262 (PRACK)
	RFC3264 (Offer/Answer)
	RFC3311 (UPDATE)
	RFC3581 (Symmetric Response Routing/rport)
	RFC4028 (Session Timer)
Codecs	G.711 (a-law and $\mu$ -law)
	G.729A
Voice Options	Echo Cancellation (48 ms)
	Jitter Buffer (200 ms)
	VAD (Voice Activity Detection)
	PLC (Packet Loss Concealment)
DTMF Relay	Inband/Outband (RFC2833)/Outband (SIP INFO)
Fax Relay	G.711 Inband/T.38
Protocol/Function	RTP
	RTCP
	DNS (A/SRV)
	NAT Traversal (STUN)
	QoS (ToS field setting in IP header of RTP/RTCP)

---

## 2 Preparations for PC Programming

*This section serves as reference operating instructions when using the Maintenance Console software to program the V-SIPGW16 card.*

## 2.1 Maintenance Console Operating Instructions

### 2.1.1 Installing and Starting the Maintenance Console

System programming, diagnosis and administration for the V-SIPGW16 card can be performed with a PC using the Maintenance Console. This section describes how to install and start the Maintenance Console.

#### System Requirements

##### Required Operating System

- Microsoft® Windows® XP or Windows Vista® Business operating system

##### Minimum Hardware Requirements

- HDD: 100 MB of available hard disk space

##### Recommended Display Settings

- Screen resolution: XGA (1024 × 768)
- DPI setting: Normal size (96 DPI)

#### Hardware Requirements

- Make sure that the PBX, IPCMPR (for KX-TDE100/KX-TDE200)/IPCEMPR (for KX-TDE600) card, and DSP card are installed.
- Make sure that the PBX is fully connected to your PC.

##### Note

For details about installation, refer to "3 Installation" in the Installation Manual.

#### Trademarks

- Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- All other trademarks identified herein are the property of their respective owners.
- Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.

#### Copyright for MD5

This software uses the Source Code of RSA Data Security, Inc. described in the RFC1321 (MD5Message-Digest Algorithm).

Copyright (C) 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing this software or this function.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this documentation and/or software.

## Installing the Maintenance Console

### Note

- Make sure to install and use the latest version of the Maintenance Console.
  - To install or uninstall the software on a PC running Windows XP Professional, you must be logged in as a user in either the "Administrators" or "Power Users" group.
  - To install or uninstall the software on a PC running Windows Vista Business, you must be logged in as a user in the "Administrators" group.
  - Product specifications, including text displayed by the software, are subject to change without notice.
1. Copy the setup file of the Maintenance Console to your PC.
  2. Double-click the setup file to run the installer.
  3. Follow the on-screen instructions provided by the installation wizard.

## Starting the Maintenance Console and Assigning the Basic Items (Quick Setup)

When you start the Maintenance Console with the Installer Level Programmer Code and connect to the PBX for the first time after initialization (with the factory default setting), Quick Setup will launch automatically. During Quick Setup, you will set up the basic items. For details about the basic items, refer to "14.1.2 Quick Setup" in the Feature Manual.

1. Connect the PC to the PBX with an Ethernet straight cable or RS-232C cross cable.
2. Start the Maintenance Console from the Start menu.
3. "Information before programming" appears.
  - a. Carefully read this important additional information, which includes updates to this and other manuals.
  - b. Click **OK** to close this window.
4.
  - a. Enter the Installer Level Programmer Code (default: **INSTALLER**).
  - b. Click **OK**.
5. Click **Connect**.
6.
  - a. Select **KX-TDE600** from **PBX Model**.
  - b. Select the **LAN** or **RS-232C** tab, depending on the type of PC connection with the PBX.
  - c. Specify the settings as required.

### Note

When connecting to the PBX for the first time selecting **LAN**, the **IP Address** and **Port Number** must be set to **192.168.0.101** and **35300** respectively.

- d. Enter the system password for installer (default: **1234**).
  - e. Click **Connect**.
7. Follow the instructions of the Quick Setup wizard for the basic items in Quick Setup.

8. On the IP addressing information screen, the information for the IPCMPR/IPCEMPR card can be assigned automatically through a DHCP server or entered manually.

**Note**

If you change any information on this screen and click **Apply**, the PBX will need to be reset.

**When using a DHCP server:**

- a. Select **Enable** for the **DHCP Client** setting.
- b. Click **Apply**.

**Note**

The boxes will turn grey and the IP addresses will be assigned automatically after the PBX is reset.

**When not using a DHCP server:**

- a. Select **Disable** for the **DHCP Client** setting.
- b. For KX-TDE100/KX-TDE200, type the IP address of the IPCMPR card in the **IP Address for IPCMPR Card** box. For KX-TDE600, type the IP address of the IPCEMPR card in the **IP Address for IPCEMPR Card** box.<sup>1</sup>
- c. In the **IP Address for VoIP-DSP** box, type the IP address of the DSP16 or DSP64 card.<sup>2</sup>
- d. In the **Subnet Mask** box, type the subnet mask address of the network.<sup>3</sup>
- e. In the **Default Gateway** box, type the IP address of the default gateway.<sup>4</sup>
- f. Click **Apply**.

**When using a DHCP server to obtain a DNS server IP address automatically:**

- a. Select **DHCP** for the **DNS Server Address Method** setting.
- b. Click **Apply**.

**Note**

The boxes will turn grey and the IP addresses will be assigned automatically after the PBX is reset.

**When not using a DHCP server to obtain a DNS server IP address automatically:**

- a. Select **Manual** for the **DNS Server Address Method** setting.
- b. In the **Manual Preferred DNS Server IP Address** box, type the IP address of the preferred DNS server.
- c. In the **Manual Alternate DNS Server IP Address** box, type the IP address of the alternate DNS server.
- d. Click **Apply**.

9. Follow the instructions of the Quick Setup wizard in Quick Setup.  
The system menu appears. You may now begin programming the PBX.

### **Notice**

- Do not change the IP addresses of the IPCMPR/IPCEMPR and DSP cards once IP telephones are registered to the PBX using these IP addresses.  
The IP telephones will not operate properly if these IP addresses are changed.
- A DHCP server must be able to use a "client identifier" option specified by RFC 2131.
- The PBX will not start properly if the IP addresses cannot be assigned automatically by the DHCP server when DHCP Client is set to Enable. In this case, you need to consult your network administrator because the DHCP server on your network may not be running or a network failure may have occurred. If the DHCP server cannot be available, change the DHCP Client setting to Disable and set fixed IP addresses, then restart the PBX.  
To change the DHCP Client setting, connect the PC with an RS-232C cross cable or Ethernet straight cable. When connecting the PC with an Ethernet straight cable, make sure the PBX is disconnected from the LAN and then connect the PC with an Ethernet straight cable using 192.168.0.101 for the IP address of the IPCMPR/IPCEMPR card.

\*1 Valid IP address range: "1.0.0.0" to "223.255.255.255"

\*2 Valid IP address range: "1.0.0.0" to "223.255.255.255"

\*3 Valid subnet mask address range: "0-255.0-255.0-255" (except 0.0.0.0 and 255.255.255.255)

\*4 Valid IP address range: "1.0.0.0" to "223.255.255.255"

## 2.2 Installing the V-SIPGW16 Card to the PBX

1.
  - a. Under **Configuration**, click **Slot**.
  - b. Move the mouse pointer over the white PBX image at the bottom of the screen for the virtual slots.
  - c. Click **Select Shelf**.
2.
  - a. Click on the name of the **V-SIPGW16** card. An image of the card will be displayed.
  - b. Drag the image of the card to a **Trunk** slot and release it. The card will move into the slot space.
3. Click **Yes** to confirm.

---

## 3 Programming the V-SIPGW16 Card

*This section serves as reference operating instructions when using the Maintenance Console software to program the V-SIPGW16 card.*



## 3.1 Programming the V-SIPGW16 Card—Port Property

Various settings can be programmed for each virtual SIP gateway port. To change the status of virtual SIP gateway ports, click **Command**.

### Accessing Port Properties




1. Under **Configuration**, click **Slot**.
2. Move the mouse pointer over the white PBX image at the bottom of the screen for the virtual slots.
3. Click **Select Shelf**.
4. Move the mouse pointer over the **V-SIPGW16** card.
5. Click **Port Property**.

### Programming Port Property

Some of the parameters can be automatically programmed by selecting the desired SIP provider for each virtual SIP gateway port.

#### Icon Description

In this section, the following icons show the different parameter type.

Icon	Description for Parameter Type
	Programmed automatically by selecting the desired SIP provider in <b>Select Provider</b> .
	Manual programming is compulsory.
	Manual programming is compulsory under certain conditions.
Not marked	Manual programming is optional.

#### Automatic Programming

Some of the parameters on this screen can be automatically programmed by selecting the desired SIP provider for each virtual SIP gateway port. A maximum of 32 SIP providers can be programmed, and a different SIP provider can be assigned to each virtual SIP gateway port.

Follow the steps below to configure a SIP provider.

1. Click **Select Provider**.  
A dialog box will appear. Available virtual SIP gateway port numbers are displayed in the list.
2. From the **Provider** menu, select the desired SIP provider.
3. Highlight the desired port numbers or click **Select All** to select all the virtual SIP gateway port numbers to be assigned to the SIP provider selected in step 2.
4. Click **Execute**.
5. Click **OK**.
6. Click **Apply**.  
Appropriate setting values designated by the SIP provider will be set in the parameters for the virtual SIP gateway ports.

#### Manual Programming

Follow the steps below to program the parameters which are not automatically programmed by selecting a provider.

1. Click a desired tab.

2. Enter information or select from the list for each parameter.

#### **Adding Settings to Provider Profiles**

Follow the steps below to add the settings to provider profiles.

1. Click **Add Provider**.  
A dialog box will appear. Available virtual SIP gateway port numbers are displayed in the list.
2. Highlight the desired port numbers or click **Select All** to select all the virtual SIP gateway port numbers to add the settings to provider profiles.
3. Click **Execute**.

## 3.1.1 Main

### Shelf

Indicates the shelf position (reference only).

#### **Default**

Current shelf type

#### **Value Range**

Shelf type

### Slot

Indicates the slot position (reference only).

#### **Default**

Current slot number

#### **Value Range**

Slot number

### Port

Indicates the port number (reference only).

#### **Default**

Current port number

#### **Value Range**

Port number

### Connection

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

#### **Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

**Channel Attribute**

Specifies the channel property of each port to enable several sessions to be performed for one subscription with the SIP provider.

**Default**

Not Used

**Value Range**

Basic channel: The subscriber channel that is assigned the SIP registration information.

Additional channel for ChN (N=1–16): The subordinative channel that uses the same registration information as a Basic channel for SIP sessions. Select the Basic channel number to which the Additional channel belongs.

Not Used: The channel is not in use.

**★ Provider Name**

Specifies the name of the SIP provider.

**Default**

Not stored.

**Value Range**

Max. 20 characters

**★ SIP Server Location—Name**

Specifies the domain name of the SIP proxy server.

**Note**

Specifies the domain name of the SIP proxy server.

**Default**

Not stored.

**Value Range**

Max. 100 characters

**☉ SIP Server Location—IP Address**

Specifies the IP address of the SIP proxy server. This setting is compulsory when not using the DNS server.

**Note**

Specify the IP address of the outbound proxy server, if provided by the SIP provider.

**Default**

Not stored.

**Value Range**

1.0.0.0–223.255.255.255

#### ★ SIP Server Port Number

Specifies the port number of the SIP proxy server.

**Default**

5060

**Value Range**

1–65535

#### ★ SIP Service Domain

Specifies the domain name provided by the SIP provider.

**Default**

Not stored.

**Value Range**

Max. 100 characters

#### Subscriber Number

Specifies the number used as the CLIP number.

**Default**

Not stored.

**Value Range**

Max. 16 digits (consisting of 0–9, \*, and #)

## 3.1.2 Account

### Shelf

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

### Slot

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

**Port**

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

**Connection**

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

**⊙ User Name**

Specifies the user name (SIP Account) provided by the SIP provider.

**Default**

Not stored.

**Value Range**

Max. 64 characters

**⊙ Authentication ID**

Specifies the authentication ID required for registration with the SIP server.

**Default**

Not stored.

**Value Range**

Max. 64 characters

**⊙ Authentication Password**

Specifies the authentication password used for registration with the SIP provider.

**Default**

Not stored.

**Value Range**

Max. 32 characters

## 3.1.3 Register

### Shelf

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

### Slot

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

### Port

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

### Connection

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

### ★ Register Ability

Specifies whether to send the REGISTER message to the SIP server.

**Default**

Enable

**Value Range**

Disable, Enable

### ★ Register Sending Interval

Specifies the maximum length of interval time after which the PBX sends the REGISTER message.

**Default**

3600 s

**Value Range**

10–86400 s

### Un-Register Ability when port INS

Specifies whether to unregister the previous registration and send the REGISTER message to the SIP server when the port status is set back to INS.

**Default**

Enable

**Value Range**

Disable, Enable

### ★ Registrar Server—Name

Specifies the domain name of the SIP registrar server.

**Default**

Not stored.

**Value Range**

Max. 100 characters

### ☉ Registrar Server—IP Address

Specifies the IP address of the SIP registrar server. This setting is compulsory when a register IP address is provided.

**Default**

Not stored.

**Value Range**

1.0.0.0–223.255.255.255

#### ★ Registrar Server Port Number

Specifies the port number of the SIP registrar server.

**Default**

5060

**Value Range**

1–65535

## 3.1.4 NAT

### Shelf

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

### Slot

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

### Port

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

### Connection

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status



**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

**★ STUN Server—Name**

Specifies the domain name of a STUN server.

**Default**

Not stored.

**Value Range**

Max. 100 characters

**☉ STUN Server—IP Address**

Specifies the IP address of the STUN server. This setting is compulsory when the STUN method is selected and a DNS server is not used.

**Default**

Not stored.

**Value Range**

1.0.0.0–223.255.255.255

**★ STUN Server Port Number**

Specifies the port number of the STUN server.

**Default**

3478

**Value Range**

1–65535

## 3.1.5 Option

**Shelf**

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

**Slot**

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

**Port**

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

**Connection**

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

**★ Session Refresh (Session Timer)—Session Timer Ability**

Enables the PBX to periodically refresh SIP sessions by sending repeated requests.

**Default**

Enable (Passive)

**Value Range**

Disable: This feature is not activated.

Enable (Active): Activates this feature only if the other device supports the feature.

Enable (Passive): Activates this feature only when requested by the other device.

**★ Session Refresh (Session Timer)—Session Expire Timer**

Specifies the length of time that the PBX waits before terminating SIP sessions when no reply to the repeated requests is received.

**Default**

180 s

**Value Range**

90–3600 s

**★ Session Refresh (Session Timer)—Refresh Method**

Specifies the type of request that the PBX sends to periodically refresh SIP sessions.

**Default**

re-INVITE

**Value Range**

UPDATE, re-INVITE

**Proxy-Require Option**

Specifies option tags in a Proxy-Require header field so that the SIP server is notified that the client is behind a router with NAT enabled and firewall.

**Default**

Not stored.

**Value Range**

Max. 100 characters

## 3.1.6 Calling Party

**Shelf**

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

**Slot**

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

**Port**

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

**Connection**

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

**★ Header Type**

Specifies the header of the SIP message in which the caller information is stored.

**Default**

From Header

**Value Range**

From Header, P-Preferred-Identity Header

**★ From Header—User Part**

Specifies the value to be stored in the username part of the SIP-URI of the From header.

**Default**

User Name

**Value Range**

User Name, Authentication ID, PBX-CLIP

**From Header—SIP-URI**

Specifies the complete SIP-URI address of the From header. The configuration in **From Header—User Part** will be invalid if this parameter is set.

**Default**

Not stored.

**Value Range**

Max. 100 characters

### ★ P-Preferred-Identity Header—User Part

Specifies the value to be stored in the username part of the SIP-URI of the P-Preferred-Identity header.

#### Default

User Name

#### Value Range

User Name, Authentication ID, PBX-CLIP

### P-Preferred-Identity Header—SIP-URI

Specifies the complete SIP-URI address of the P-Preferred-Identity header. The configuration in **P-Preferred-Identity Header—User Part** will be invalid if this parameter is set.

#### Default

Not stored.

#### Value Range

Max. 100 characters

### ★ Number Format

Selects the format of the CLIP number to be sent to the called party.

#### Default

National

#### Value Range

International, +International, National

### ⦿ Remove Digit

Specifies the number of leading digits of the CLIP number to be removed. This setting is compulsory when **PBX-CLIP** is selected in **From Header—User Part** or **P-Preferred-Identity Header—User Part**.

#### Default

0

#### Value Range

0–32

### ⦿ Additional Dial

Specifies the number to be added to the CLIP number in the place of the removed digits. This setting is compulsory when **PBX-CLIP** is selected in **From Header—User Part** or **P-Preferred-Identity Header—User Part**.

#### Default

Not stored.

#### Value Range

Max. 20 digits (containing of 0–9, \*, and #)

## Anonymous format in "From" header

Specifies the format of the "From" header when not sending caller ID.

### Default

Display name and SIP-URI

### Value Range

Display name and SIP-URI, Display name only

### Note

If "**Display name and SIP-URI**" is selected, the display name part and the SIP-URI of the "From" header will be displayed as "**Anonymous**".

[Example]

From: **Anonymous** <sip:anonymous@anonymous.invalid>

If "**Display name only**" is selected, only the display name part of the "From" header will be displayed as "**Anonymous**".

[Example]

From: **Anonymous** <sip:1234@example.com>

## 3.1.7 Called Party

### Shelf

Indicates the shelf position (reference only).

### Default

Current shelf type

### Value Range

Shelf type

### Slot

Indicates the slot position (reference only).

### Default

Current slot number

### Value Range

Slot number

### Port

Indicates the port number (reference only).

### Default

Current port number

### Value Range

Port number

## Connection

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

### Default

Current status

### Value Range

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

## ★ Number Format

Specifies the format of an incoming call number.

### Default

National

### Value Range

International, +International, National

## ★ Type

Specifies the header of the incoming SIP message in which the dialed number is stored.

### Default

To header

### Value Range

Request-URI, To header

## 3.1.8 Voice/FAX

### Shelf

Indicates the shelf position (reference only).

#### Default

Current shelf type

#### Value Range

Shelf type

### Slot

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

**Port**

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

**Connection**

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

**IP Codec Priority—1st, 2nd, 3rd**

Specifies the priority of the codecs to be used. **None** is only available for 2nd and 3rd priorities.

**Default**

1st: G.711A

2nd: G.711 $\mu$

3rd: G.729A

**Value Range**

G.711A, G.711 $\mu$ , G.729A, None

**Packet Sampling Time (G.711A)**

Specifies the time interval between measurements (samples) of sound data during a conversation. The smaller this number, the higher the quality of the transmitted sound.

**Default**

20 ms



**Value Range**

10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms

**Packet Sampling Time (G.711 $\mu$ )**

Specifies the time interval between measurements (samples) of sound data during a conversation. The smaller this number, the higher the quality of the transmitted sound.

**Default**

20 ms

**Value Range**

10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms

**Packet Sampling Time (G.729A)**

Specifies the time interval between measurements (samples) of sound data during a conversation. The smaller this number, the higher the quality of the transmitted sound.

**Default**

20 ms

**Value Range**

10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms

**Voice Activity Detection for G.711**

Enables the use of the Voice Activity Detection feature for the G.711 codec. This feature conserves bandwidth by detecting silent periods during a call and suppressing the packets of silence from being sent to the network.

**Default**

Disable

**Value Range**

Disable, Enable

**FAX Sending Method**

Specifies the method of transporting the fax signal.

**Default**

G.711 Inband

**Value Range**

G.711 Inband, T.38

**Maximum Bit Rate**

Specifies the maximum bit rate of the fax signal.

**Default**

No Speed Limit

**Value Range**

No Speed Limit, 2400 bps, 4800 bps, 7200 bps, 9600 bps, 12000 bps, 14400 bps

## FAX Detection Ability

Enables the use of the FAX Detection Ability feature. This feature enables end-to-end fax signal relay when the other party prefers a codec other than G.711. This feature functions only if the other party supports G.711.

**Default**

Enable

**Value Range**

Disable, Enable

## ★ DTMF

Specifies the method to transport DTMF tones.

**Default**

Outband (RFC2833)

**Value Range**

Inband, Outband (RFC2833), Outband (SIP INFO)

## Payload Type

Specifies the payload type of RFC2833 for DTMF tones.

**Note**

Manual programming is required if **DTMF** is set to **Outband (RFC2833)**.

**Default**

101

**Value Range**

96–127

## 3.1.9 RTP/RTCP

### Shelf

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

## Slot

Indicates the slot position (reference only).

### Default

Current slot number

### Value Range

Slot number

## Port

Indicates the port number (reference only).

### Default

Current slot number

### Value Range

Port number

## Connection

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

### Default

Current status

### Value Range

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

## RTP QoS Ability

Specifies the type of value to be stored in the ToS field in the IP header.

### Default

ToS

### Value Range

ToS, DSCP, HEX

## RTP QoS-ToS Priority

Specifies the priority level in the ToS field.

### Default

0

**Value Range**

0–7

**RTP QoS-ToS Type**

Specifies the ToS type in the ToS field.

**Default**

Normal

**Value Range**

Normal, Monetary Cost, Reliability, Throughput, Delay

**RTP QoS-DSCP**

Specifies the value in the ToS field by a DSCP for DiffServ.

**Default**

Not stored.

**Value Range**

0–63

**RTP QoS-HEX**

Specifies the value in the ToS field by a hexadecimal number.

**Default**

Not stored.

**Value Range**

00–FF

**RTCP Packet Sending Ability**

Specifies whether to enable each port to send RTCP packets.

**Default**

Enable

**Value Range**

Disable, Enable

**RTCP Packet Interval**

Specifies the interval time until the next RTCP packet is sent.

**Default**

5 s

**Value Range**

5–60 s

**3.1.10 T.38****Shelf**

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

**Slot**

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

**Port**

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

**Connection**

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

### T38 FAX Max Datagram

Specifies the maximum datagram size when using the T.38 protocol.

**Default**

512

**Value Range**

272–512

### T38 FAX UDPTL Error Correction – Redundancy

Specifies whether to enable the redundancy feature when using the T.38 protocol.

**Default**

Enable

**Value Range**

Disable, Enable

### T38 FAX UDPTL Redundancy count for T.30 messages

Specifies the redundancy count for T.30 messages when using the T.38 protocol.

**Default**

3

**Value Range**

0–7

### T38 FAX UDPTL Redundancy count for data

Specifies the redundancy count for data when using the T.38 protocol.

**Default**

0

**Value Range**

0–3

### T38 FAX Rate Management Method

Specifies the rate management method when using the T.38 protocol.

**Default**

Transferred TCF

**Value Range**

Transferred TCF, Local TCF

## 3.1.11 T.38 Option

### Shelf

Indicates the shelf position (reference only).

#### Default

Current shelf type

#### Value Range

Shelf type

### Slot

Indicates the slot position (reference only).

#### Default

Current slot number

#### Value Range

Slot number

### Port

Indicates the port number (reference only).

#### Default

Current port number

#### Value Range

Port number

### Connection

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

#### Default

Current status

#### Value Range

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

### T38 FAX QoS Available

Specifies the type of value to be stored in the ToS field in the IP header when using the T.38 protocol.

#### Default

ToS

**Value Range**

ToS, DSCP, HEX

**T38 FAX QoS-ToS Priority**

Specifies the priority level in the ToS field when using the T.38 protocol.

**Default**

0

**Value Range**

0–7

**T38 FAX QoS-ToS Type**

Specifies the ToS type in the ToS field when using the T.38 protocol.

**Default**

Normal

**Value Range**

Normal, Monetary Cost, Reliability, Throughput, Delay

**☉ T38 FAX QoS-DSCP**

Specifies the value in the ToS field by a DSCP for DiffServ when using the T.38 protocol. This setting is compulsory when **DSCP** is selected in **T38 FAX QoS Available**.

**Default**

Not stored.

**Value Range**

0–63

**☉ T38 FAX QoS-HEX**

Specifies the value in the ToS field by a hexadecimal number when using the T.38 protocol. This setting is compulsory when **HEX** is selected in **T38 FAX QoS Available**.

**Default**

Not stored.

**Value Range**

00–FF

## 3.1.12 DSP

**Shelf**

Indicates the shelf position (reference only).



**Default**

Current shelf type

**Value Range**

Shelf type

**Slot**

Indicates the slot position (reference only).

**Default**

Current slot number

**Value Range**

Slot number

**Port**

Indicates the port number (reference only).

**Default**

Current port number

**Value Range**

Port number

**Connection**

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

**Default**

Current status

**Value Range**

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

**Echo Canceller Ability**

Specifies the echo canceller ability time.

**Default**

48 ms

**Value Range**

OFF, 48 ms, 128 ms

#### DSP Digital Gain (Down)

Specifies the DSP Digital Gain for the down voice path.

**Default**

0 dB

**Value Range**

-14–6 dB

#### DSP Digital Gain (Up)

Specifies the DSP Digital Gain for the up voice path.

**Default**

0 dB

**Value Range**

-14–6 dB

#### EC Gain

Specifies the Echo Canceller Gain.

**Default**

0 dB

**Value Range**

-14–6 dB

#### NLP Setting

Specifies the NLP (Non-Linear Processor) setting to control echo sound quality.

**Default**

Weak

**Value Range**

Disable, Weak, Normal, Strong

## 3.1.13 Supplementary Service

#### Shelf

Indicates the shelf position (reference only).

**Default**

Current shelf type

**Value Range**

Shelf type

## Slot

Indicates the slot position (reference only).

### Default

Current slot number

### Value Range

Slot number

## Port

Indicates the port number (reference only).

### Default

Current port number

### Value Range

Port number

## Connection

Indicates the port status.

This column offers two ways to open the screen to select the port command:

- Click the desired cell in the column.
- Select the desired cell in the column, and then click **Command**.

### Default

Current status

### Value Range

INS: The port is in service.

OUS: The port is out of service.

Fault: The port is not communicating with the network.

## CLIR

Specifies whether to allow restriction of the display of the CLIP number on the called party's telephone when making a SIP CO line call.

### Default

Yes

### Value Range

Yes, No

## ★ CNIP (Send)

Specifies whether to send the caller's name to be displayed on the called party's telephone when making a SIP CO line call.

### Default

Yes

**Value Range**

Yes, No

**★ CNIP (Receive)**

Specifies whether to receive the caller's name to be displayed on the called party's telephone when receiving a SIP CO line call.

**Default**

No

**Value Range**

Yes, No

## 3.2 Programming the V-SIPGW16 Card—Card Property

### 3.2.1 Card Property

The properties of the V-SIPGW card can be specified. To program the parameters, click **Common Settings**, and set the desired value.


#### Accessing Card Properties

1. Under **Configuration**, click **Slot**.
2. Move the mouse pointer over the white PBX image at the bottom of the screen for the virtual slots.
3. Click **Select Shelf**.
4. Move the mouse pointer over the **V-SIPGW16** card.
5. Click **Card Property**.

#### Programming Card Property

##### Icon Description

In this section, the following icons show the different parameter type.

Icon	Description for Parameter Type
	Manual programming is compulsory under certain conditions.
Not marked	Manual programming is optional.

#### DNS Server IP Address Method

Specifies the method of IP address assignment for a DNS server. When selecting **DHCP**, the DNS server IP address can be assigned automatically by a DHCP server. When selecting **Manual**, the DNS server IP address must be assigned manually.

##### Default

Manual

##### Value Range

DHCP, Manual

#### DHCP Preferred DNS Server IP Address

Indicates the IP address of the preferred DNS server assigned automatically by the DHCP server (reference only).

##### Default

Not stored.

##### Value Range

1.0.0.0–223.255.255.255

## DHCP Alternate DNS Server IP Address

Indicates the IP address of the alternate DNS server assigned automatically by the DHCP server (reference only).

### Default

Not stored.

### Value Range

1.0.0.0–223.255.255.255

## Manual Preferred DNS Server IP Address

Specifies the IP address of the preferred DNS server manually. This setting is compulsory if a DNS server IP address is not assigned automatically.

### Default

Not stored.

### Value Range

1.0.0.0–223.255.255.255

## Manual Alternate DNS Server IP Address

Specifies the IP address of the alternate DNS server manually.

### Note

If **Manual Preferred DNS Server IP Address** is programmed, this setting is optional. However, if possible, it is recommended to specify **Manual Alternate DNS Server IP Address** as well.

### Default

Not stored.

### Value Range

1.0.0.0–223.255.255.255

## Manual DNS Server Port Number

Specifies the port number of the DNS server.

### Default

53

### Value Range

1–65535

## DNS Port Number

Specifies the port number of the PBX used for communication with the DNS server.

### Default

30053

**Value Range**

1–65535

**DNS Retry Interval Timer**

Specifies the length of time until a query is retried when no response is received from the DNS server.

**Default**

3

**Value Range**

1–10 s

**DNS Retry Counter**

Specifies the number of times that a query is retried when no response is received from the DNS server.

**Default**

2

**Value Range**

1–10

**DNS SRV Record Resolve Ability**

Specifies whether to request that the DNS server translates domain names into IP addresses using the DNS SRV record.

**Default**

Enable

**Value Range**

Disable, Enable

## 3.3 Programming the V-SIPGW16 Card—Shelf Property

Common settings for all of the V-SIPGW cards installed in the IPCMPR (for KX-TDE100/KX-TDE200)/ IPCEMPR (for KX-TDE600) Virtual Shelf can be programmed.


### Accessing Shelf Properties

1. Under **Configuration**, click **Slot**.
2. Move the mouse pointer over the white PBX image at the bottom of the screen for the virtual slots.
3. Click **Select Shelf**.
4. Move the mouse pointer over the **V-SIPGW16** card.
5. Click **Shelf Property**.

### Programming Shelf Property

#### Icon Description

In this section, the following icons show the different parameter type.

Icon	Description for Parameter Type
	Manual programming is compulsory under certain conditions.
Not marked	Manual programming is optional.

## 3.3.1 Main

### SIP Client Port Number

Specifies the port number of the PBX used for communications with the SIP server.

#### Default

35060

#### Value Range

1–65535

### NAT Traversal

Specifies the NAT traversal method.

- STUN: A STUN Server, used alongside the SIP Server, finds out the global IP address of the router with NAT enabled.
- Fixed IP Address: The global IP address of the router with NAT enabled is fixed.

#### Note

Manual programming is optional except when programming is required depending on the network conditions.

#### Default

Off



**Value Range**

Off, Fixed IP Addr., STUN

**NAT - Voice (RTP) UDP Port No.**

Specifies the starting port number of the dynamic ports used for NAT Traversal.

**Default**

16000

**Value Range**

2–65000 (even number only)

**☉ NAT - Keep Alive Packet Sending Ability**

Specifies whether to send Keep Alive packets in order to maintain the NAT binding information. This setting may be compulsory depending on the network conditions.

**Default**

Disable

**Value Range**

Disable, Enable

**NAT - Keep Alive Packet Type**

Specifies the type of Keep Alive packets to be sent out.

**Default**

Blank UDP

**Value Range**

Blank UDP, None

**NAT - Keep Alive Packet Sending Interval**

Specifies the interval time until the next Keep Alive packet is sent.

**Note**

It is required to set this interval shorter than the NAT binding time of the router. The default value is appropriate in most cases.

**Default**

20 s

**Value Range**

1–60 s

### ☉ NAT - Fixed Global IP Address

Specifies the global IP address of the router with NAT enabled. This setting is compulsory if **Fixed IP Addr.** is selected in **NAT Traversal**.

**Default**

Not stored.

**Value Range**

1.0.0.0–223.255.255.255

### STUN Ability

Specifies whether to open a protocol port of the STUN server to enable STUN feature.

**Default**

Disable

**Value Range**

Disable, Enable

### STUN Client Port Number

Specifies the port number of the PBX used for communications with the STUN server.

**Default**

33478

**Value Range**

1–65535

### STUN External Address Detection Retry Counter

Specifies the number of times that a query is retried when no response is received from the STUN server.

**Default**

1

**Value Range**

0–8

### STUN Resending Interval

Specifies the length of time until a query is retried when no response is received from the STUN server.

**Default**

500 ms

**Value Range**

0–1600 ms

## SIP Called Party Number Check Ability

Specifies whether to receive a SIP CO line call when receiving the INVITE message with an incorrect target SIP-URI. The setting specified here is also applied when the request header is blank or contains characters that can not be modified to a receivable number.

### Default

Disable (High->Low)

### Value Range

Disable (High->Low), Disable (Low->High), Enable

## Symmetric Response Routing Ability

Enables this feature to request that the SIP server sends the response back to the source IP address and port from which the request originated.

### Default

Enable

### Value Range

Disable, Enable

## 100rel Ability

Specifies whether to add the option tag 100rel to the header field of the INVITE message.

### Default

Enable (Passive)

### Value Range

Disable: This feature is not activated.

Enable (Active): Activates this feature only if the other device supports the feature.

Enable (Passive): Activates this feature only when requested by the other device.

## Ringback Tone to Outside Caller

Enables the PBX to send a ringback tone to an outside caller when the network cannot send the tone.

### Default

Disable

### Value Range

Disable, Enable

## 3.3.2 Timer

### SIP T1

Specifies the retransmission interval time for INVITE requests and responses.

### Default

5 x 100 ms

**Value Range**

5–255 × 100 ms

**SIP T2**

Specifies the retransmission interval time for INVITE responses and non-INVITE requests.

**Default**

40 × 100 ms

**Value Range**

40–255 × 100 ms

---

## 4 Maintenance

*This section serves as reference operating instructions for data management of the V-SIPGW16 card using the Maintenance Console software.*

## 4.1 Configuration Management

### 4.1.1 Importing/Exporting V-SIPGW16 Configuration Data and Provider Profiles

The configuration data (V-SIPGW16 card—Port Property) or provider profiles (if updated provider profiles are available) for the V-SIPGW16 card can be exported or imported using the Import/Export tool. Follow the steps below to import or export the configuration data or provider profiles:

#### **Note**

To access the following menu options, you must be logged in to the Maintenance Console in Batch or Interactive mode at Installer level. For details about the software mode and access level, refer to "2.1.1 Starting Maintenance Console and Software Modes" and "2.1.2 Access Levels" in the PC Programming Manual.

#### **[Provider Profiles]**

##### **To import provider profiles**

1. From the **Tool** menu, point to **Import**, and then click **V-SIPGW16 Provider** to import.
2. Navigate to the folder containing the provider profiles you want to open.
3. Select the file.
4. Click **Open** to open the file.
5. Click **OK**.

##### **To export provider profiles**

1. From the **Tool** menu, point to **Export**, and then click **V-SIPGW16 Provider** to export.
2. Navigate to the folder in which you want to save the file.
3. Enter a file name.
4. Click **Save**.
5. Click **OK**.

#### **[Configuration Data (V-SIPGW16 card—Port Property)]**

##### **To import configuration data**

1. From the **Tool** menu, point to **Import**, and then click **V-SIPGW16 Settings** to import.
2. Navigate to the folder containing the provider profiles you want to open.
3. Select the file.
4. Click **Open** to open the file.
5. Click **OK**.

##### **To export configuration data**

1. From the **Tool** menu, point to **Export**, and then click **V-SIPGW16 Settings** to export.
2. Navigate to the folder in which you want to save the file.
3. Enter a file name.
4. Click **Save**.
5. Click **OK**.

#### **Note**

You cannot select which fields are imported or exported. The configuration data for all fields will be automatically imported or exported.

## 4.1.2 V-SIPGW16 Protocol Trace

The trace data of protocol activity can be collected from the V-SIPGW16 card and saved to the PC, using the utility, **V-SIPGW16 Protocol Trace**.

This option requires that the target V-SIPGW16 card be set to INS status.

Follow the steps below to trace and file V-SIPGW16 card protocol activity:

### **Note**

To access the following menu options, you must be logged in to the Maintenance Console in Batch or Interactive mode at Installer level. For details about the software mode and access level, refer to "2.1.1 Starting Maintenance Console and Software Modes" and "2.1.2 Access Levels" in the PC Programming Manual.

### **To save trace data to the SD Memory Card**

1. From the **Utility** menu, select **V-SIPGW16 Protocol Trace**.

When the progress bar disappears, the protocol trace is complete. The trace data has been saved to the SD Memory Card (file name: "PRTSIPC").

### **To transfer trace data to the PC**

1. From the **Utility** menu, select **File Transfer PBX (SD Card) to PC**.  
The list of trace data files will be displayed.
2. Select the desired trace data file.
3. Click **Transfer**.
4. Navigate to the folder in which you want to save the file.
5. Enter a file name.
6. Click **Save**.
7. Click **OK**.

---

# 5 Appendix



## 5.1 Revision History

### 5.1.1 KX-TDE100/KX-TDE200 PMMPR Software File Version 3.0xxx

#### New Contents

- 3.1 Programming the V-SIPGW16 Card—Port Property  
Adding Settings to Provider Profiles

#### Changed Contents

- 2.1.1 Installing and Starting the Maintenance Console  
Starting the Maintenance Console and Assigning the Basic Items (Quick Setup)

### 5.1.2 KX-TDE600 PGMPR Software File Version 3.0xxx

#### New Contents

- 3.1 Programming the V-SIPGW16 Card—Port Property  
Adding Settings to Provider Profiles

#### Changed Contents

- 2.1.1 Installing and Starting the Maintenance Console  
Starting the Maintenance Console and Assigning the Basic Items (Quick Setup)

# Index

- A**
- Accessing Card Properties 45
  - Accessing Port Properties 17
  - Accessing Shelf Properties 48
  - Adding Settings to Provider Profiles, Port Property 18
  - Automatic Programming, Port Property 17
- B**
- Bandwidth Requirements 8
- C**
- Card Property, Icon Description 45
  - Card Property, Programming 45
  - Configuration Management 54
- D**
- DHCP Server 13
  - DNS (Domain Name System) 5
  - DNS Server 5
- F**
- Firewall Requirements 7
  - Fixed IP Address 5
- H**
- Hardware Requirements 11
- I**
- Icon Description, Card Property 45
  - Icon Description, Port Property 17
  - Icon Description, Shelf Property 48
  - Important Notice for Subscription and Installation 7
  - Installing and Starting the Maintenance Console 11
  - Installing the V-SIPGW16 Card to the PBX 15
  - ISP (Internet Service Provider) 4
  - ITSP (Internet Telephony Service Provider) 4
- M**
- Maintenance 53
  - Manual Programming, Port Property 17
- N**
- NAT (Network Address Translation) Traversal 5
- P**
- Port Property, Automatic Programming 17
  - Port Property, Icon Description 17
  - Port Property, Manual Programming 17
  - Port Requirements 7
  - Programming Card Property 45
  - Programming Port Property 17
  - Programming Shelf Property 48
- Provider Profiles 54
- Q**
- Quick Setup 12
- R**
- Required Bandwidth for Each Channel 8
  - Revision History, KX-TDE100/KX-TDE200 PMMPR Software File Version 3.0xxx 57
  - Revision History, KX-TDE600 PGMPR Software File Version 3.0xxx 57
  - Router Requirements 8
- S**
- SBC (Session Border Controller) 6
  - Shelf Property, Icon Description 48
  - Specifications 9
  - STUN 5
  - STUN Server 5
  - System Requirements 11
- V**
- V-SIPGW16 Connection Outline 4
  - V-SIPGW16 Protocol Trace 55



DUBUgcb]WHY`Yd\ cbY`GngHya g



See More  
Panasonic Manuals



[www.voicesonic.com](http://www.voicesonic.com)  
Phone 877-289-2829

---

**Copyright:**

This material is copyrighted by Panasonic System Networks Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic System Networks Co., Ltd.

© Panasonic System Networks Co., Ltd. 2009