

REFRIGERATOR

BOTTOM MOUNT FREEZER

MODEL NAME: RF195AC RF197AC

RF215AC RF217AC RF20HFENB RF18HFENB

SERVICE Manual

REFRIGERATOR



CONTENTS

- 1. PRECAUTIONS(SAFETY WARNINGS)
- 2. PRODUCT SPECIFICATIONS
- 3. DISASSEMBLY AND REASSEMBLY
- 4. TROUBLESHOOTING
- 5. EXPLODED VIEW & PARTS LIST
- 6. PCB DIAGRAM
- 7. WIRING DIAGRAM
- **8. SCHEMATIC DIAGRAM**

For the latest parts information, Please access to our service web site (North America: http://service.samsungportal.com)



IMPORTANT SAFETY NOTICE

The service guide is for service men with adequate backgrounds of electrical, electronic, and mechanical experience. Any attempt to repair a major appliance may result in personal injury and property damage. The manufacturer or dealer cannot be responsible for the interpretation of this information.

SAMSUNG ELECTRONICS AMERICA, INC.

Technical Service Guide Copyright © 2009

All rights reserved. This service guide may not be reproduced in whole or in part in any form without written permission from the SAMSUNG ELECTRONICS Company.

Contents

1. PRECAUTIONS(SAFETY WARNINGS)	• •		• •	• •		• •	•	• • 4
2. Product Specifications · · · · · · · · · · · · · · · · · · ·								7
2-1) Introduction of Main Function · · · · · · · · · · · · · · · · · · ·								7
2-2) Specifications · · · · · · · · · · · · · · · · · · ·								8
2-3) Interior Views · · · · · · · · · · · · · · · · · · ·								9
2-4) Model Specification · · · · · · · · · · · · · · · · · · ·								. 10
2-5) Model Specification & Specification Chart · · · · · · · · · · ·								
2-6) Dimensions of Refrigerator (Inches)								
2-7) Refrigerant Route in Refrigeration cycle · · · · · · · · · · · ·								
2-8) Cooling Air Circulation · · · · · · · · · · · · · · · · · · ·								
,								
3. Disassembly and Reassembly \cdot								· 17
3-1) PRECAUTION · · · · · · · · · · · · · · · · · · ·								· 17
3-2) Refrigerator Door								· 18
3-3) Freezer Door(RF195) · · · · · · · · · · · · · · · · · · ·								· 19
3-3) Freezer Door(RF217,RF197) · · · · · · · · · · · · · · · · · · ·								· 20
3-4) Freezer Door Switch								· 21
3-5) Refrigerator Light								. 22
3-6) Glass shelves								. 22
3-7) Moving trav · · · · · · · · · · · · · · · · · · ·								. 23
3-8) Vegetable & Fruit Drawers Shelf · · · · · · · · · · · · · · · · · · ·								. 23
3-9) Gallon Door Bin								. 24
3-10) Evaporator In Refrigerator · · · · · · · · · · · · · · · · · · ·								. 24
3-11) Door Handle Freezer · · · · · · · · · · · · · · · · · ·								. 26
3-12) Freezer Light								. 26
3-13) Evaporator Cover In Freezer · · · · · · · · · · · · · · · · · · ·								. 27
3-14) Evaporator InFreezer · · · · · · · · · · · · · · · · · · ·								. 27
3-15) Motor Fan								. 28
,								
4. TROUBLESHOOTING								. 30
4-1) Check items before failure diagnosis · · · · · · · · · · · · · · · · · ·								. 30
4-2) Diagnostic method according to the trouble symptom(Flow Chart)								· 41
5 F ALALANY A PARTOLIOT								
5 . Exploded View & PARTS LIST · · · · · · · · · · · · · · · · · · ·		• •		• • •	•		• •	. 59
5-1) Freezer · · · · · · · · · · · · · · · · · · ·		• • •		• • •	•			. 59
5-2) Refrigerator · · · · · · · · · · · · · · · · · · ·								
5-3) Cabinet · · · · · · · · · · · · · · · · · · ·								
5-4) Disassembly of Freezer Door								
5-5) Disassembly of Refrigerator Door Left · · · · · · · · · · · ·		• • •		• •	•		• •	• 73
5-6) Disassembly of Refrigerator Door Right								
5-1) Freezer · · · · · · · · · · · · · · · · · · ·								
5-2) Cabinet · · · · · · · · · · · · · · · · · · ·								
5-3) Disassembly of Freezer Door		• •			•			· 84
6. PCB DIAGRAM · · · · · · · · · · · · · · · · · · ·								. 86
6-1) PCB L ayout with part position (Main Board)								. 00
6-2) Connector Layout with part position (Main Board)								. 00
0-2) Connector Layout with part position (Main Doard)		• •		•	•	•	•	. 0/
7. Wiring Diagram · · · · · · · · · · · · · · · · · · ·								. 88
······································								50
8. Schematic Diagram								
8-1) Refrigerator Block Diagram · · · · · · · · · · · · · · · · · · ·								
8-2) Main · · · · · · · · · · · · · · · · · · ·								

1. PRECAUTIONS(SAFETY WARNINGS)

- Due to the risk of electric shock, be sure to unplug the unit before servicing.
- Use the right electronic equipment for your new Refrigerator.
 - Make sure to check out the right model name, rated voltage and current, operating temperature, etc.
- Upon repair, make sure that harnesses are not to be water-penetrated and are bundled tight.
 - ⇒ Should not be detached by a certain amount of external force.
- Upon repair, completely remove dust or other foreign substances from housing, harness, connector, etc.
 - ⇒ To prevent fire by tracking, short, etc.
- After repair, check out the assembled state of parts.
- Check out the surrounding conditions.
 - ⇔ Change the location, if the fridge is located at humid, wet places or the installed state is unstable.
- If needed, ground the fridge.
 - ⇒ Especially, if there is a possibility of electric leakage, ground is indispensable.
- Do not allow consumers to overload a certain outlet.
- Check out whether the power cord or the outlet is broken, squeezed, chopped off or heatdeformed.
 - Repair or replace the defective power cord/outlet immediately.
 - ⇒ Make sure the power cord is not punctuated or stomped down.
- Do not allow consumers to keep food unstable or place bottles in the Freezer Room.
- Do not allow consumers to repair the fridge for themselves.
- Do not allow consumers to keep things except for food.
 - Pharmaceutical, Chemical substances: These are not possible to be fine-Controlled with a consumer fridge.
 - ⇒ Flammable material (alcohol, benzene, ether, LPG, etc): possibility of explosion.

PRECAUTIONS(SAFETY WARNINGS)

Read all instructions before repairing the product and keep to the instructions in order to prevent danger or property damage.

CAUTION/WARNING SYMBOLS DISPLAYED SYMBOLS



Warning

Indicates that a danger of death or serious injury exists.



Caution

Indicates that a risk of personal injury or material damage exists.



means Prohibition".



means Do not disassemble".



means No contact".



means The things to be followed".



means Power cord should be unplugged from the consent"



means Earth to prevent Electric shock".



Warning & Caution

Due to risk of electric shock, be sure to unplug the unit before servicing.

• It may cause electric shock.




Unplug



Use the rated components on the replacement.

• Check the correct model, rated voltage, rated current, operating temperature and so on.



On repair, make sure that the wires such as harness are bundled tightly.

• Bundle tightly wires in order not to be detached

• Bundle tightly wires in order not to be detached by the external force and then not to be wetted.



On repair, remove completely dust or other things of housing parts, harness parts, and check parts.

• Cleaning may prevent the possible fire by tracking or short.



After repair, check the assembled state of components.

• It must be in the same assembled state when compared with the state before disassembly.




Check if there is any trace indicating the permeation of water.

• If there is that kind of trace, change the related components or do the necessary treatment



such as taping using the insulating tape.



* Please ler users know following warnings & cautions in detail.



Warning & Caution

Do not allow users to put bottles or kinds of glass in the freezer.

• Freezing of the contents may inflict a wound.



Prohibition



Do not allow users to store narrow and lengthy bottles or foods in a small multipurpose room.

 It may hurt you when refrigerator door is opened and closed resulting in falling stuff down.



Prohibition @



Do not allow users to store pharmaceutical products, scientific materials, etc., in the refrigerator.

• The products which temperature control should not be stored in the refrigerator.




Do not allow users to insert the power plugs for many products at the same time.

• May cause abnormal generation of heat or fire.



Prohibition



Do not allow users to disassemble, repair or alter.

 It may cause fire or abnormal operation which leads to injury.



Do not allow users to bend the power cord with excessive force or do not have the power cord pressed by heavy article.

• May cause fire.



Do not allow users to store articles on the product.


• Opening or closing the door may cause things to fall down, with may inflict a wound.



Do not allow users to install the refrigerator in the wet place or the place which water splashes.

• Deterioration of insulation of electric parts may cause electric shock or fire.






The Appliance must be properly grounded.

• If earthing is not done, it will cause breakdown and electric shock.





2-1) Introduction of Main Function

• The SAMSUNG bottom mount freezer in 2009 has the following characteristics.



Surround Multi Flow

 Uniform cooling for each shelf by a center positioned fan and duct with multiple flow effluences.



Twin Cooling System

• The refrigerator and the freezer have two evaporators. Given this independent system, the freezer and the refrigerator are cooled individually as required and are, therefore, more efficient. Food odor from the refrigerator does not affect food in the freezer due to separate air flow circulation.



Easy Handle System(RF197AC,RF217AC)

 The freezer door is more user-friendly and convenient.



Moving Tray

• The Deli Drawer can be moved side to side for customer improved customer satisfaction.



Digital Display & Temperature Control

 Digital Display & Temperature Control look and feel neat & clear design.

2-2) Specifications


ELECTRICAL SPECIFICATIONS

Defrost Control From 12 to 64 hrs 140°F(60?)(off) 104°F(40?)(on) Thermo Bimetal Protector R: 62.6°F(12?) F: 57.2°F(14?) AC115V 60Hz 11.6 Amps Electrical Rating Maximum Current Leakage 0.5 mA Maximum Ground Path Resistance 0.1 Ohm Energy Consumption 453kWh/year(RF21) 445kWh/year(RF19)

NO LOAD PERFORMANCE

Ambient Temperature70°F(21°C) 90°F(32°C)
Refrigerator, $34^{\circ}F(1^{\circ}C) \sim 46^{\circ}F(8^{\circ}C) \cdots 34^{\circ}F(1^{\circ}C) \sim 46^{\circ}F(8^{\circ}C)$
Freezer,
Run Time,%<40<65


Refrigerator




REFRIGERATION SYSTEM

Refrigerant Charge	(R134a)5.64 oz(160g)
Compressor(MK162D-L1U) ************************************	730 Btu/hr(0.124kw)
Compressor(MKV172C-L2J)	730 Btu/hr(0.124kw)

Freezer



Dryer C-Fan



Compressor

condenser Water Valve


INSTALLATION

Clearance must be provided for air circulation

AT TOP	2?	(50m m)
AT SIDES	1?	(25m m)
AT REAR ::::::::::::::::::::::::::::::::::	2?	(50m m)

ASSY PBA

2-3) Interior Views



2-4) Model Specification

ITEM		ITEM		ITEM SPEC SAMSUNG			SUNG
		SPEC	RF20/18	RF197/217			
Appearance							
			Cooling Tech	Twin Cooling			
Product Zone		Door Shape	Contour				
			Special Room	Moving Tray			
	Cooling	F-Room	220 Ê	177.3			
	Speed(Min)	R-Room	220 Ê	179.1			
217)	89.6 (32°C)	F-Room	-26.0Ê	-29	9.9		
(RF2	09.0 (32 0)	R-Room	2.0 Ê	-1	.6		
luce	109.4 (43°C)	F-Room	-18.0Ê	- 2°	1.3		
orma	109.4 (43 C)	R-Room	5.0 Ê	-4	.3		
Perf	R-Room F-Room R-Room R		2.0 Ê	0.6			
	Distribution (Fridge) R-Room		2.0 Ê	0.8			
	Run Time	N-N	65 %Ê	51.6			
se	φ Sound power level		46dBÊ	41.8			
Sound power level Sound Pressure level		45dBÊ	39.7				

2-5) Model Specification & Specification Chart

Free St	anding	Model	Swing/Auto Ice Maker	Swing/A	uto Ice Maker	Drawer/Auto Ice	Maker	Drawer/Auto Ice Maker
		Ownig/rate foe maker	Ownig//	3 D		IVICITOI	Brawon late lee maker	
Model Number/ BOM code			RF18		RF20	RF197		RF217
Dimension	า (WxDxl	H)Inch	32 1/8 x 30 4/8 x 70 6/8	32 1/8 x	32 4/8 x 70 6/8	32 1/4 x 30 1/2 x	69 3/4	32 1/4 x 32 1/2 x 69 3/4
Dimension	n (WxDxl	H) I mm	817*775*1798	817	*825*1798	817*774*177	72	817*824*1772
Capacity	To	otal	17.5 / 496	1:	9.4 / 550	17.8 / 504		19.7 / 557.8
(net)	Refriç	gerator	11.8 / 334	1:	2.8 / 363	12.1 / 342.6	6	13.3 / 376.6
(cu.ft/l)	Fre	ezer	5.7 / 162	6	6.6 / 187	5.7 / 161.4		6.4 / 181.2
	W	idth	32 1/8 (817)	32	1/8 (817)	32 1/4 (817	')	32 1/4 (817)
	Height	w/o Hinge	70 6/8 (1798)	70 (6/8 (1798)	68 5/8 (1743	3)	68 5/8 (1743)
Dimension (Net:	Tioigitt	With Hinge	70 6/8 (1798)	70 (6/8 (1798)	69 3/4 (1772	2)	69 3/4 (1772)
Inch(mm))		with Handle	30 4/8 (775)	32	4/8 (825)	30 1/2 (774	!)	32 4/8 (824)
	Depth	w/o Handle	28 1/8 (715)	30	1/8 (765)	28 1/2 (715	5)	30 1/8 (765)
		w/o Door	24 2/8 (617)	26	2/8 (667)	24 3/8 (617	')	26 2/8 (667)
Dimension	Width		34 5/8 (880)	34	5/8 (880)	34 5/8 (879	9)	34 5/8 (880)
(packing:	Height		75 (1906)	7	5 (1906)	75 (1906)		75 (1906)
Inch/mm)	Depth		30 4/8 (776)	32	4/8 (826)	30 4/8 (776	5)	32 4/8 (826)
Weight	Net		231 / 105	2	43 / 110	231 / 105		243 / 110
(lb/kg)	Packing		254 / 115	2	67 / 121	254 / 115		267 / 121
Co	ompresso	r			Recip	rocate		
Rated Frequ	ency and	Frequency			AC 115	V/60Hz		
R	efrigerant	t		R 134a				
Foa	ming Age	ent			C-Pe	ntane		
Refrigerant Input Amount 5.64				5.64 oz	: (160g)			
Type	Refrigera	ator		Indire	ect Cooling M	ethod Refriger	ator	
Motor Rated Consumption Power 130W				DW WC				
Electric Heater Rated Consumption Power					350	WC		
COLOR								
			Cabinet (Both S	ide)	D	oor		Molding

COLOR						
	Cabinet (Both Side) Door					
Black	All Black	Empire Black	l Black			
Real STS	Noble STS	Real Stainless	INOX GRAY			
White	Snow White	Snow White	Snow White			
Platinum Inox	Noble STS	Platinum Inox	INOX GRAY			

Items			s	Specif	ication	
Model			el	RF19*,RF21*	RF18*/RF20*	
			Model	MK162DL1U-E09	MKV172CL2J-SJ1	
er		Compressor Starting type		AC	INV	
eez	eeze		Oil Charge	FREO	L α -10	
or Fr		Evaporator	Freezer	SPLIT F	IN TYPE	
ıts fo		Evaporator	Refrigerator	SPLIT F	IN TYPE	
Components for Freezer		Cond	enser	Forced and Natura	al Convection Type	
Jup		Dr	yer	Molecular s	hieve XH-9	
ပြ		Capillary tube	(Dia x Length)	0.032" x 157" (0.8	2mm x 4000mm)	
		Refriç	gerant	R1:	34a	
ents		Model	Temperature Selection	ON(°F)	OFF(℉)	
Room Temperature Sensor Components	Freezer	THERMISTOR	-8°F (-22°C)	0°F (-18°C)	-15℉(-26℃)	
r Col	Free	(F-SENSOR)	-2°F(-19°C)	5°F(-15°C)	9 ℉(-23℃)	
Sensc		502AT	8℉(-13℃)	16℉(-9℃)	1°F(-17°C)	
ture (Model		Temperature Selection	ON(℉)	OFF(°F)	
npera	Refrigerator	THERMISTOR	34°F (1°℃)	41 °F (5°C)	27 °F(- 3 °C)	
n Ter	əfrig	(R-SENSOR)	38 °F (3 °C)	45 °F(7 °C)	30°F (-1°C)	
Roof	Œ	502AT	46 °F(8 °ℂ)	54°F(12°C)	39℉ (4℃)	
	cle	First Defrost Cycle (Co	ncurrent defrost of F and R)	6hr \pm 10min		
	t Cycle	Defrost	Cycle(FRE)	12~34hr(varies according to the conditions used)		
ıts	Defrost	Defrost	Cycle(REF)	6~17hr(varies according to the conditions use		
Components	De	Pau	Pause time 12 ±1min		1min	
Jupo	ensor	F Defrost-Sensor	Model	THERMIST	OR (502AT)	
_	(N)	1 Deliost Gensor	SPEC	5 .0 K Ωat 7	'7 °F(25 °ℂ)	
Defrost Related	efrost	R Defrost-Sensor	Model	THERMISTOR (502AT)		
t Re	Def	Tt Bellost Gellsol	SPEC	5.0 K Ω at 7	'7 °F(25 °C)	
fros		F Bimetal-thermo	Rated	AC 12	5V 6A	
اصّا	etal	Protector	Operating temperature	Off : 140°F (60°C)	/ On : 104℉ (40℃)	
	Bimeta	R Bimetal-thermo	Rated	AC 12	5V 6A	
		Protector	Operating temperature	Off : 140°F(60°C)	/ On : 104 °F(40 °C)	

Items			Specification		
Model			RF19*,RF21*	RF20*/RF18*	
	Defrost Heater(FRE) Heated at F Defrost		AC 120V, 240W		
	Defrost Heater(REF) Heated at R Defrost		AC115V, 120W		
		Model	4TM412SFBYY-53	4TM445PHBYY-82	
	Over Load Relay	Temp.ON	275 ± 9°F(135±5°C)	2 5 7 ± 9°F(125±5°C)	
		Temp.OFF	141.8 ± 9°F(61±5°C)	1 5 6 ± 16°F(69±9°C)	
Components	Rated Voltage		AC 115V/ 60Hz		
bou	Motor-BLDC(FRE)		DC12V / DREP5020LC		
Jom	Motor-BL	DC(REF)	DC12V / DREP5020LC		
	Motor-BLD0	C(CIRCUIT)	DC12V / DRCP5030LA		
Electric	Lamp	(FRE)	DC 12V / 100mA~130mA(1EA)		
	Lamp	(REF)	DC 12V / 255mA~320mA(1EA)		
	Door Switch	FRE	DC200V 0.5A / MS	S-406-SS-01(1EA)	
	Door Switch	REF	DC200V 0.5A / MS	S-406-SS-01(2EA)	
Power Cord		AC125V 15A			
Ground Screw			BSBN (BRA	SS SCREW)	