Model:____FWS___(MY 2019)_____ FloorPlan:_____VIENNA_____

12 Volt Fused Component	Fuse Location	Fuse Size	Fuse Type (Blade,Tube,AutoReset)
Running lights	Under driver seat	7.5 amp	Blade
Trailer plug	Under driver seat	20 amp	Blade
Entry step	Under bed base	30 amp	(mini) auto reset
4 point leveling	Battery compartment	50 amp	Auto reset
Level control pad	Behind entry step	20 amp	Blade
Coach power	Battery compartment	50 amp	Auto reset
Power disconnect	Within disconnect under bed base	5 amp	Blade
Chassis radio	Inverter compartment	15 amp	Blade
Ent. Center radio	Under bed base	10 amp	Blade
Ent. Center radio	Within radio (back side)	10 amp	Blade
Camera switcher	Under driver seat	3 amp	Blade
Inverter	Inverter compartment	120 amp	Auto reset
Inverter wake up	Under bed base	2 amp	Blade
Battery isolator	Inverter compartment	80 amp	Auto reset
All other coach fuse's are located beside control panel in 12 volt power center.			