

Fig. 43

3) Where you just removed the wire in step 2, connect the ES White wire

1) Easy Start Orange wire goes with the white herm wire

4) Make a 3-way splice with the compressor (C) common

