

Code Lists / Liste des codes /
Lista de Códigos

Audio

Amplifier / Amplificateur / Amplificador		
Durabrand	1561	
Harman/Kardon	0892	
JVC	0331	
Left Coast	0892	
Lenoxx	1561	
Marantz	0892	
Optimus	1189	
Philips	0892	
Pioneer	1390	
Polk Audio	0892	
RCA	0823	
Sony	0815	
Victor	0331	
Yamaha	0354	

Receiver / Récepteur / Receptor		
Accurian	2098	
Aiwa	1405, 0189, 0121, 1243, 1641	
Akai	1512	
Alco	1390	
Anam	1609, 1074	
Apex Digital	1257, 1430, 1774	
Audiovox	1189	
B & K	0701, 0820, 0840	
Bose	1229, 0639, 1253, 1629, 1841, 1933	
Cambridge Soundworks	1370, 2297	
Carver	1189, 0189	
Daewoo	1250	
Denon	1360, 1142, 2279, 2857	
Fisher	1801	
Gateway	1517	
Go Video	1532	
Harman/Kardon	0189, 0891, 1304, 1306, 2241	
Hitachi	1801	
Insignia	1030, 1077, 1893, 2169, 2175	
Integra	0135, 1298, 1320, 1805	
JBL	1306	
JVC	1374, 1676, 1871, 2239, 2331	
Kenwood	1313, 1570, 1569, 0186	
KLH	1390, 1412, 1428	
Koss	1366	
LG	1293, 2197	
Linn	0189	
Magnavox	1189, 1269, 0189, 0391, 1514	
Marantz	1189, 1269, 0189, 1289	
Mitsubishi	1393	
Onkyo	0135, 0842, 1298, 1320, 1531, 1805	
Optimus	1023, 0186, 1074	
Oritron	1366	
Panasonic	1308, 0367, 1288, 1316, 1548, 1633, 1763, 1764, 2967	
Philips	1189, 1269, 0189, 0391, 1266, 1831, 2311	
Pioneer	1023, 0244, 0630, 1123, 1384, 1935	
Polaroid	1508	
Polk Audio	0189, 1289	
Proscan	1254	
RCA	1023, 1609, 1254, 1074, 1123, 1390, 1511, 2041	
Rio	1869	

Cable / Câble

Amino	1602, 1822	
Bright House	1376, 1877	
Cable One	1376, 1877	
Cablevision	1376, 1877	
Charter	1376, 1877, 2187	
Cisco	1877, 0877, 1982	
Comcast	1376, 1877, 1822, 2576	
Cox	1376, 1877	
Digeo	1187, 2187	
Director	0476	
General Instrument	0476	
Homecast	2301	
i3 Micro	1602	
Insight	1376, 1877	
Jerrold	0476	
Mediacom	1376, 1877	
Motorola	1376, 1877	
Myrio	1822	
Pace	1877	
Panasonic	1982	
Pioneer	1877	
Scientific Atlanta	1877, 0877	
Sejin	1602	
Suddenlink	1376, 1877	
Time Warner	1376, 1877, 2187	
Tivo	2576	

Cable-DVR Combos / Combinés Câble - DVR / Combos de Cable-DVR		
Amino	1822	
Bright House	1376, 1877	
Cable One	1376, 1877	
Cablevision	1376, 1877	
Charter	1376, 1877, 2187	
Cisco	1877, 0877, 1982	
Comcast	1376, 1877, 1822, 2576	
Cox	1376, 1877	
Digeo	1187, 2187	
Director	0476	
General Instrument	0476	
Homecast	2301	
i3 Micro	1602	
Insight	1376, 1877	
Jerrold	0476	
Mediacom	1376, 1877	
Motorola	1376, 1877	
Myrio	1822	
Pace	1877	
Panasonic	1982	
Pioneer	1877	
Scientific Atlanta	1877, 0877	
Sejin	1602	
Suddenlink	1376, 1877	
Time Warner	1376, 1877, 2187	
Tivo	2576	

Satellite / Satélite

Bell ExpressVu	0775, 1170	
Chaparral	0216	
Coolsat	1806	
Sanyo	0869	
Sharp	0186, 1286	
Sherwood	1077, 1517, 1653, 1905, 2169	
Sherwood Newcastle	2169	
Sonic Blue	1532, 1869	
Sony	1759, 1058, 1441, 1258, 1622, 1558, 1758, 1822, 1858, 2172	
Stereophonics	1023	
Sunfire	1313	
Teac	1074, 1390, 1528	
Technics	1308	
Thorens	1189	
Toshiba	1775, 1775	
Venturer	1788	
Philips	1250	
HTS	0775, 1775	
Vizio	1517	
Wards	0189	
Yamaha	0176, 0186, 0376, 1176, 1276, 1331, 1375, 1376, 1476, 1815, 2061	
Zenith	0857, 1293	

Audio Accessories / Accessoires de audio / Accesorios de audio		
Accurian	1106	
Altec Lansing	0607	
Apple	1115, 1644	
D-Link	1522	
DLO	1155	
GPX	2113	
Griffin	1891	
iDeck	1106	
iLive	2113	
Monitor Audio	1106	
NaviPod	1644	
Netgear	1785	
Roku	1828	
SSI	1522	
Yamaha	1809, 1810	

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satellite-DVR

Bell ExpressVu	0775, 1170	
DirectTV	1377, 0392, 0639, 1142, 1076, 1442, 1443	
Dishpro	0775, 1505, 1775	
Dish Network System	0775, 1505	
Dishpro	0775, 1505	
Expressvu	0775, 1775	
GE	0566	
Echostar	0869	
General Instrument	0775, 1775	
GOI	0775, 1775	
Toshiba	1788	
Venturer	1788	
Philips	1250	
HTS	0775, 1775	
Hughes Network Systems	1142, 0749, 1749, 1442, 1443	
Humax	1790	
JVC	0775, 1170, 1775	
LG	1414	
Mitsubishi	0749	
Motorola	0869	
Next Level	0869	
Panasonic	0247, 0701, 1189	
Pansat	1807	
Philips	1142, 0749, 1749, 1076, 1442	
Proscan	0392, 0566	
RadioShack	0869	
RCA	0566, 0143	
Samsung	1377, 1276, 1109, 1442, 1609, 1708	
Sony	0639, 1639	
Star Choice	0869	
Tivo	1142, 1442, 1443	

DVD / Lecteurs DVD

Accurian	0675, 1416	
Advent	1016	
Aiwa	0641	
Akai	0695, 0770, 0899, 1089	
Alco	0790	
Allegro	0869	
Amphion Media Works	0872, 1245	
AMW	0872, 1245	
Apex Digital	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480	
Arrgo	1023	
Aspire Digital	1168, 1407	
Charter	1489, 1678	
Audiovox	0790, 1121, 1122	
B & K	1423	
BBK	1224	
Cisco	1877, 1982	
Bel Canto Design	1571	
Blaupunkt	0717	
Cox	1376, 1877	
Digeo	1187, 2187	
Homecast	2301	
Insight	1376, 1877	
Mediacom	1376, 1877	
Motorola	1376, 1187	
Myrio	1822	
Pace	1877	
Panasonic	1982	
Pioneer	1877	
Scientific Atlanta	1877, 0877	
Suddenlink	1376, 1877	
Time Warner	1376, 1877, 2187	
Tivo	2576	

Daewoo	0784, 0705, 0833, 0869, 1169, 1172, 1234, 1242, 1441, 1443	
Denon	0490, 0634, 2258	
Desay	1407	
Diamond Vision	1316, 1609, 1610	
DigitalMax	1738	
Disney	0675, 1270	
Dual	1068, 1085	
Durabrand	1127, 2164	
DVD2000	0521	
Emerson	0591, 0675, 0821, 1268	
Enterprise	0591	
ESA	0821, 1268, 1443	
Presidian	0670, 1919	
Fisher	0675, 1268, 1334	
Funai	1963	
Gateway	1073, 1077, 1158	
GE	0522, 0815, 0717	
GFM	0675, 1268	
Go Video	0744, 0715, 0741, 0783, 0833, 0869, 1044, 1075, 1099, 1144, 1158, 1304, 1443, 1730	
GoldStar	0741	
GPX	0699, 0769	
Greenhill	0717	
Harman/Kardon	0582, 0702, 1229	
Helios	2192	
Hello Kitty	0831	
Hitachi	0573, 0664, 1247, 1919	
Sansui	0695	
Hiteker	0672	
Humax	2367	
iLo	1348, 1472	
Initial	0717, 1472	
Insignia	0675, 1268, 2095, 2428	
Integra	0627, 1769, 2147	
JBL	0702	
Shinsonic	0533, 0839	
Sigma Designs	0674	
JVC	0558, 0623, 0867, 1164, 1275, 1550, 1602, 1863	
jWin	1049	
Kawasaki	0790	
Kenwood	0490, 0534, 0682	
KLH	0717, 0790, 1149, 1261	
Konka	0711, 0719, 0720	
SVA	0860, 1105	
Sylvania	0675, 0821, 1268, 2194	
Symphonic	0675, 0821	
Teac	0790	
Technics	0490, 0703	
Terapin	1031	
Theta Digital	0571	
Magnavox	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506	
Malata	0782	
Marantz	0539, 2414	
McIntosh	1273	
Memorex	0695, 0831, 1270, 2213	
Microsoft	0522, 2083	
Citizen	0839, 0717, 1472	
Mitsubishi	1521, 0521	
NAD	0741	
Curtis Mathes	1087	
CyberHome	0816, 0874, 1023, 1024, 1117, 1129, 1502, 1537	
NEC	0785	
Nesa	0717	
NexxTech	1402	
Norcent	1003, 0872, 1107, 1265, 1457	
Olevia	2331	

Onkyo	0503, 0627, 1769, 2120, 2147	
Oppo	0575, 1224, 2185	
Apex Media Electronics	1056	
Oritron	0651	
Panasonic	0490, 0632, 0703, 1362, 1462, 1490, 1641, 1762	
Philco	0675	
Philips	0503, 0539, 2056, 0646, 0675, 0854, 1260, 1267, 1340, 1354, 2084, 2334, 2434	
Pioneer	0525, 0571, 0142, 0631, 0632, 1460, 1571, 2442	
Polaroid	1061, 1086, 1245, 1261, 1316, 1478, 1480, 1482, 2313	
Polk Audio	0539	
Portland	0770	
ESA	0675, 1738	
Prima	1016	
Primare	1467	
Princeton	0674	
Proscan	0522	
ProVision	0778	
Qwestar	0651	
Pioneer	0522, 0571, 0717, 0790, 0822, 1022, 1132, 1193, 1769	
RCA	0631, 1460	
Polaroid	1086	
Presidian	1360	
RCA	0522	
Samsung	0490	
Sanyo	0670	
Sensory Science	1158	
Sharp	1033, 1070, 1431, 1432, 1433	
Sony	0675	
Sylvania	1510, 1588, 2277	
Toshiba	0741	
Zenith	0741	

DVD-R		
Accurian	0675, 1416	
Advent	1803	
Akai	1933	
Apex Digital	1675, 1935, 2232	
Audiovox	1943, 1991	
Broksonic	1937, 1951, 1952	
Axon	1937	
Broksonic	1935	
Cinego	1986	
Citizen	1935	
Diamond Vision	1997	
Dynex	2049, 2184	
Gateway	0741, 1158, 1304, 1730	
Go Video	1864, 1394, 1963	
Humax	1963	
iLo	1348	
JVC	1164, 1275	
LG	0741	
LiteOn	1158, 1416, 1440, 1738	
Magnavox	0646, 0675, 1506	
Panasonic	0490	
Philips	0646, 1340	
LG	1423, 1993	
Magnavox	1866, 1963, 1990	
Mintek	1990	
Panasonic	1941	
Polaroid	1523, 1766, 1769, 1962, 1991, 2002	
Prima	1933	
Proscan	2256	
RCA	1948, 1958, 2002, 2187	
Samsung	1903	
Sansui	1935	
Sharp	0818	
Sova	1952	
Sylvania	1864, 1394, 1886, 1963	
Toshiba	1524, 1635, 1935	
TruTech	2066	

TV-VCR-DVD Combos / Combinés téléviseur -magnétoscope - lecteur DVD / Combos de TV-VCR-DVD	Controlled by TV / Contrôlé par TV / Controlado por TV		
	Akai		1903
	Broksonic		1938
	Diamond Vision		1996
	Emerson		1944
	ESA		1944
	Insignia		2088
	Magnavox		1944
	Panasonic	1946,	1947
	Polaroid		1992
	RCA		1953
	Sylvania		1944
	Symphonic		1944
	Toshiba		1945
	Controlled by DVD / Contrôlé par DVD / Controlado por DVD		
Akai		0899	
Broksonic		0868	
Diamond Vision		1609	
Emerson		0821	
ESA		0821	
Funai		1334	
Magnavox		0821	
Panasonic	1362,	1462	
Polaroid		1482	
RCA		1132	
Sharp		0630	
Superscan		0821	
Sylvania		0821	
Symphonic		0821	
Toshiba		1045	
	Controlled by VCR / Contrôlé par VCR / Controlado por VCR		
Sharp		0807	

DTV Converters / Récepteurs TV numériques / Convertidores Digitales

Access HD.....	2185
Airlink 101.....	2491
Alpha Digital.....	2185
AMTC.....	1563
Apex Digital.....	2478
Artec.....	2490
CASTI.....	2305
Channel Master.....	2365
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2488
Gridlink.....	2348
Insignia.....	1415
Lasonic.....	2348
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Philco.....	1563
RCA.....	2325, 2454
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2488

TV/VCR Combos / Combinés téléviseur -magnétoscope / Combos de TV-VCR

Controlled by TV / Contrôlé par TV / Controlado por TV.....	0180
America Action.....	0145
Audiovox.....	0180
Emerson.....	0236
Controlled by VCR / Contrôlé par VCR / Controlado por VCR.....	
Broksonic.....	0002, 1479
Citizen.....	1278
Colt.....	0072
Curtis Mathes.....	1035
Daewoo.....	1278
Emerson.....	0002, 0593, 1278, 1479
Funai.....	0000
GE.....	0240, 0807, 1035, 1060
GoldStar.....	1237
Harley Davidson.....	0000
Hitachi.....	0000
LG.....	1037
Lloyd's.....	0000
Magnasonic.....	0593, 1278
Magnavox.....	0000, 0593, 1781
Magnin.....	0240
Memorex.....	0162, 1037, 1162, 1237, 1262
MGA.....	0240
Mitsubishi.....	0807
Optimus.....	0162, 0593, 1162, 1262
Orion.....	0002, 1479
Panasonic.....	0162, 1035, 1162, 1262
Pennney.....	0240, 1035, 1237
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0240, 0807, 1035, 1060
Samsung.....	1014
Sansui.....	0000, 1479
Sansui.....	0000, 1479
Sanyo.....	0240
Sears.....	0000, 1237
Sony.....	1232, 0000
Sylvania.....	1781
Symphonic.....	0000, 0593
Thomas.....	0000
Toshiba.....	0845, 1145
Zenith.....	0000, 1479

DVRS

ABS.....	1972
Alienware.....	1972
Bell ExpressVu.....	1944
CyberPower.....	1972
Dell.....	1272
Alienware.....	0739, 0740
DirecTV.....	1944
Dish Network System.....	1944
Dishpro.....	1944
Echostar.....	1944
ExpressVu.....	1944
Gateway.....	1972
Go Video.....	0614
GOL.....	1944
Emerson.....	0002, 0593, 1278, 1479
Funai.....	0000
GE.....	0240, 0807, 1035, 1060
GoldStar.....	1237
Harley Davidson.....	0000
Hitachi.....	0000
LG.....	1037
Lloyd's.....	0000
Magnasonic.....	0593, 1278
Magnavox.....	0000, 0593, 1781
Magnin.....	0240
Memorex.....	0162, 1037, 1162, 1237, 1262
MGA.....	0240
Mitsubishi.....	0807
Optimus.....	0162, 0593, 1162, 1262
Orion.....	0002, 1479
Panasonic.....	0162, 1035, 1162, 1262
Pennney.....	0240, 1035, 1237
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0240, 0807, 1035, 1060
Samsung.....	1014
Sansui.....	0000, 1479
Sansui.....	0000, 1479
Sanyo.....	0240
Sears.....	0000, 1237
Sony.....	1232, 0000
Sylvania.....	1781
Symphonic.....	0000, 0593
Thomas.....	0000
Toshiba.....	0845, 1145
Zenith.....	0000, 1479

Gridlink.....	2348
Insignia.....	1415
Lasonic.....	2348
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Philco.....	1563
RCA.....	2325, 2454
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2488

Video Accessories / Accessoires de vidéo / Accesorios de vídeo

ABS.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Verizon.....	0145
Viewsonic.....	1996, 1997
Voodoo.....	1272
Vudu.....	2298
Winegard.....	1481, 2482
Zenith.....	1415
Zenith.....	1415
Zinwell.....	2488
ZT Group.....	1272
Accurian.....	1803
Action.....	0873
Admiral.....	0093, 0463
Advent.....	0761, 0783, 0815, 0817, 0842, 1933
Aiko.....	0092
Epson.....	1563
Evolution.....	2479
Gateway.....	1272
Mind.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348
Hewlett Packard.....	1272
Howard Computers.....	1272
AOC.....	0030, 1365, 1590, 2014
Aomni.....	1623
Apex Digital.....	0748, 0879, 0765, 0767, 0890, 1217, 1943, 1991
Astar.....	1272
HP.....	1272
ReplayTV.....	1272
iBUYPOWER.....	1272
Insignia.....	1415
KoolConnect.....	1481
Lasonic.....	2348
LG.....	1415
Linksys.....	1272
Bell & Howell.....	0154
Philco.....	1032, 1315
Magnavox.....	1563
Media Center PC.....	1272
Memorex.....	2486
MicroGEM.....	2489
Cadia.....	1283
Microsoft.....	1272
Mind.....	1272
Carnivale.....	0030
Carver.....	0054
Celebrity.....	0000
Celera.....	0765
Philco.....	0765
Changhong.....	1986
Cinego.....	0060, 0030, 0092, 0051
Prism.....	0051
Claron.....	0180
Coby.....	0054
Commercial Solutions.....	1447, 0047
Sony.....	1272
Stack 9.....	1272
Craig.....	0180
SureWest.....	1481
Sylvania.....	1563
Crosley.....	0054
Crown.....	0180
Systemax.....	0030
Curtis Mathes.....	0047, 0054, 0154, 0451, 0093, 0060, 0702, 0030,
Tagar Systems.....	0145, 0166, 0466, 1147, 1347
Tivax.....	2185
Toshiba.....	1272
CXC.....	0180
CyberHome.....	0794
Cytron.....	1326

Tvs / Téléviseurs

Ventura.....	2454
Venturer.....	2454
Denon.....	0145
Diamond Vision.....	1996, 1997
Digital Lifestyles.....	1765
Dumont.....	0017
Durabrand.....	0463, 0180, 0178, 0171, 1034
Dwin.....	0720
Dynex.....	1463, 2049, 2184
Electroband.....	0000
Electrograph.....	1755, 1623
Electrohome.....	0463
Element.....	1687
Emerson.....	1864, 0154, 0236, 0463, 0180, 0178, 0171, 0623, 1394,
Envision.....	1665, 1944, 1963
Emprex.....	1422, 1546, 1765
Envision.....	0030, 0813, 1365, 2014
Epson.....	0833, 0840, 1290
ESA.....	0812, 0171, 1944, 1963
Fisher.....	0154
FlexVision.....	0710
Fujitsu.....	0809, 0683, 0853, 2008
Funai.....	0180, 0171, 1271, 1963
Futuretech.....	0180
Gateway.....	1755, 1001, 1002, 1003, 1756
GE.....	1447, 0047, 0051, 0451, 0178, 1347
GE.....	0171, 1665, 1963, 2167
GFM.....	0017, 0030
Gibraltar.....	0886
Go Video.....	0178, 0030
GoldStar.....	0180
Grunpy.....	0180
Haier.....	1034, 1748, 1749
Hallmark.....	0178
Hannspree.....	1348, 1351, 1352
Harman/Kardon.....	0054
Harsper.....	1206
Harvard.....	0180
Haverm.....	0093
Helios.....	0865
Hello Kitty.....	0451
Hewlett Packard.....	1494, 1088, 1089, 1101, 1502
Hisense.....	0030
Hitachi.....	1643, 1145, 0145, 0797, 1960
HP.....	1494, 1088, 1089, 1101, 1502
Hyundai.....	0849, 1219, 1294
iLo.....	1286, 1603, 1665, 1684, 1990
Infinity.....	0054
Initial.....	1603, 1990
Princeton.....	0700
Prism.....	0178
Proscan.....	1447, 0047, 1347, 2147, 2256
Proton.....	0178, 0466
Protron.....	1320, 1323
Proview.....	0835, 1498, 1687
Pulsar.....	0017
Puneet.....	1546
Quasar.....	0250, 0051, 0650
Westinghouse.....	0047, 0154, 0180, 0178, 0030
White Westinghouse.....	0463, 0623
Wyse.....	1365
Yamaha.....	0030, 0769, 0797, 0833, 0839
Zenith.....	0017, 0463, 0178, 0092

Daewoo.....	0451, 0092, 1661, 0623, 0661, 0672
Dell.....	1264, 1080, 1178, 1403, 1863
Denon.....	0145
Samsung.....	1454, 1866, 0054, 0030, 0706, 0802, 1198, 1254,
Diamond Vision.....	1365, 1525, 1944, 1963, 1990
Digital Lifestyles.....	1765
Dumont.....	0017
Durabrand.....	0463, 0180, 0178, 0171, 1034
Dwin.....	0720
Dynex.....	1463, 2049, 2184
Electroband.....	0000
Electrograph.....	1755, 1623
Electrohome.....	0463
Element.....	1687
Emerson.....	1864, 0154, 0236, 0463, 0180, 0178, 0171, 0623, 1394,
Envision.....	1665, 1944, 1963
Emprex.....	1422, 1546, 1765
Envision.....	0030, 0813, 1365, 2014
Epson.....	0833, 0840, 1290
ESA.....	0812, 0171, 1944, 1963
Fisher.....	0154
FlexVision.....	0710
Fujitsu.....	0809, 0683, 0853, 2008
Funai.....	0180, 0171, 1271, 1963
Futuretech.....	0180
Gateway.....	1755, 1001, 1002, 1003, 1756
GE.....	1447, 0047, 0051, 0451, 0178, 1347
GE.....	0171, 1665, 1963, 2167
GFM.....	0017, 0030
Gibraltar.....	0886
Go Video.....	0178, 0030
GoldStar.....	0180
Grunpy.....	0180
Haier.....	1034, 1748, 1749
Hallmark.....	0178
Hannspree.....	1348, 1351, 1352
Harman/Kardon.....	0054
Harsper.....	1206
Harvard.....	0180
Haverm.....	0093
Helios.....	0865
Hello Kitty.....	0451
Hewlett Packard.....	1494, 1088, 1089, 1101, 1502
Hisense.....	0030
Hitachi.....	1643, 1145, 0145, 0797, 1960
HP.....	1494, 1088, 1089, 1101, 1502
Hyundai.....	0849, 1219, 1294
iLo.....	1286, 1603, 1665, 1684, 1990
Infinity.....	0054
Initial.....	1603, 1990
Princeton.....	0700
Prism.....	0178
Proscan.....	1447, 0047, 1347, 2147, 2256
Proton.....	0178, 0466
Protron.....	1320, 1323
Proview.....	0835, 1498, 1687
Pulsar.....	0017
Puneet.....	1546
Quasar.....	0250, 0051, 0650
Westinghouse.....	0047, 0154, 0180, 0178, 0030
White Westinghouse.....	0463, 0623
Wyse.....	1365
Yamaha.....	0030, 0769, 0797, 0833, 0839
Zenith.....	0017, 0463, 0178, 0092

LXI.....	0047, 0054, 0154, 0156, 0178
MAG.....	1498, 1687
Magnavox.....	1454, 1866, 0054, 0030, 0706, 0802, 1198, 1254,
Marantz.....	1365, 1525, 1944, 1963, 1990
Matsushita.....	0054, 0030, 0704, 0854, 0855, 1154, 1398
Maxent.....	0250, 0650
Maxent.....	1755, 0762, 1211, 1757
Megapower.....	0700
Megatron.....	0178, 0145
Memorex.....	0154, 0463, 0150, 0178
MGA.....	0150, 0178, 0030
Midland.....	0047, 0017, 0051
Mintek.....	1603, 1990
Mitsubishi.....	1250, 0093, 0150, 0178, 0836, 0868, 1550
Monivision.....	0700, 0843
Motorola.....	0093, 0835
Moxell.....	0835
MTC.....	0060, 0030
Multitech.....	0180
NAD.....	0156, 0178, 0866, 1156
NEC.....	0030, 0497, 0882, 1398, 1704
NetTV.....	1755, 0762
Nexus Electronics.....	2183
Nikko.....	0178, 0030, 0092
Norcent.....	0748, 0824, 1089, 1365, 1589, 1590, 1591
Norwood Micro.....	1286, 1296, 1303
NTC.....	0093, 0864
NuVision.....	1657, 2158
Olevia.....	1610, 1144, 1240, 1331
Olympus.....	1610, 1144, 1240, 1331
Onwa.....	0180
Optimus.....	0250, 0154, 0166, 0650
Optoma.....	0887
Optonica.....	0093
Orion.....	0236, 0463, 1463
Panasonic.....	0250, 1480, 0051, 0650, 1291, 1941, 1946, 1947
PARK.....	2194, 2202
Penney.....	0047, 0156, 0051, 0060, 0178, 0030, 1347
Petters.....	1523
Philco.....	0054, 0030
Philips.....	1454, 0054, 0690, 1154, 1483, 1744, 1867
Pilot.....	0030
Pioneer.....	1457, 0166, 0679, 0866, 1260, 1398
Planar.....	0463
Polaroid.....	1523, 0765, 2121, 2120, 2119, 2002, 1992, 1991, 1962, 1769, 1767, 1766,
1687, 1498, 1341, 1328, 1327, 1326, 1316, 1314, 1286, 1276, 1262, 0865	
Portland.....	0092
Prima.....	0761, 0783, 0815, 0817, 1933
Princeton.....	0700
Vidtek.....	0178
Viewsonic.....	1755, 0797, 0857, 0864, 0885, 1330, 1342,
Proton.....	1578, 1627, 1742, 2014, 2087
Viore.....	1207, 1684
Visart.....	1336
Vizio.....	1758, 0864, 0885, 1499, 1756
Wards.....	0054, 0178, 0030, 0866, 1156
Waycon.....	0156
Westinghouse.....	1712, 0885, 0889, 0890, 1282, 1577
White Westinghouse.....	0463, 0623
Wyse.....	1365
Yamaha.....	0030, 0769, 0797, 0833, 0839
Zenith.....	0017, 0463, 0178, 0092

Runco.....	0017, 0030, 0497, 0603, 1398, 1629
Sampo.....	1755, 0030, 0762
Samsung.....	0812, 0060, 0702, 0178, 0030, 0766, 0814, 1060, 1575, 1903
Sansui.....	0463, 1409, 1935
Sanyo.....	0154, 0088, 0799, 0893, 1142
Sceptre.....	0878, 1217, 1360, 1599
Scotch.....	0178
Scott.....	0236, 0180, 0178, 1711
Sears.....	0047, 0054, 0154, 0156, 0178, 0171
Sharp.....	0818, 0093, 0491, 0688, 0689, 0851, 1602
Sheng Chia.....	0093
Sherwood.....	1399
Signet.....	1262
SIM2 Multimedia.....	1297
Sole.....	1483, 1623
Sony.....	0000, 0810, 0834, 1317, 1685
Soundesign.....	0180, 0178
Sova.....	1320, 1952
Soyo.....	1546, 1826
Spectroniq.....	1498, 1687
Squareview.....	0171
SSS.....	0180
Starlite.....	0180
Studio Experience.....	0843
Superscan.....	0093, 0864
Supreme.....	0000
SVA.....	0748, 0865, 0870, 0872
Sylvania.....	1864, 0054, 0030, 0171, 1271, 1314, 1394, 1665, 1886, 1944, 1963
Symphonic.....	0180, 0171, 1944
Syntax.....	1610, 1144, 1240, 1331
Tandy.....	0093
Tatung.....	1101, 1285, 1286, 1287, 1288, 1361, 1756
Technics.....	0250, 0051
Techview.....	0847
Teichwood.....	0051
Teknika.....	0054, 0180, 0150, 0060, 0092
Telefunken.....	0702
TMK.....	0178
TNCI.....	0017
Toshiba.....	1524, 0154, 0156, 1256, 0060, 1945, 1935, 1704, 1656, 1635, 1356, 1343, 1325, 1306, 1156, 0845, 0832, 0650
TruTech.....	1723, 2066
TVS.....	0463
Ultra.....	1323
US Logic.....	1286, 1303
Vector Research.....	0030
Victor.....	0053
Vidikron.....	0054, 1398, 1629
Vidtech.....	0178
Viewsonic.....	1755, 0797, 0857, 0864, 0885, 1330, 1342, 1578, 1627, 1742, 2014, 2087
Viore.....	1207, 1684
Visart.....	1336
Vizio.....	1758, 0864, 0885, 1499, 1756
Wards.....	0054, 0178, 0030, 0866, 1156
Waycon.....	0156
Westinghouse.....	1712, 0885, 0889, 0890, 1282, 1577
White Westinghouse.....	0463, 0623
Wyse.....	1365
Yamaha.....	0030, 0769, 0797, 0833, 0839
Zenith.....	0017, 0463, 0178, 0092