

Image printing distance, end of wire vs. shoulder of wire


REV 1 01/02/2013

CS327 software version 4.56 or higher.

In the Image marking screen there is a checkbox labeled Mark from Shoulder.

When the box is not checked the distance you enter is measured from the end of the wire.

In the example below the labels will be **printed 250 mm from the end of the wire.**



When the box is checked the distance you enter is measured from the strip shoulder.

In the example below, if the strip length for both the lead and the tail of the wire is 400mm (programmed on the main run screen) then label will be **printed 650mm from the end of the wire.**

