

Red lines at C20 and C21 denote schematic errors and are to be disregarded as far as the schematic is concerned. They should NOT be part of the unit. DOUBLE CHECK TO MAKE SURE.



