



9,6250



3,2500



WARNING

CROSSWALK IS DESIGNED FOR STATIONARY PUMP
OPERATION ONLY. CROSSWALK IS NOT DESIGNED
FOR TRANSPORTING PEOPLE. ALL PERSONNEL MUST
BE SEATED IN CAB WITH SEAT BELTS FASTENED
WHILE VEHICLE IS IN MOTION. RIDING ON CROSSWALK
MAY RESULT IN SERIOUS INJURY OR DEATH.