

## 3104669 EMERGENCY ASO INSTRUCTIONS HME 63249-200

### **AIR SHUT-OFF VALVE RESET PROCEDURE**

**With the key switch in the ON position and the engine stopped, hold ASO test button for 5 seconds; this will open the valve. ASO lamp will turn off, indicating that reset was successful.**

CONSULT VEHICLE MANUAL FOR ADDITIONAL INFORMATION ABOUT ENGINE AIR SHUT-OFF SYSTEM