



Innovative Controls Inc. Safety Message Bezels

PUMP DATA

LOGO	Fire Truck Manufacturer		PUMP	
	Address Here Address Here 90028		MAKE	
		GPM	PRESSURE	ENGINE RPM
CAPACITY			150 PSI	
MODEL NO.			200 PSI	
SERIAL NO.			250 PSI	
PRODUCTION NO.		GOVERNOR SPEED		
		GEAR RATIO		

IC Assembly P/N 3000576-0001
 IC Label P/N 3000578-0001
 IC Bezel P/N 3000577
 Assembly, Size A Message Bezel w/ Pump Data Label





IC Assembly P/N 3000576-0002

IC Label P/N 3000578-0002

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Keep Legs Inside Kick Gaurd Label



A warning label assembly consisting of a silver-colored bezel with a central opening. Inside the bezel is a black rectangular label with a yellow header bar. The header bar contains a black exclamation mark inside a triangle followed by the word "WARNING" in large, bold, black capital letters. Below the header bar, the main body of the label is black with white text.

! WARNING

Death or serious injury might occur if proper operating procedures are not followed. The pump operator as well as individuals connecting supply or discharge hoses to the apparatus must be familiar with water hydraulics hazards and component limitations.

IC Assembly P/N 3000576-0005

IC Label P/N 3000576-0005

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Hose Connection Warning Label





IC Assembly P/N 3000576-0006

IC Label P/N 3000576-0006

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Rotating Shafts Warning Label





IC Assembly P/N 3000576-0007

IC Label P/N 3000578-0007

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Spare Tire Instructions Warning Label





IC Assembly P/N 3000576-0008

IC Label P/N 3000578-0008

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Seated and Belted Warning Label





WARNING

Failure to obey the following can result in serious injury or death.

- 1. Inspect vehicle and aerial device, including operation, daily and prior to use.**
- 2. For stationary operation, vehicle must be securely parked and stabilized before all preparation and aerial device operation.**
- 3. Outriggers must be on solid footing to prevent tip-over.**
- 4. Operator must wear proper protective gear, including a body belt attached to ladder or platform with a lanyard. Platform doors must be securely latched.**
- 5. Operate all controls slowly for smooth motion.**
- 6. Do not load beyond rated capacity.**

IC Assembly P/N 3000576-0025

IC Label P/N 3000578-0025

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Aerial Inspection and Operation Warning Label





IC Assembly P/N 3000576-0050

IC Label P/N 3000578-0050

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Do Not Ride Tailboard Warning Label





IC Assembly P/N 3000576-0052

IC Label P/N 3000578-0052

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Do Not Ride on Tailboard Label





IC Assembly P/N 3000576-0051

IC Label P/N 3000578-0051

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Do Not Ride Tailboard Warning Label



⚠ WARNING

**This vehicle has
a maximum
seating capacity
of**

■ personnel

**Personnel must
be seated with
seatbelt
fastened while
apparatus is in
motion.**

IC Assembly P/N 3000576-0053

IC Label P/N 3000578-0053

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Seating Capacity Warning Label



⚠ WARNING

**This vehicle has
a maximum
seating capacity
of**

■ personnel

**Personnel must
be seated with
sealtbelt
fastened while
apparatus is in
motion.**

IC Assembly P/N 3000576-0054

IC Label P/N 3000578-0054

IC Bezel P/N 3000577

Assembly, Size A Message Bezel w/ Seating Capacity Warning Label



SAFETY INSTRUCTIONS

Before raising cab:

1. **Read operator manual.**
2. **Provide sufficient cab clearance.**
3. **Secure or remove any loose items.**
4. **Make sure nothing is on the front bumper.**
5. **Make sure cab doors are shut and latched.**
6. **Make sure cab tilts fully and the safety bar engages.**

Before lowering cab:

1. **Make sure all service items are removed from engine area.**
2. **Raise cab to maximum height to release safety latch.**
3. **Make sure all personnel are clear of cab area.**
4. **Pull safety latch handle and hold out to lower cab.**


IC Assembly P/N 3000573-0001

IC Label P/N 3000575-0001

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Cab Safety Precautions Label





IC Assembly P/N 3000573-0002

IC Label P/N 3000575-0002

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Tire Chains Instruction Label





IC Assembly P/N 3000573-0003

IC Label P/N 3000575-0003

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Alignment Light Label






IC Assembly P/N 3000573-0004

IC Label P/N 3000575-0004

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Not A Step Warning Label






IC Assembly P/N 3000573-0005

IC Label P/N 3000575-0005

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Hose Connection Warning Label





IC Assembly P/N 3000573-0006

IC Label P/N 3000575-0006

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Pump Inlet Valve Warning Label






IC Assembly P/N 3000573-0007

IC Label P/N 3000575-0007

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Not For Transportation Danger Label






IC Assembly P/N 3000573-0010

IC Label P/N 3000575-0010

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Vehicle Contact Electrocution Danger Label






IC Assembly P/N 3000573-0025

IC Label P/N 3000575-0025

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Vehicle Contact Electrocution Danger Label






IC Assembly P/N 3000573-0026

IC Label P/N 3000575-0026

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Not Insulated Electrocution Danger Label





IC Assembly P/N 3000573-0027

IC Label P/N 3000575-0027

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Pump Operator Electrocution Danger Label






IC Assembly P/N 3000573-0028

IC Label P/N 3000575-0028

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Aerial Stabilizer Motion Warning Label






IC Assembly P/N 3000573-0029

IC Label P/N 3000575-0029

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Open and Close Valves Warning Label





IC Assembly P/N 3000573-0030

IC Label P/N 3000575-0030

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Vehicle Specifications Warning Label






IC Assembly P/N 3000573-0031

IC Label P/N 3000575-0031

IC Bezel P/N 3000574

Assembly, Size B Message Bezel w/ Vehicle Specifications Warning Label






IC Assembly P/N 3000573-0050

IC Label P/N 3000575-0050

IC Bezel P/N 3000574


Assembly, Size B Message Bezel with Read Manual Warning





IC Assembly P/N 3000582-0001
IC Label P/N 3000584-0001
IC Bezel P/N 3000583
Assembly, Size C Message Bezel w/ Cab Tilt Label






IC Assembly P/N 3000582-0002

IC Label P/N 3000584-0002

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ ABS Code Switch Label





IC Assembly P/N 3000582-0003

IC Label P/N 3000584-0003

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Computer Code Switch Label






IC Assembly P/N 3000582-0004

IC Label P/N 3000584-0004

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Cab Tilt Latch Label






IC Assembly P/N 3000582-0005

IC Label P/N 3000584-0005

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Engage PTO Instruction Label





IC Assembly P/N 3000582-0006

IC Label P/N 3000584-0006

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Engage Generator Instruction Label





IC Assembly P/N 3000582-0007

IC Label P/N 3000584-0007

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Direct Fill 50psi Warning Label





IC Assembly P/N 3000582-0008

IC Label P/N 3000584-0008

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Intake Pressure Relief Warning Label





IC Assembly P/N 3000582-0009

IC Label P/N 3000584-0009

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Open Valve Warning Label





IC Assembly P/N 3000582-0010

IC Label P/N 3000584-0010

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Relief Valve Discharge Warning Label





IC Assembly P/N 3000582-0011

IC Label P/N 3000584-0011

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Remove Caps Warning Label





IC Assembly P/N 3000582-0012

IC Label P/N 3000584-0012

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Do Not Move Apparatus Warning Label





IC Assembly P/N 3000582-0013

IC Label P/N 3000584-0013

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Open Handles Warning Label





IC Assembly P/N 3000582-0015

IC Label P/N 3000584-0015

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Store Folding Step Caution Label






IC Assembly P/N 3000582-0016

IC Label P/N 3000584-0016

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Direct Fill 100psi Warning Label





IC Assembly P/N 3000582-0017

IC Label P/N 3000584-0017

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Auto-Pump Compressor Drain Label





IC Assembly P/N 3000582-0018

IC Label P/N 3000584-0018

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Ladder Rack Up/Down Label





IC Assembly P/N 3000582-0020

IC Label P/N 3000584-0020

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Do Not Pull Warning Label





IC Assembly P/N 3000582-0021

IC Label P/N 3000584-0021

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Water Tank Refill Warning Label





IC Assembly P/N 3000582-0022

IC Label P/N 3000584-0022

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Tank Rack Up/Down Label





IC Assembly P/N 3000582-0025

IC Label P/N 3000584-0025

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Diesel Fuel Only Label





IC Assembly P/N 3000582-0026

IC Label P/N 3000584-0026

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Do Not Move Apparatus Warning Label





IC Assembly P/N 3000582-0027

IC Label P/N 3000584-0027

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Not a Step Warning Label





IC Assembly P/N 3000582-0028

IC Label P/N 3000584-0028

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Store Folding Step Caution Label





IC Assembly P/N 3000582-0051

IC Label P/N 3000584-0051

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Light Tower Bulb Info Label





IC Assembly P/N 3000582-0052

IC Label P/N 3000584-0052

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Overall Tower Height Warning Label





IC Assembly P/N 3000582-0053

IC Label P/N 3000584-0053

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Not A Step Warning Label






IC Assembly P/N 3000582-0054

IC Label P/N 3000584-0054

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Primer Engaged Label





IC Assembly P/N 3000582-0055

IC Label P/N 3000584-0055

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Tie Off Capacity 500 Caution Label






IC Assembly P/N 3000582-0056

IC Label P/N 3000584-0056

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Tie Off Capacity 1000 Caution Label





IC Assembly P/N 3000582-0057

IC Label P/N 3000584-0057

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Shore Power Inlet Data Label





IC Assembly P/N 3000582-0058

IC Label P/N 3000584-0058

IC Bezel P/N 3000583

Assembly, Size C Message Bezel w/ Ladder Rack Up/Down Label





IC Assembly P/N 3000587-0001

IC Label P/N 3000588-0001

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Seated and Belted Warning Label





IC Assembly P/N 3000587-0002

IC Label P/N 3000588-0002

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Stand Clear Crushing Injury Warning Label





IC Assembly P/N 3000587-0003

IC Label P/N 3000588-0003

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Stand Clear of Outrigger Warning Label





IC Assembly P/N 3000587-0004

IC Label P/N 3000588-0004

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Lowering Cab Warning Label





IC Assembly P/N 3000587-0005

IC Label P/N 3000588-0005

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Safety Chain Fastened Warning Label





IC Assembly P/N 3000587-0006

IC Label P/N 3000588-0006

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Fan Warning Label





IC Assembly P/N 3000587-0007

IC Label P/N 3000588-0007

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Close Crosslay Cover Warning Label






IC Assembly P/N 3000587-0008

IC Label P/N 3000588-0008

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Explosion Warning Label





IC Assembly P/N 3000587-0009

IC Label P/N 3000588-0009

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Pressurized Inlets Warning Label





IC Assembly P/N 3000587-0010

IC Label P/N 3000588-0010

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Enclosed Seats Warning Label





IC Assembly P/N 3000587-0011

IC Label P/N 3000588-0011

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Turntable Area Warning Label





IC Assembly P/N 3000587-0012

IC Label P/N 3000X588-0012

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Traction Warning Label





IC Assembly P/N 3000587-0013

IC Label P/N 3000588-0013

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Do Not Walk Warning Label





IC Assembly P/N 3000587-0014

IC Label P/N 3000588-0014

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Exiting Bucket Warning Label





IC Assembly P/N 3000587-0016

IC Label P/N 3000588-0016

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Vehicle Capacity and Height Warning Label






IC Assembly P/N 3000587-0017

IC Label P/N 3000588-0017

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Aerial Modification Warning Label






IC Assembly P/N 3000587-0018

IC Label P/N 3000588-0018

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Fire Caution Label





IC Assembly P/N 3000587-0019

IC Label P/N 3000588-0019

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Fumes Caution Label





IC Assembly P/N 3000587-0020

IC Label P/N 3000588-0020

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Flow Water Caution Label





IC Assembly P/N 3000587-0021

IC Label P/N 3000588-0021

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Pinch Point Caution Label






IC Assembly P/N 3000587-0022

IC Label P/N 3000588-0022

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Oil Caution Label





IC Assembly P/N 3000587-0024

IC Label P/N 3000588-0024

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Set Rear Jacks Caution Label





IC Assembly P/N 3000587-0025

IC Label P/N 3000588-0025

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Avoid Electrocution Danger Label





IC Assembly P/N 3000587-0026

IC Label P/N 3000588-0026

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Aerial Electrocution Danger Label





IC Assembly P/N 3000587-0027

IC Label P/N 3000588-0027

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Climb Boom Danger Label






IC Assembly P/N 3000587-0028

IC Label P/N 3000588-0028

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Open Valves Fall Hazard Danger Label





IC Assembly P/N 3000587-0031

IC Label P/N 3000588-0031

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Leveling Override Instruction Label





IC Assembly P/N 3000587-0034

IC Label P/N 3000588-0034

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Bumper Warning Label






IC Assembly P/N 3000587-0038

IC Label P/N 3000588-0038

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Ride On Deck Step Warning Label





IC Assembly P/N 3000587-0039

IC Label P/N 3000588-0039

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Operator Procedure Warning Label





IC Assembly P/N 3000587-0040

IC Label P/N 3000588-0040

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Vehicle Height Warning Label






IC Assembly P/N 3000587-0041

IC Label P/N 3000588-0041

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Maximum Occupancy Warning Label






IC Assembly P/N 3000587-0042

IC Label P/N 3000588-0042

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Power Rewind Reel Data Label






IC Assembly P/N 3000587-0043

IC Label P/N 3000588-0043

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Power Rewind For Air Data Label





IC Assembly P/N 3000587-0044

IC Label P/N 3000588-0044

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Power Source Specs. Label





IC Assembly P/N 3000587-0047

IC Label P/N 3000588-0047

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Flashing Shift Indicator Warning Label






IC Assembly P/N 3000587-0048

IC Label P/N 3000588-0048

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Maximum Weight 31000 Warning Label





IC Assembly P/N 3000587-0049

IC Label P/N 3000588-0049

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Drain Yoke Caution Label





IC Assembly P/N 3000587-0050

IC Label P/N 3000588-0050

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Seated and Belted Warning Label






IC Assembly P/N 3000587-0051

IC Label P/N 3000588-0051

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Riding Warning Label





IC Assembly P/N 3000587-0052

IC Label P/N 3000X588-0052

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Hose Connecting Warning Label





IC Assembly P/N 3000587-0054

IC Label P/N 3000X588-0054

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Pins and Floats Warning Label





IC Assembly P/N 3000587-0055

IC Label P/N 3000X588-0055

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Waterway Monitor Warning Label





IC Assembly P/N 3000587-0056

IC Label P/N 3000X588-0056

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Foam Tank A Fill Warning Label





IC Assembly P/N 3000587-0057

IC Label P/N 3000X588-0057

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Foam Tank B Fill Warning Label





IC Assembly P/N 3000587-0058

IC Label P/N 3000588-0058

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ No Smoking Caution Label






IC Assembly P/N 3000587-0059

IC Label P/N 3000X588-0059

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Bedding Ladder Caution Label





IC Assembly P/N 3000587-0060

IC Label P/N 3000X588-0060

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Water Tank Fill Procedure Label





IC Assembly P/N 3000587-0101

IC Label P/N 3000588-0101

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Waterway Valve Override Label






IC Assembly P/N 3000587-0102

IC Label P/N 3000588-0102

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Front Suction Elbow Warning Label





The total weight
of equipment
should not
exceed 5 lbs.

IC Assembly P/N 3000587-0104

IC Label P/N 3000588-0104

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Equipment Weight Limit Label






IC Assembly P/N 3000587-0105

IC Label P/N 3000588-0105

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Tank Fill Warning Label





IC Assembly P/N 3000587-0106

IC Label P/N 3000588-0106

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Horizontal Fumes Caution Label





IC Assembly P/N 3000587-0107

IC Label P/N 3000588-0107

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Not A Step Warning Label





IC Assembly P/N 3000587-0110

IC Label P/N 3000588-0110

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Pressure Governor RPM Caution Label





IC Assembly P/N 3000587-0115

IC Label P/N 3000588-0115

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Do Not Drill Back Wall Warning Label





IC Assembly P/N 3000587-0118

IC Label P/N 3000588-0118

IC Bezel P/N 3000586

Assembly, Size D Message Bezel w/ Riding Warning Label, Black Background



**Mechanical
Siren**

IC P/N 3001137-0001
Mechanical Siren Label



**Electronic
Siren**

IC P/N 3001137-0002
Electronic Siren Label



**Air
Horn**

IC P/N 3001137-0003
Air Horn Label



Siren

IC P/N 3001137-0004
Siren Label



Q 2 B

IC P/N 3001137-0005
Q 2 B Label





Innovative Controls Inc. 560 Braddock Avenue East Pittsburgh, PA 15112 412-824-2264 Fax: 412-824-2339