


8.63 X 6.00

Assembly 3005214
Panel 3005213
Label 3005212



Paint #
63249-112

DISCHARGE

OK TO PUMP
AND ROLL

COOLANT
OVER-TEMP
WHEN LIT

LOW OIL
PRESSURE
WHEN LIT

PUMP ENGINE
RUNNING
WHEN LIT

GLOW PLUGS
OPERATING
WHEN LIT

PRIME

IGNITION

START

we will be affixing this label here so I would like to match the font

UV-1 polycarbonate graphic overlay
on 3mm aluminum composite panel
with LED modules installed

on 3005214 - HME #

60443-39

Innovative Controls Inc.
Kubota Auxiliary Pump Control Assembly
for HME

