


MX150 Rear Panel Connections



INPUT Control allows the selection of various sources for listening and viewing in Zone A and Zone B

Indicates the Format of the Incoming Signal and which channels are active; L (Left Front), C (Center), R (Right Front), LS (Left Surround), LFE (Low Frequency Effects), RS (Right Surround), LBS (Left Back Surround), S (Pro Logic Surround) and RBS (Right Back Surround)

Information Display indicates Input Selection Status, Volume, Trim Adjustments, Surround Modes and various other functions

Indicates when the Zone A Input source selected is an Analog, Digital or HD Digital Audio Signal. Also indicates when Room Perfect is active

Indicates the Listen Output Format and which channels are active; L (Left Front), C (Center), R (Right Front), LS (Left Surround), SUB (Subwoofer), RS (Right Surround), LBS (Left Back Surround), BS (Back Surround) and RBS (Right Back Surround)

Adjusts the Listening Volume Level for both Zone A and Zone B


Selects the parameter for making audio and front panel display adjustments

Selects the desired audio operating mode for Zone A

Indicates when Zone B Front Panel Control is active

Indicates when the Late Night function is activated

Indicates when the MX150 is in Standby/On Mode



IR (Infra Red) Sensor accepts IR signals directly from the Remote Control

Activates the volume compression circuit, supported by selected Dolby Digital sound tracks

Allows up or down adjustment for various Setup and Trim functions

Used to select the highlighted Menu Option and to activate the User Menu

Activates control of Zone B for Input Selection and Volume Adjustment

Activates the On-Screen Display overlay sent to the TV/Monitor indicating the various MX150 information. Also indicates various MX150 information on the Front Panel Information Display

Press to go into Setup Mode for changing operational settings

Step backward to the previous Menu Option Page and out of the Trim Select Mode

Used to move Left or Right through Menu Options. Also used in the Trim Mode to select the various Functions

Switches On and Off Zones A or B, or resets all the MX150 microprocessors