

Parts List of Switch Circuit Assembly (AWS-048)

CAPACITORS

Symbol	Description			Part No.
C1	Ceramic	100p	50V	CKDSL 101K 50
C2	Ceramic	100p	50V	CKDSL 101K 50
C3	Ceramic	100p	50V	CKDSL 101K 50
C4	Ceramic	100p	50V	CKDSL 101K 50
C5	Mylar	0.033	50V	CQMA 333K 50
C6	Mylar	0.033	50V	CQMA 333K 50
C7	Mylar	0.033	50V	CQMA 333K 50
C8	Mylar	0.033	50V	CQMA 333K 50

RESISTORS

Symbol	Description			Part No.
R1	Carbon film	180k		RD¼PM 184J
R2	Carbon film	180k		RD¼PM 184J
R3	Carbon film	180k		RD¼PM 184J
R4	Carbon film	180k		RD¼PM 184J
R5	Carbon film	22k		RD¼PM 223J
R6	Carbon film	22k		RD¼PM 223J
R7	Carbon film	22k		RD¼PM 223J
R8	Carbon film	22k		RD¼PM 223J
R9	Metal oxide	150	2W	RS2P 151K
R10	Metal oxide	150	2W	RS2P 151K
R11	Metal oxide	150	2W	RS2P 151K
R12	Metal oxide	150	2W	RS2P 151K
R13	Metal oxide	75	1W	RS1P 750K
R14	Metal oxide	75	1W	RS1P 750K
R15	Metal oxide	75	1W	RS1P 750K
R16	Metal oxide	75	1W	RS1P 750K
R17	Carbon film	12k	½W	RD½PS 123J
R18	Carbon film	12k	½W	RD½PS 123J
R19	Carbon film	12k	½W	RD½PS 123J
R20	Carbon film	12k	½W	RD½PS 123J
R21	Carbon film	10		RD¼PM 100J
R22	Carbon film	10		RD¼PM 100J
R23	Carbon film	10		RD¼PM 100J
R24	Carbon film	10		RD¼PM 100J

SEMICONDUCTORS

Symbol	Description	Part No.
D1	Diode	SIB01-01
D2	Diode	SIB01-01
D3	Diode	SIB01-01
D4	Diode	SIB01-01
D5	Diode	SIB01-01
D6	Diode	SIB01-01
D7	Diode	SIB01-01
D8	Diode	SIB01-01
D9	Diode	1S188 FM-1
D10	Diode	1S188 FM-1
D11	Diode	1S188 FM-1
D12	Diode	1S188 FM-1

SWITCHES

Symbol	Description	Part No.
	Push switch (TAPE MONITOR, DOLBY NR ADP, LOUDNESS)	ASG-049
	Push switch (LEVEL INDICATOR SENSITIVITY)	ASG-047
	Push switch (SPEAKERS)	ASG-046

13.11 POWER AMPLIFIER ASSEMBLY (AWH-027)



