

SX-828


FW K UW
FVZW KCW


PIONEER

SX-828

NOTES :

- Neither switch (S₄) nor capacitors (C₃ & C₄) are provided for FTZ-approved unit.
- No switch (S₄) is provided for 120V unit, but capacitors (C₃ & C₄) are provided.









CURRENT (at +B 12V)

$I_{AM} = 43.5 \text{ mA}$
 $I_{FM} = 46.5 \text{ mA}$
 $I_{MAX} = 50.0 \text{ mA}$

VOLTAGE


FM: NO SIGNAL AT ANT
 () AM: NO SIGNAL AT ANT
 () AM: INPUT 74 dB
 { } FM STEREO: INPUT 60 dB

NOTE: C_{13} is replaced by C_{12} in 120 V model.




NOTES :

- Neither switch (S4) nor capacitors (C3 & C4) are provided for FTZ-approved unit.
- No switch (S4) is provided for 120V unit, but capacitors (C3 & C4) are provided.




AF UNIT

AWK-012




HEAD AMP UNIT

W21-002

 $Q_1 \sim Q_6$ 2SC1312 or 2SC1344


MAIN AMP UNIT

AWH-010





PROTECTOR UNIT

AWM-025



MOUNTING TEMPLATE



Remove the four feet on the bottom plate of the unit.

