




XANTREX AUTO GEN START WIRING



Set the mode of operation to standby.
Enter advanced setup by pressing <Enter>, Up Arrow and Down Arrow simultaneously.
Set the generator type to '10'
Set Temp1 trigger to 'Enable'
Set Temp2 trigger to 'Enable'
Exit advanced setup by pressing <Enter>, Up Arrow and Down Arrow simultaneously.



This drawing and its contents are the property of Renegade / Kibbi LLC and are not to be copied or reprinted without written consent

LET	REVISION DESCRIPTION	BY	DATE



DRAWN BY:	MODEL:	DRAWING DESCRIPTION:	CUSTOMER:
mike	####	Valencia Primary Power	####
DRAWN DATE:	DRAWING SCALE:	SERIES:	FILE LOC & FILE NUMBER:
2/2/17	#	####	