Model-Veracruz Floor plan = FWS & MDS (MY 2019)			
12 Volt Fused Component	Fuse Location	Fuse Size	Fuse Type (Blade, Tube, AutoReset)
Coach	Tied into Chassis Running lights.		
Trailer Plug	Under hood on the passenger's side.	Multiple Fuses	Blade
Entry Steps	In battery compartment in the coach shutoff.	20 AMP	Blade
Cord Reel	In battery compartment in the coach shutoff.	20 AMP	Blade
Hose Reel	In battery compartment in the coach shutoff.	20 AMP	Blade
Tank Heater	Behind 12V fuse panel.	15AMP	Auto Reset
Ignition Interlock	Under dash on the passanger side.	5 AMP	Blade
4pt. Leveling System	In the battery compartment .	150 AMP	Auto Reset
Inverter Power	In the battery compartment .	300 AMP	Class T
Inverter Wake-Up	Behind 12V fuse panel.	5 AMP	Auto Reset
Inverter Reset	On the right hand side of the inverter.		Push Reset
Toilet	Behind 12V fuse panel.	40 AMP	Auto Reset
Slide Power	Behind 12V fuse panel.	20 AMP	Auto Reset
Brake Light	Under dash on the passanger side.	5 AMP	Blade
Brake and Turn Relays	Under bed/fuse in battery compartment	10 AMP	Auto Reset
Cab Radio	In the battery compartment (only if Kenwood Radio).	10 AMP	Auto Reset
All Other Fuses	In the 12V panel		Blade
Interior Lights	Multiplex panel		Auto Reset
Chassis Fuses	Located under hood and the dash on the passenger side.		Blade
12V Load Center Feed	Located in the battery compartment area.	100 AMP	MIDI
12V Mini Breaker Feed	Located in the battery compartment area.	100 AMP	MIDI
Slide controller	FWS floorplan > Inverter box , MDS floorplan > under bottom dresser drawer		