Model:___MBS__(MY 2019)_____ FloorPlan:_____Villagio_____

12 Volt Fused Component	Fuse Location	Fuse Size	Fuse Type (Blade,Tube,AutoReset)
Running lights	Under driver seat	7.5 amp	Blade
Trailer plug	Under driver seat	20 amp	Blade
Entry step	Under closet floor	30 amp	(mini) auto reset
Coach power	Battery compartment	50 amp	Auto reset
Power disconnect	Within disconnect under closet floor	5 amp	Blade
Chassis radio	Inverter compartment	15 amp	Blade
Stab jacks	Battery compartment	40 amp	(mini) auto reset
Converter	Within converter under closet floor	35 amp	Blade
Camera switcher	Under driver seat	3 amp	Blade
Battery isolator	Inverter compartment	80 amp	Auto reset
All other coach fuse's are located beside control panel in 12 volt power center.			