

#### HYDRONIC HEATING SYSTEM MAINTENANCE AND SERVICE RECORD

### For Technical Service and Parts:

# USA call 1-800-993-4402 CANADA call 1-800-755-1272

## **Recommended Service and Maintenance Schedule**

A	Rubber hoses – fuel, water and coolant	Annually	Inspect all hoses for cracks, leaks, weak points, and corrosion. Replace if necessary
В	Hose clamps	Annually	Inspect for hose wear under clamps and corrosion. Replace if necessary
С	Fuel filter	Annually	Replace
D	Nozzle/O-ring/Filter	Annually	Disassemble, clean, inspect for wear, replace filter and nozzle O-Ring
Ε	Ignitor	Annually	Inspect for wear. Replace after 2 years
F	Exhaust System	Annually	Inspect for leaks, corrosion, tighten joints as necessary
G	Coolant	Annually 36 Mths	Check level and PH Replace
Н	Electronic Control board	Annually	Ensure connections are tight and not corroded
١	Compressor, Fuel Pump, Combustion Fan	Annually	Inspect hoses for cracks and leaks. Replace if necessary. Inspect fan for corrosion and wear
J	Combustion chamber and exhaust	1000 hours	Vacuum clean

See Owners Manual for additional service and maintenance information

Service kits	CH50	NE-S	NE	Combi	Zephyr	_
OASIS Annual Service Kit	# 2150	# 2160	# 2163	# 2166	# 2170	
Inc. Ignitor, Garber fuel filter, Compressor air filter, Nozzle filter, Nozzle o-ring						
OASIS 3 year service kit	# 2151	# 2161	# 2164	# 2167	# 2171	
Inc. Ignitor, Garber fuel filter, Compressor air filter, Nozzle filter, Nozzle o-ring, Digital flame sensor						
OASIS 5 year service kit	# 2152	# 2162	# 2165	# 2168	# 2172	
Inc. Ignitor, Garber fuel filter, Compressor air filter, Nozzle filter, Nozzle o-ring, Nozzle, Digital flame sensor						

In-Service date

Serial no.

See label located on top of heater

Service Date / hours on meter	Services Performed	Technician / Service Centre		

Service Date / hours on meter	Services Performed	Technician / Service Centre

### Keep this card in the pouch attached to the heater

www.itrheat.com

ITR U.S.A. 5305 NE 121<sup>st</sup> Ave., Suite 401 Vancouver WA U.S.A. 98682 Tel: (360) 993-4877 Fax: (360) 993-1105 Toll Free: 1-800-993-4402 ITR CANADA 2431 Simpson Rd., Richmond, BC, Canada V6X 2R2 Tel: (604) 278-1272 Fax: (604) 278-1274 Toll Free: 1-800-755-1272



Call any number above for a replacement maintenance card or contact us at <u>www.itrheat.com</u>.

Registration of ITR products at www.itrheat.com is recommended.