



Service Bulletin

No.: MZ05-009 **Date:** January 9, 2007

Model: ER2500

Subject: If the video equipment connected to the ER2500 does not have a coupling capacitor the units will not sync properly.

Symptom: The following 6 parts have been changed on the MAIN PCB.


Solution: 1. C531 CHIP ELECT. CAPACITOR (100uF 16V) is changed to (33uF 16V).


- 2. C537 CHIP ELECT. CAPACITOR (100uF 16V) is changed to (33uF 16V).
- 3. CARBON FILM FIXED RESISTOR (75 OHM +-5% 1/6W) is added.
- 4. CARBON FILM FIXED RESISTOR (75 OHM +-5% 1/6W) is added.
- 5. R525 CHIP RESISTOR (75 OHM) is removed.
- 6. R530 CHIP RESISTOR (75 OHM) is removed.

Parts:


Ref #	FORMER		NEW	
	Description	Part Number	Description	Part Number
C531	100uF 16V	00MOA10701620	33uF 16V	00MOA33602520
C537	ELECT. CHIP		ELECT. CHIP	
	CAPACITOR		CAPACITOR	
NEW	NA	NA	75 OHM +-	00MGD05750160
			5% 1/6W	
			CARBON	
			FILM FIXED	
			RESISTOR	

CONFIDENTIALITY NOTICE:






Remove R530



CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.



Serial Number Range:

This problem applies to the following serial number.
The upgrade applies to MZ01xxxx000400 and earlier.
This improvement has been done in production from serial number MZ010504000401 and after.

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.