



ER2500

Service Bulletin

No.: MZ05-017 **Date:** January 9, 2007

Model:

Subject: The Remote Controller has been changed.

Symptom: The batteries run down in about two weeks. The standby current of the Remote Controller was too high at 1.3mA.

Solution: Replace the Remote Controller. (The Part number has not changed.) The improved remote can be identified by a blue label (dot) in the battery compartment. See the picture on the next page for details.

Parts:

Ref#	Description	Part Number
NA	REMOTE CONTROLLER	00MZK16BW0010
	RC2500ER	



As for improvement the remote controller, the blue label is stuck on the Battery compartment.

Serial Number Range:

This problem applies to the following serial number.

ER2500 applies to MZxx0517xxxxxx and earlier.

This improvement has been done in production from serial number MZxx0518xxxxxx and later.