

S.M.S.L

THX[®]
TECHNOLOGY



SH-9

使用说明书

本说明书的内容可能会随版本更改, 如有变动, 恕不另行通知 Ver: 1.1

安全注意事项

- 请将本音响系统安装在通风良好、阴凉、干燥、干净的位置，远离直射阳光热源、振动、灰尘、潮湿或寒冷。
- 只能使用本机指定的电压。使用高于指定数值的电压很危险，而且可能导致火灾，损坏本机或造成人身伤害。对于使用高于指定电压造成的任何损害，我司将不负任何责任。
- 不要试图自行改造或修理本机。如果需要任何服务，请与销售或者我司客服人员联系。不管有任何理由，都没有打开机壳的必要。
- 如果打算长时间不使用本机（比如度假时），请从墙壁交流电源插座上断开电源线的连接。

重要提示：

本说明书所提到的产品规格和资讯仅供参考。如有内容更新，恕不另行通知。

保修条款

一、服务期限

佛山双木三林科技有限公司承诺产品的良好品质，产品自售出之后7天内正常使用情况下出现故障，客户可以选择退货或者保修（不影响二次销售才可退货）。正常使用一年内出现故障可以免费保修。

二、购买日期以销售商开出的购机发票或收据日期为准，网购可以交易截图为准。

三、有以下情况都不能享受“三包”服务

1. 一切人为因素损坏，包括非正常工作环境下使用或不按照说明书使用。
2. 用户私自拆机、改装、维修。
3. 使用非指定或许可的配件造成损坏的。
4. 机身的QC或保修贴损毁。
5. 不能出示有效购机凭证。
6. 不属于本公司产品。

四、保修方式为送修

此条款只适于中国大陆，其它地区请参考当地销售代理商的规定和国家法规。

产品特点

- 美国THX公司的THXAAA-888耳机放大电路,并取得THX认证和授权 ;
- 16欧姆输出功率达6W, 32欧时达到3W, 并且此时维持最低失真度 ;
- 300欧时不失真输出电压达11.2Vrms ;
- 0.1 Hz至500 kHz (-3dB) 频率响应 ;
- SNR>137dB ;
- THD<0.00006% ;
- 超紧凑设计, 非常适合桌面耳机系统 ;
- 平衡立体声耳机输出 ;
- 平衡立体声线路输入 ;
- 高精度低温漂电阻, 以适应温度变化 ;
- 高品质继电器和无冲击声设计 ;
- 高精度低噪声256级继电器音量控制 ;
*实际使用时为了音量更加线性, 屏蔽了多余的级数。
- 高低两档可切换增益控制 ;
- 耳机放大器具有DC, 过压, 过流, 短路和热保护的全面保护 ;
- 高效超低噪声电源 ;
- 1.9吋的液晶显示屏。



经THX公司许可制造, THX和THX商标已经在美国和其他司法管辖区注册。版权所有。

技术参数

- 音频部分:
 - 输入方式: 平衡 x1, 非平衡 x1
 - 输出方式: 平衡 x1, 非平衡 x1
 - 输出功率:
 - 6W x 2 (16 Ω)
 - 3W x 2 (32 Ω)
 - 440mW x 2 (300 Ω)
 - 220mW x 2 (600 Ω)
 - 信噪比: 137dB, A-Weighted
 - 剩余噪音: 1.9uV, A-Weighted
 - THD+N: -123dB, 0.00006% (A-Weighted)
 - THD+N: -117dB, 0.00013% (20-20kHz, 32 Ω , -3dB)
 - THD: -125dB, 0.00006% (1 kHz, 16 Ω , -3dB)
 - 输入阻抗: 47k Ω
 - 输出阻抗: 接近 0 Ω
 - 频率响应: 0.1Hz - 500kHz(-3dB)
 - 增益: 低(+0dB), 高(+10dB)
- 其他:
 - 电源电压/电源频率: AC100-240V, 50-60 Hz
 - 能量功耗(EN60065): 24 W
 - 待机功率: <0.1W
 - 尺寸: 187.5X154X40(mm)
 - 包装尺寸: 282x232x79(mm)
 - 重量: 790g

规格时有变更, 恕不另行通知

关于遥控器

- 如果遥控器距离本机很近时操作仍无效，请用新电池更换。
- 如果要长时间不使用遥控器，请取出遥控器的电池。
- 按照电池处置的地方性法规处置废旧电池。

遥控器的使用



注意

1. 遥控器请使用2节7号(AAA)电池
2. 第一次操作SH-9时，先按B键

部件介绍



- | | | |
|--------------|------------|---------|
| 1 功能旋钮 | 2 显示屏 | 3 红外接收窗 |
| 4 6.35mm耳机插口 | 5 平衡耳机插座 | 6 RCA输入 |
| 7 XLR平衡输入 | 8 AC电源输入接口 | |

*注:功能旋钮

- 1、旋钮:音量加减,菜单切换,功能选择
- 2、按键:短按,进入菜单,确认
长按,退出菜单,开关机


操作说明

1. 主界面




- 1、输入模式(BAL/RCA)
- 2、增益(高/低)
- 3、音量

操作说明




有7页的设置, 屏幕如左图所示

1. INPUT (输入选择)
2. GAIN (增益模式)
3. VOL MODE (音量调整)
4. DIMMER (自动熄屏)
5. BRIGHTNESS (亮度)
6. REMOTE CODE (遥控码值选择)
7. VERSION (版本号)




输入菜单

1. BALANCED (平衡输入)
2. UNBALANCED (非平衡输入)



增益菜单


1. LOW (+ 0dB)
2. HIGH (+ 10dB)



音量控制模式:

1. 开启: 音量继电器会间隔变动, 以避免继电器动作过于频繁, 延长继电器寿命!
2. 关闭: 快速旋转音量旋钮时, 继电器逐级跳至设定音量。

操作说明




DIMMER (自动熄屏): 5秒~60秒

(范围5秒 - 60秒, 设置后, 屏会在这个时间内自动熄灭, 遥控或者旋钮任意操作屏幕会重新点亮。这样可以很大程度上减少光污染, 提升听音环境的舒适性!)




亮度调节范围: LEVEL 1~6



遥控码值选择:

选择使用遥控器上的A, B, C, 如果是其它请选择D。这个功能的作用是在当SH-9与SD-9同时使用时, 因为它们默认都是B, 因此会冲突, 所以可以在这里设定SH-9的遥控码值, 以免冲突。



版本号

S.M.S.L

THX[®]
TECHNOLOGY



SH-9

USER MANUAL

The contents of this manual may be changed with the edition, and are subject to change without notice.

Ver: 1.1

Safety Notes

- Install this unit in a well ventilated, cool, dry, clean place-away from direct sunlight, heat sources, vibration, dust, moisture, or cold..
- Use the voltage specified on this unit Only. Using this unit with a higher voltage than specified is dangerous and may cause fire , damage to this unit, or personal injury. Our company will not be held responsible for any damage resulting from the use of this unit with a voltage other than that specified.
- Do not attempt to modify or fix this unit by yourself. Contact alesperson or customer service when any service is needed. The cabinet should never be opened for any reason.
- When not planning to use this unit for long periods of time (i.e. when going on vacation), disconnect the power cable from the AC wall outlet.

Important note:

The product specifications and information mentioned in this manual are for reference only. The content of this manual is subject to change without notice.

Warranty Terms

1.The Term of Service

Foshan Shuangmusanlin Technology Co., Ltd promises to offer good-quality products. If the product is broken in 7 days after purchasing when you use it normally, you can choose to send it back for return, replacement or repairing (only the product does not affect the second sales can be returned). Repairing for free in one year if you use it normally.

2.Date of purchase is in accordance with the date on invoice or receipt used by seller, and if you buy it on line, you can show the screenshot of trade.

3.If an inappropriate usage causes the unit damaged, the warranty will be void. As below.

- All damages by inappropriate use, including using it under non-normal working environment or without following the instructions.
- Dismantling, refitting, repairing by user in private.
- Causing damage by using some fittings instead of the designative or accredited ones.
- Cannot provide credible proof of purchase.

4.Sending it back to our company for repairing.

5.Contact your S.M.S.L Audio reseller for a return or replacement.

Features

- THXAAA-888 Headphone Amplifier with THX AAA Technology;
- 6 Watts into 16 Ohm, 3 Watts into 32 Ohm Headphones with lowest THD+N ;
- 0.1 Hz to 500 kHz(-3dB) Frequency Response ;
- SNR>137dB ;
- THD<0.00006% ;
- Ultra-Compact Design, Perfect for Desktop Systems ;
- Balanced Stereo Headphone Output ;
- Balanced Stereo Line Input;
- High Precision Resistors for Temperature Stability ;
- Pop-less Design with High-Quality Relays ;
- High precision and low noise 256 level relay volume control ;
*In actual use, in order to make the volume more linear, the extra levels are shielded.
- 2 Positions Switchable Gain Control ;
- Fully Protection with DC, Over-Voltage, Over-Current, Short-Circuit and Thermal Protection on Headphone Amplifier ;
- High-Efficiency Ultra-Low-Noise Power Supply .
- 1.9 inch LCD display.



Manufactured under license from THX Ltd. THX and the THX logo are registered in the U.S. and other jurisdictions. All rights reserved.

Specifications

■ Audio Section:

Inputs:	Balanced x1, Unbalanced x1
Outputs:	Balanced x1, Unbalanced x1
Output Power:	6W x 2 (16 Ω) 3W x 2 (32 Ω) 440mW x 2 (300 Ω) 220mW x 2 (600 Ω)
SNR:	137dB, A-Weighted
Output Noise:	1.9uV, A-Weighted
THD+N:	-123dB, 0.00006% (A-Weighted)
THD+N:	-117dB, 0.00013% (20-20kHz, 32 Ω , -3dB)
THD:	-125dB, 0.00006% (1 kHz, 16 Ω , -3dB)
Input Impedance:	47k Ω
Output Impedance:	Near 0 Ω
Frequency Response:	0.1Hz - 500kHz(-3dB)
Gain:	Low(+0dB), High(+10dB)

■ General Section:


Power supply voltage/frequency:	AC100-240V, 50-60 Hz
Power consumption(EN60065):	24 W
Power consumption in standby mode:	<0.1W
Size:	187.5x154x40(mm)
Packing size:	282x232x79(mm)
Weight:	790g

Specifications are subject to change without notice.

Remote control

- Install 2 x AAA batteries as instructions.
- When using the remote control, point it toward the remote control signal receiver on the main unit from a distance of 5 m (16 ft) or less. Do not place obstructions between the main unit and the remote control.
- The remote control might not work if the remote control signal receiver on the unit is exposed to direct sunlight or bright light. If this occurs, try moving the unit. Beware that use of this remote control could cause the unintentional operation of other devices that can be controlled by infra.

Operating the remote control



Note

1. This remote controller use 2 x R03/AAA batteries.
2. When you first operate SH-9, press the B key first.

Display Interface and Instructions



- | | | |
|-------------------------|---------------------------|-----------------|
| 1 Knob | 2 Display | 3 Remote window |
| 4 6.35mm headphone jack | 5 Balanced headphone jack | 6 RCA input |
| 7 XLR input | 8 Power AC input | |

* Note: Knob

1. Knob: Volume/Menu up or down
2. Button: Press to Menu/Enter
Hold to Return or Power ON/OFF


Operating instructions

1. Main




- 1、 Input mode (BAL/RCA)
- 2、 Gain (High / Low)
- 3、 Volume

Display Interface and Instructions




There are 7 pages of settings in this menu.

1. INPUT
2. GAIN
3. VOL MODE
4. DIMMER
5. BRIGHTNESS
6. REMOTE CODE
7. VERSION




INPUTS

1. BALANCED
2. UNBALANCED



GAIN


1. LOW (+ 0dB)
2. HIGH (+ 10dB)



VOL MODE

1. ENABLE: Reduce the frequency of relay operation and increase the service life of relay.
2. DISABLE: When the rapidly rotating volume knob, the relay jumps to the set volume step by step.


Display Interface and Instructions



DIMMER: 5 second ~ 60 second
(The range is 5 seconds-60 seconds. After setting, the screen will automatically go off within this time, and the screen will re-light up if you operate the remote control or the knob at any time.)




Brightness Level: 1 ~ 6



REMOTE CODE:

For remote control code selection, choose to use A, B, C on the remote control, if it is other, please choose D. This function is used when SH-9 and SD-9 are used at the same time, because they are both B by default, so it will Conflict, so you can set the remote control code value of SH-9 here to avoid conflict.



VERSIONS